



# WEN 18 Gauge 2-Inch Air Brad Nailer Pressure Regulator Chamber Gasket Replacement

This guide will aid in replacing the WEN 18 Gauge 2-Inch Air Brad Nailer Pressure Regulator Chamber Gasket.

Written By: Ousman Jammeh



This document was generated on 2019-09-22 01:25:29 PM (MST).

## INTRODUCTION

If you need to replace a Brad Nailer Pressure Regulator Chamber Gasket, follow the steps outlined in this guide. For this guide, you will need a 4mm Allen wrench. The steps outlined are relatively easy to follow.

### TOOLS:

- 4mm Allen Wrench (1)

## Step 1 — Pressure Regulator Chamber Gasket



- Using a 4mm Allen wrench, remove the 4 Allen screws, 44mm in length, from the yellow cap on the back of the brad nailer.

## Step 2



- Remove the yellow cap to reveal the gasket.
- i* Keep the nailer upright so the piston does not fall out. If the piston falls out, simply put it back in place.

## Step 3



- Remove the faulty gasket and replace it with a new gasket.

To reassemble your device, follow these instructions in reverse order.