



Wii U GamePad Battery Replacement

Remove the battery in order to get the Nintendo Wii U Gamepad case off

Written By: Valentina Cerruty



INTRODUCTION

In order to remove the battery, you will need the tool PH0. (small screwdriver) This guide will help you to remove the battery and be able to remove the Nintendo's case.

TOOLS:

- Phillips #0 Screwdriver (1)

PARTS:

- Nintendo Wii U GamePad Battery (1)

Step 1 — Battery



- Place Gamepad face down and remove the two 4.7 mm screws with a Phillips size #00 screwdriver.

Step 2



- Lift and remove the battery plate.

Step 3



- With your finger, press down and pull back on the battery connector plug.
- Remove the battery from the battery case.

To reassemble your device, follow these instructions in reverse order.