



WowWee MiPosaur Battery Replacement

This guide will show you how to remove and replace the batteries in the WowWee MiPosaur.

Written By: Melissa Bender



INTRODUCTION

This guide will lead you through the process of opening the battery panel of the WowWee MiPosaur for the purpose of replacing batteries.

TOOLS:

- [Phillips #1 Screwdriver \(1\)](#)

PARTS:

- [AA Batteries \(4\)](#)

Step 1 — Battery



- Use a Phillips head #1 screwdriver to remove 3 2mm screws from MiPosaur's underside panel.
- *(i)* You may need to use an extension on your screwdriver to work around small space between the panel and the dinosaur's leg.
- *(i)* You can remove the bottom screw completely, but the top two screws are captive and do not need to be removed entirely.

Step 2



- Firmly grasp the panel and pull apart from the base of the toy.

Step 3



- Remove the battery from the device.

To reassemble your device, follow these instructions in reverse order.