



X-Treme Tablet Generation 2 Power Button Replacement

Replacing the power button for X-Treme Tablet Generation 2

Written By: Faiz Kasman



INTRODUCTION

If the power button on your device is not working, consider using this guide to remove and replace it for your device.

TOOLS:

- [Phillips #0 Screwdriver \(1\)](#)

Step 1 — Power Button



- Remove the two screws using a Phillips #0 screwdriver.
- Pry the back cover carefully and continue going around the device.

Step 2



- Remove three screws that are attached to the motherboard using the Phillips #0 screwdriver.
- Carefully lift the motherboard to free up the faulty power button and take it out.

Step 3



- Replace the power button.
- For easy installation, have the tablet placed vertically while inserting the power button.

To reassemble your device, follow these instructions in reverse order.