



# XQ-673H Water Tubes Replacement

This guide will show the owner how to take apart the device and show the owner how to replace the water tubes.

Written By: Sean Perry



## INTRODUCTION

This guide will help the owner of a Kitchen Gourmet XQ-673H replace the water tubes.

### TOOLS:

- Small Needle Nose Pliers (1)
- Phillips #1 Screwdriver (1)

## Step 1 — Water Tubes



**⚠** Make sure the device is unplugged before continuing.


- Turn the Kitchen Gourmet upside down.

## Step 2




- Using a Phillips #1 screwdriver, remove the six 10mm screws found on the bottom of the device.
- Remove the bottom cover.

## Step 3





- Using a Phillips #1 screwdriver, remove the six 12mm screws.
- Some screws are not visible from this photo, but their location is highlighted by the circles.

## Step 4



- Using small needle nose pliers, squeeze the metal that is covering the tube.
- Carefully slide down the metal covering.
- Repeat this step for the other tube.

## Step 5




- Using your fingers, gently slide off the Water Tubes.

## Step 6



- Carefully lift the bottom section off the device.

## Step 7



- Using small needle nose pliers, squeeze the metal that is covering the tube.
- Carefully slide down the metal covering.
- Repeat this step for the other tube.
- Remove both of the Water Tubes completely.

To reassemble your device, follow these instructions in reverse order.