



Xbox 360 Faceplate Replacement

Written By: Walter Galan



INTRODUCTION

This guide is an internal guide used as a prereq.

TOOLS:

- [Spudger \(1\)](#)

Step 1 — Faceplate



- Insert the flat edge of a spudger between the faceplate and the outer casing near the power button.
- Run your spudger along the edge of the faceplate to release the clips securing it to the front of the console.

(i) You may also accomplish this task by using the edge of the Xbox 360 opening tool, but it may scratch the plastic case.

(i) Alternatively, you can use your hands to carefully pull the faceplate away from the Xbox.

Step 2



- Repeat the same motions as previously mentioned to release the left side of the faceplate.

Step 3



- Remove the faceplate from the front face of the console.

To reassemble your device, follow these instructions in reverse order.