




# Yuneec Typhoon H LED Board Replacement

If one of the LED lights fails on one of the propellers, this guide will help you replace the LED board.

Written By: Claire Luce



## INTRODUCTION

This guide instructs you to replace the LED lights on your Yuneec Typhoon H drone. The LED lights are important for tracking where your drone is, when flying within line of sight and for other pilots to know where your drone is in the sky.

### TOOLS:


- **Phillips #000 Screwdriver (1)**

## Step 1 — LED Board



*(i)* This guide begins with the propeller already removed.

## Step 2



- Turn the drone upside down to have easy access to the prop arm.
- Twist out the prop motor clockwise.

## Step 3



- Unscrew two 4.9mm screws on the board using a Phillips #000 screwdriver.

## Step 4



- Hold the LED board in one hand and pinch the plug at the connection to the board with the other hand.
- Pull the plug out from the connection piece.

To reassemble your device, follow these instructions in reverse order.