



Yuneec Typhoon H Landing Gear Replacement

After completing this guide, the landing gear on the Typhoon will be replaced, and you will be able to fly and land successfully.

Written By: Shasta Banchio



INTRODUCTION

Learn how and where to unscrew the landing gear legs in order to replace broken ones, without breaking your drone more.

TOOLS:

- **Phillips #00 Screwdriver (1)**

Step 1 — Landing Gear



- Lift all drone arms up so you can access the landing gear easily.

Step 2



- Unscrew the 16.9 mm screw at the top of the landing leg with a Phillips #00 screwdriver.
 - ⚠ Make sure the screw head is not stripped in the process.
 - If stripped, the whole leg, including the internal sensors, will need to be replaced.

Step 3



- Pull the landing leg out slowly and remove it from the device.

Your Yuneec Typhoon H should now be ready to fly safely again.