





Zebra GK420t Platten Rollers Replacement

Replacement of Zebra GK420T Rollers

Written By: IT Asset Team



Step 1 — Removing The Roller




- Power Off the device and open the main cover
- locate the 2 tabs on either side of the roller and push them outwards to release them
- Pull up on both tabs to release the roller from the printer

Step 2 — Building the New Roller



- The new Roller will be packaged in separate sections in the order that it needs building
- Starting on the right the shorter side of the roller place 1 tab
- On the left side of the roller place the other tab and then the cog to secure the tab in place

Step 3 — Fitting the Roller



- Make sure the printer is clear of debris
- Insert the roller keeping the tabs up
- Once inserted push the tabs down to lock in place with the body of the printer

To reassemble your device, follow these instructions in reverse order.