



Zoom Q3HD Handy Video Recorder Lense Cleaning

Cleaning lens from inside

Written By: Grace Bently



INTRODUCTION

The Zoom Q3HD is a handy video/audio recording device released in 2010 How to clean the lens from inside

TOOLS:

- [Phillips #000 Screwdriver](#) (1)
- [iFixit Opening Tools](#) (1)

PARTS:

- [Compatible Replacement](#) (1)

Step 1 — Lens



- Remove the two screws from the bottom of the device.
- *(i)* Make sure to put your screws in a safe place.

Step 2




- Flip the device over and remove the four screws bordering the grate of the device.

Step 3



- On the front of the device, slide the battery compartment cover off by pushing inward and sliding downward.

Step 4



- Remove the two screws from the lip of the battery compartment.

Step 5



- Remove the final screw from the bed of the battery compartment.


Step 6



 **WARNING:** Pieces may become loose when you separate the device in half!

- Run the pry tool along the edges of the device to begin separating the device in two halves.


Step 7



 **REMINDER:** Pieces may become loose when you separate the device in half!

- Apply upward pressure to fully separate the device into two halves.


Step 8



 **WARNING:** If you're not careful with keeping the screen close to the board, you will rip off the ribbon attaching the screen to the circuit board.

- Lift display screen keeping the top half close to the board.

Step 9



- Gently flip the black clip up attaching the ribbon of the screen to the circuit board.

Step 10



- Gently slide the ribbon from the circuit board, removing the screen.

To reassemble your device, follow these instructions in reverse order.