



iClicker Teardown

The purpose of this guide is to show the different components used in an iClicker.

Written By: Vicente Rios



Step 1 — iClicker Teardown



- Remove the battery cover

Step 2




- Remove the two AAA batteries

Step 3




- Remove the three screws using a screwdriver

Step 4




- Remove the back cover

Step 5




- Remove the positive and negative battery contacts using pliers

Step 6




- Remove the circuit board

Step 7



- Remove the soft touch buttons

Step 8



- You're done!

To reassemble your device, follow these instructions in reverse order.