



# iHome iP41BR iPod Adapter Replacement

Replace the iPod adapter on your iHome iP41BR

Written By: Paige Reisman



 **TOOLS:**

- **Phillips #0 Screwdriver** (1)
- **Phillips #00 Screwdriver** (1)
- **Metal Spudger (optional)** (1)

## Step 1 — Remove Phillips Screws




- Remove the two 8mm Phillips #0 screws from the iHome's iPod adapter.

## Step 2 — Pull Out iPod Adapter



- Use the metal spudger to loosen the edges of the plastic cover.
- Pull the adapter up and away from the housing, rotating it forward slightly as you lift it so the top faces you.


## Step 3



- Pull firmly on the red and black cable connector to disconnect it.
- Pinch the ribbon cable on both sides and pull it firmly to disconnect it.


**i** The ribbon cable takes a bit more force to disconnect than the red and black cable. Make sure to pull evenly on the entire cable for ease of removal.

## Step 4 — Remove Plastic Cover



- Remove the four 7mm Phillips #00 screws attaching the black plastic cover to the bottom of the adapter assembly.

## Step 5



- Pull the ipod adapter out of the plastic holder ad replace.

To reassemble your device, follow these instructions in reverse order.