




# iMac G5 20" Model A1145 RAM Replacement

Written By: Andrew Bookholt



## INTRODUCTION

Upgrade your RAM for an instant increase in speed.

### TOOLS:

- Phillips #1 Screwdriver (1)

### PARTS:

- PC2-4200 2 GB RAM Chip (Desktop) (1)

## Step 1 — Access Door



- Orient the iMac face-side down on a table with the bottom edge facing yourself.
- Remove the two Phillips screws securing the access door to the bottom grille of your iMac.

*(i)* The screws are captive in the access door.

**⚠ Before beginning the repair, unplug the computer and press and hold the power switch for 20-30 seconds, to discharge internal capacitors.**

## Step 2




- Remove the access door.

## Step 3 — RAM



- Insert your fingers into the two RAM arms and pull both arms toward yourself to eject the RAM chip.

## Step 4



- Slide the RAM chip straight out of its socket.
- Make sure both RAM arms are fully rotated outward before reinstalling your RAM chip.

To reassemble your device, follow these instructions in reverse order.