



iMac Intel 20" EMC 2133 and 2210 Access Door Replacement

Written By: Walter Galan



INTRODUCTION

Remove your access door to replace RAM chips or to open the case of your iMac.

TOOLS:

- [Phillips #1 Screwdriver \(1\)](#)

Step 1 — Access Door



- Loosen the single Phillips screw in the center of the access door.
- *(i)* This screw is captive in the access door.
- Remove the access door from your iMac.

To reassemble your device, follow these instructions in reverse order.