



# iMac Intel 27" EMC 2429 Access Door Replacement

Replace the access door on your iMac Intel 27" EMC 2429.

Written By: Phillip Takahashi



## INTRODUCTION

Remove the access door to replace it or access the RAM.

### TOOLS:

- Phillips #2 Screwdriver (1)

## Step 1 — Access Door



- Loosen the three Phillips screws securing the access door to the bottom edge of your iMac.
- These screws will remain captive in the access door.
- Remove the access door from your iMac.

**★** During reassembly, fasten the access door loosely and align it with the pocket cut into the outer case of the iMac before fully tightening the screws.

To reassemble your device, follow these instructions in reverse order.