



# iOpener (Legacy) Instructions

Basic instructions for using the original iOpener to open up glued-shut devices.

Written By: Andrew Optimus Goldheart



## INTRODUCTION

The [iOpener](#) is an insulated, heat-retaining bag that can be heated in a microwave and used to transfer heat to the adhesive along the edge of an iPad or similar device.

**Follow these basic instructions to get started with your original style (white, solid-filled) iOpener. For the new, liquid filled iOpener, follow [this guide](#) instead.**

For detailed instructions specific to your device and repair, see our set of [iPad repair guides](#).

### TOOLS:

- [iOpener](#) (1)
- [Microwave](#) (1)

## Step 1 — iOpener (Legacy) Instructions



- ⓘ We recommend that you clean your microwave before proceeding, as any nasty gunk on the bottom may end up stuck to the iOpener.
- Place the iOpener in the center of the microwave.

 For carousel microwaves: Make sure the plate spins freely. If your iOpener gets stuck, it may overheat and burn.

## Step 2



- Heat the iOpener for **one minute**.

 If you are using a new, liquid-filled iOpener, only microwave your iOpener for 30 seconds, and be sure to follow [the appropriate guide](#).
- Throughout the repair procedure, as the iOpener cools, reheat it in the microwave for an additional minute at a time.

 Be careful not to overheat the iOpener during the repair. Always wait at least two minutes before reheating the iOpener.

## Step 3



- Remove the iOpener from the microwave, holding it by the printed tag.
- If your iOpener has no tag, grab it by a corner, or handle with an oven mitt to avoid burning yourself.

 The bag will be very hot, so be careful when handling it. Use an oven mitt if necessary.

## Step 4



- Lay the iOpener flat on the edge of the device, over an adhesive seal you wish to heat. Smooth the iOpener along the surface to ensure good contact with the device.
- Let the bag sit on the device for approximately 90 seconds before attempting to open the front panel.
- At this point you should be able to begin prying under the screen with a plastic opening tool. Be sure to see your device's [specific guide](#) for where and how to do this.

 Throughout the procedure you may need to reheat the iOpener. To prevent overheating the iOpener, always wait at least two minutes before microwaving again. Do not microwave the iOpener for more than one minute at a time.

To reassemble your device, follow these instructions in reverse order.