iPega 9023 Disassembly

This guide will give step by step instructions to repair sticky ABXY buttons.

Written By: AndrewGueguen

This document was generated on 2019-09-30 08:58:14 AM (MST).

© iFixit — CC BY-NC-SA   www.iFixit.com   Page 1 of 4

TOOLS:

- Phillips #0 Screwdriver (1)
- 64 Bit Driver Kit (1)

This document was generated on 2019-09-30 08:58:14 AM (MST).

Step 1 — Remove Cover

- Remove the four screws with the 3 mm Triage driver from the backside of the controller.

- Use the 3 mm Triage Driver for the screws in red.

- Use the 4 mm nut driver as a makeshift extension to remove the screws in green.

Step 2 — Removing the logic board

- Remove the 4 screws holding the logic board in place.

This document was generated on 2019-09-30 08:58:14 AM (MST).

To reassemble your device, follow these instructions in reverse order.

This document was generated on 2019-09-30 08:58:14 AM (MST).