




iPhone 11 Pro Rear Case Replacement

This guide will show how to remove speaker, cables, taptic engine, battery, logic board, and button covers on iPhone 11 Pro

Written By: Arty



INTRODUCTION

[video: https://www.youtube.com/watch?v=dYuDcT_et_8]

Use this guide to remove all components from the rear case of your iPhone 11 Pro. This guide will show you how to remove speaker, cables, taptic engine, battery, logic board, and button covers so you can replace a dented or bent cover.

TOOLS:

- [iPhone Standoff Screwdriver](#) (1)
- [P2 Pentalobe Screwdriver iPhone](#) (1)
- [Tri-point Y000 Screwdriver Bit](#) (1)
- [Phillips #000 Screwdriver](#) (1)
- [Tweezers](#) (1)
- [Suction Handle](#) (1)
- [Spudger](#) (1)

To reassemble your device, follow these instructions in reverse order.