iPhone 1st Generation SIM Card Replacement

Written By: iRobot

INTRODUCTION

How to remove the SIM card from the 1st Generation iPhone.

TOOLS:

- SIM Card Eject Tool (1)

PARTS:

- iPhone Gen 1 SIM Card Tray (1)
- iPhone Gen 1 SIM Card (1)

This document was generated on 2019-09-16 12:06:39 PM (MST).

www.iFixit.com

Step 1 — SIM Card

- Insert a SIM card eject tool or paper clip into the hole next to the headphone jack.

- Press down on the paper clip until the SIM card tray pops out.

Step 2

- Grasp the SIM card tray and slide it out of the iPhone.

To reassemble your device, follow these instructions in reverse order.

This document was generated on 2019-09-16 12:06:39 PM (MST).