



iPhone 5 Battery Connection Replacement

Internal prerequisite guide to disconnect the battery.

Written By: Andrew Optimus Goldheart





TOOLS:

- [Phillips #00 Screwdriver](#) (1)
 - [iFixit Opening Tools](#) (1)
-

Step 1 — Battery Connection



- Remove the following two screws securing the metal battery connector bracket to the logic board:
 - One 1.8 mm Phillips screw
 - One 1.6 mm Phillips screw

Step 2




- Remove the metal bracket securing the battery connector from the iPhone.

Step 3



- Use a plastic opening tool to gently pry the battery connector up from its socket on the logic board.

 Be very careful to only pry up on the battery connector and not the socket on the logic board. If you pry up on the logic board socket, you may break the connector entirely.

To reassemble your device, follow these instructions in reverse order.