



iPhone 5 headphone jack for music remote control to wait for headphones

Detachment of jack plugs (e.g., the original Apple headset) results in a conductive layer in the headphone jack

Written By: RustyOcean

INTRODUCTION

Detachment of jack plugs (e.g., the original Apple headphone) results in a conductive layer between the individual segments of the jack plug. This affects the music remote control (play, pause, song change).

Step 1 — iPhone 5 headphone jack for music remote control to wait for headphones



- **Step 1:** Carefully loosen the dust in the headphone jack with a soft tool (such as a toothpick) and remove it.

Step 2



- Roll a piece of very fine sandpaper (about 1cm x 2cm) into a thin roll and carefully sand the deposits inside the headphone jack. Caution: The round pins that make contact between the jack plug and the headphone jack should not be damaged.

Repeat the steps in order to reassemble your device.