



iPhone 7 Plus SIM Card Replacement

Eject the SIM card tray to replace the network SIM card in your iPhone 7 Plus.

Written By: Jeff Suovanen



INTRODUCTION

Use this guide to remove or replace the SIM card in your iPhone 7 Plus.

TOOLS:

- [SIM Card Eject Tool](#) (1)

PARTS:

- [iPhone 7 Plus SIM Card Tray](#) (1)
- [iPhone 7/7 Plus SIM Card Tray Gasket](#) (1)

Step 1 — SIM Card



- Insert a SIM card eject tool or a paperclip into the small hole in the SIM card tray.
- Press firmly to eject the tray.

Step 2



- Remove the SIM card tray from the iPhone.
- *(i)* The SIM card will fall out of the tray easily.
- When reinserting the SIM card, ensure that it is in the proper orientation relative to the tray.
- A thin rubber gasket around the SIM tray provides water and dust protection. If this gasket is damaged or missing, replace the gasket to protect your iPhone's internal components.

To reassemble your device, follow these instructions in reverse order.