



# iPhone 8 Barometric Vent Replacement

Prerequisite only. Removes the barometric vent for the iPhone 8.

Written By: Arthur Shi



# INTRODUCTION

Prerequisite only.

## TOOLS:

- [Phillips #000 Screwdriver \(1\)](#)

## Step 1 — Barometric Vent



- Remove the two screws securing the barometric vent to the rear case:
  - One 2 mm Phillips screw
  - One 1.8 mm Phillips screw

## Step 2



- Gently push the barometric vent in the direction of the battery to separate the adhesive securing the vent to the bottom edge of the iPhone.

## Step 3



- Remove the barometric vent.

To reassemble your device, follow these instructions in reverse order.