



iPod Shuffle 1st Generation Hold Switch Replacement

Written By: iRobot



INTRODUCTION

The plastic hold switch.

TOOLS:

- Spudger (1)

PARTS:

- iPod Shuffle Gen 1 Hold Switch (1)

Step 1 — Hold Switch



ⓘ Before opening your iPod, ensure that the hold switch is in the locked position.

Step 2



- Use a spudger to pry up the white plastic hold switch.

To reassemble your device, follow these instructions in reverse order.