



# iomega LDHD250-U Teardown

Written By: Nate Pritzker



 **TOOLS:**

- Phillips #0 Screwdriver (1)

## Step 1 — Remove Rear Screws



**⚠ Remember to power off and unplug the unit before opening it up!**


- Remove the two PH #0 Screws

## Step 2 — Removing the cover



- After removing the back part of the unit, slide the front part out.
- Remember to put aside the center part you removed

## Step 3 — Removing the Hard Drive



- There are two ways to remove the Hard Drive
  - 1. Removing the 4 screws on the side of the unit
  - 2. Sliding the HDD back and then releasing it (my unit will not slide back)
- The HDD can now be lifted out, unplugged, and replaced, upgraded, or keep it the same.

 Pull up and unplug as the cables can break if too much force is applied

To reassemble your device, follow these instructions in reverse order.