



top and bottom covers

This will be the guide on how to open the covers of a control Dualshock 2.

Written By: ath67



INTRODUCTION

Sorry for my English, I'm from Brazil And I'm very happy to have a guide at iFixit

TOOLS:

- [Phillips #00 Screwdriver](#) (1)

Step 1 — top and bottom covers



- Remove all five screws (very easy)

Step 2



- Gently pull the covers apart to not damage the covers.

To reassemble your device, follow these instructions in reverse order.