Asus K55a-si50301p Wifi Card Replacement

Replace your wireless card to restore wifi capabilities to the Asus K55a-si50301p.

Written By: Zack Cannon

This document was generated on 2020-01-03 04:38:32 PM (MST).

© iFixit — CC BY-NC-SA
www.iFixit.com
Page 1 of 7

🔧 TOOLS:

- [Phillips #0 Screwdriver](#) (1)
- [iFixit Opening Tools](#) (1)
- [Phillips #1 Screwdriver](#) (1)

This document was generated on 2020-01-03 04:38:32 PM (MST).

Step 1 — Battery

- Press and slide the two battery retention clips on either side of the battery towards the unlock position.

Step 2

- Pull the right side retention clip so that the red indicator is showing.

- ⓘ The small graphic below the retention clip denotes locked and unlocked positions. The clip will stay put once moved into position.

This document was generated on 2020-01-03 04:38:32 PM (MST).

Step 3

- Pull the retention clip on the left hand side of the laptop away from the battery.

- Gently pull the battery out with your free hand.

Step 4 — Lower Back Panel

- Remove the two 8.5mm screws using a PH0 screwdriver.

Step 5

- Using the iFixit opening tool, gently pry the plastic cover away from its original position.

Step 6

- Gently pull up and then towards you until the plastic cover is free.

This document was generated on 2020-01-03 04:38:32 PM (MST).

www.iFixit.com

Step 7 — Wifi Card

- Remove the white and black wires from the card.

- This does not require much force. Simply squeeze on the sides of the connector and allow the end to pop off.

Step 8

- Remove the two 9mm Phillips #1 screws from the wifi card.

Step 9

- After unscrewing lift gently to remove.

To reassemble your device, follow these instructions in reverse order.

This document was generated on 2020-01-03 04:38:32 PM (MST).