Casio LK-170 Key Replacement

This guide will walk you through the steps to replace a key or multiple keys on the keyboard of the Casio LK-170 .

Written By: Samantha Baker

INTRODUCTION

Key's stuck or broken? No problem. Replace sets of keys in no time with the help of a screwdriver.

## 🔧 TOOLS:

- JIS Driver Set (1)

This document was generated on 2019-10-05 06:56:50 PM (MST).

Step 1 — Key

ⓘ You will be removing 17 11mm screws with a JIS-1 screwdriver to detach the back of the keyboard from the front.

● You will begin by removing 4 screws on each side of the piano, circled in red.

● You will then remove the four screws that are a little hidden, circled in orange.

● Next, remove the two screws in the middle of piano, as well as the three screws on the top of the piano, circled in yellow.

Step 2

- After flipping the keyboard over to the front, carefully remove the the front panel from the back panel of the keyboard using your hands.

- You should now see the screws holding the keys in place.

- (i) There are five 18mm screws per section of keys.

- With a JIS-1 bit, unscrew the five screws in the section with the key you want to replace.

Step 3

- You will be able to pick up the white keys with your hands and remove them.

To reassemble your device, follow these instructions in reverse order.