Dell Latitude E4310 Memory Door Replacement

Memory door removal for Dell Latitude E4310.

Written By: Laura Lujan

This document was generated on 2019-10-09 03:26:16 PM (MST).

© iFixit — CC BY-NC-SA   www.iFixit.com   Page 1 of 4

INTRODUCTION

Use this guide to remove the memory door on the Dell Latitude E4310 Laptop to access the RAM for upgrade or replacement.

🔧 TOOLS:

- Phillips #1 Screwdriver (1)

This document was generated on 2019-10-09 03:26:16 PM (MST).

Step 1 — Memory Door

- Unscrew the two 4mm Phillips #1 screws.

Step 2

- Lift up the panel with your finger.

(i) The screws are clipped to the panel and will remain attached.

This document was generated on 2019-10-09 03:26:16 PM (MST).

To reassemble your device, follow these instructions in reverse order.

This document was generated on 2019-10-09 03:26:16 PM (MST).