DigiTech RP70 LED Light Replacement

This replacement guide is to help you replace the LED light in the DigiTech RP70.

Written By: Elijah Smith

This document was generated on 2019-09-22 10:40:52 AM (MST).

© iFixit — CC BY-NC-SA   www.iFixit.com   Page 1 of 5

INTRODUCTION

If the LED light is broken, or dead, this guide will teach you how to remove the broken component for replacement.

🔧 TOOLS:

- [Phillips #0 Screwdriver](#) (1)
- [Soldering Iron](#) (1)

This document was generated on 2019-09-22 10:40:52 AM (MST).

Step 1 — Motherboard

⚠ Unplug the device from its AC power adapter; unplug anything connected to the input/output jacks.

● Remove the four 8mm Phillips #0 screws located on the back panel.

Step 2


● Remove the back panel to expose the motherboard.

This document was generated on 2019-09-22 10:40:52 AM (MST).

Step 3

● Remove the two 11mm #0 Phillips screws located at the bottom of the motherboard.

This document was generated on 2019-09-22 10:40:52 AM (MST).

© iFixit — CC BY-NC-SA

www.iFixit.com

Page 4 of 5

Step 4

- Lift the indented end of the motherboard opposite the input/output jacks. Then, pull away from the input/output jacks to slide the motherboard out of the casing.

Step 5 — LED Light

- Desolder the back of the motherboard where the LED light is located.

To reassemble your device, follow these instructions in reverse order.

This document was generated on 2019-09-22 10:40:52 AM (MST).