HP Pavilion dm4-2015dx Keyboard Replacement

Replacing the keyboard

Written By: Jacob Meloche

This document was generated on 2019-09-26 11:46:10 PM (MST).

© iFixit — CC BY-NC-SA
www.iFixit.com
Page 1 of 5

🔧 **TOOLS:**

- 64 Bit Driver Kit (1)

Step 1 — Keyboard

- Turn off the device, disconnect it from all power, and remove the battery.

- Remove 2 screws securing the memory cover, then remove the cover.

Step 2

- Remove the 2 screws securing the hardware cover, then remove the cover.

- Remove the 2 screws securing the hard drive cover, then remove the cover.

Step 3

- Remove the screws (as shown in pic), these two screws secure the HP keyboard.

- Make sure to use a flathead screwdriver or a similar tool to release the two keyboard tabs.

Step 4

- Turn the device right-side up and pull the keyboard frame upward. Make sure to use a flathead screwdriver or similar tool to pry the keyboard from the frame.

- Locate and remove the lockdown cable and unlock the keyboard cables.

- Slide out the keyboard cable and install a new HP Pavilion DM4 keyboard.

To reassemble your device, follow these instructions in reverse order.

This document was generated on 2019-09-26 11:46:10 PM (MST).