How to check Magnavox MWD200F fuses

Written By: Taryn

🔧 TOOLS:

- Tweezers (1)

This document was generated on 2019-12-20 11:09:13 PM (MST).

## Step 1 — How to remove Magnavox MWD200F cover

- Using a Philips screwdriver, remove the two screws on the top of the device, towards the back.

Step 2

- Remove the plastic cover by pulling up on the back and away from the faceplate.

This document was generated on 2019-12-20 11:09:13 PM (MST).

© iFixit — CC BY-NC-SA

www.iFixit.com

Page 3 of 4

Step 3

- Remove the faceplate by unclipping the latches on the bottom of the device.

- Once it's unlatched, pull the faceplate off.

Step 4 — How to check Magnavox MWD200F fuses

- Now that the device is open, you can check for any blown fuses that may need to be replaced.

To reassemble your device, follow these instructions in reverse order.

This document was generated on 2019-12-20 11:09:13 PM (MST).