Samsung Galaxy Camera Lens and Motherboard Replacement

This guide will show how to replace the lens and motherboard as one part.

Written By: Richard Hicks

## 🔧 TOOLS:

- Phillips #0 Screwdriver (1)
- iFixit Opening Tools (1)

This document was generated on 2019-09-17 03:50:16 PM (MST).

Step 1 — Screen

● Begin removing the 3/16" screws for the device.

Step 2

● Turn the device and remove the additional 3/16" screws.

Step 3

- Turn the device and remove the additional 3/16" screw.

Step 4

- Take the white cover plate off.

Step 5

- Using the plastic opening tools, pry open the camera from the bottom.

- ⓘ This may require a moderate use of force because of the sealing glue.

Step 6

- Gently pull the connector away from the motherboard.

This document was generated on 2019-09-17 03:50:16 PM (MST).

Step 7 — Lens and Motherboard

- Unscrew the motherboard's screws. There are 4 3/32" screws and 3 5/32" screws.

Step 8

- Unscrew the lens' screws. There are 1 black 4/32" screw, 3 3/16" black screws, and 2 white 5/32" screws.

Step 9

- Pull these connectors away from motherboard.

Step 10

- Lift the motherboard and lens out of the case.

To reassemble your device, follow these instructions in reverse order.

This document was generated on 2019-09-17 03:50:16 PM (MST).