![iFixit logo]

The top right corner lights Replacement

Replacing the Top corner lights in Logitech G910

Written By: Nasser

INTRODUCTION

Use this guide to replace the lights of your Logitech G910.

🔧 TOOLS:

- Phillips #0 Screwdriver (1)
- Metal Spudger (1)

　　　　　　　　　　www.iFixit.com

Step 1 — Lights

- Pull out the Keyboard from the computer.

Step 2

- Flip the keyboard and unscrew the "15" back screws.

Step 3

- Releases the front part.

Step 4

- Gently lift up the plastic film in the top right corner.

To reassemble your device, follow these instructions in reverse order.

This document was generated on 2019-09-22 08:04:33 AM (MST).

www.iFixit.com