Toshiba Satellite L305-S5946 RAM Replacement

Remove RAM from your Toshiba Satellite L305-S5946.

Written By: Michael Erberich

This document was generated on 2019-10-19 12:35:45 PM (MST).

© iFixit — CC BY-NC-SA

www.iFixit.com

Page 1 of 6

INTRODUCTION

Use this guide to replace or upgrade RAM cards in your Toshiba Satellite L305-S5946. Replacing your RAM cards will allow you to work with more programs. Doing this requires only removal of the battery as a precursor.

TOOLS:

- iFixit Opening Tools (1)
- Phillips #1 Screwdriver (1)

PARTS:

- PC2-6400 2 GB RAM Chip (1)

This document was generated on 2019-10-19 12:35:45 PM (MST).

Step 1 — Battery

- Turn the laptop upside-down.

- Position the laptop so that the display hinges are facing away from you.

Step 2

- Slide the left battery bay latch to the left.

Step 3

- Slide the right battery bay latch to the right and hold.

- While holding onto the latch, use a plastic opening tool to lift and remove the battery bay cover.

- Remove the battery.

Step 4 — RAM

- Use a Phillips #1 screwdriver to turn the screw on the RAM cover.

- Turn the screw until you hear a click.
  - ⓘ This is a captive panel screw and remains with the cover.

Step 5

- Insert the plastic opening tool into the indent and lift to remove the RAM cover.
  - (i) This is a captive panel screw and remains with the cover.

Step 6

- Use your fingernails to push the white and silver retaining clips away from each side of the RAM card.
  - (i) The RAM card should pop up at an angle.

This document was generated on 2019-10-19 12:35:45 PM (MST).

Step 7

- Use your fingers to gently pull the RAM card away from the computer.

- Repeat step 9 to remove the other RAM card that may be installed.

To reassemble your device, follow these instructions in reverse order.

This document was generated on 2019-10-19 12:35:45 PM (MST).