Toshiba Satellite L505 Laptop Keyboard Replacement

This guide is for the removal and replacement of the Toshiba Satellite L505.

Written By: Matias

This document was generated on 2020-04-04 05:16:57 AM (MST).

INTRODUCTION

Removing the keyboard from this laptop is a very simple and easy process. It should be noted that even though it is simple, it is equally as easy to push a component on the hard drive out of place since some parts of the motherboard are exposed under the keyboard

TOOLS:

- ESD-safe pry tool (1)
- Phillips #1 Screwdriver (1)

    www.iFixit.com

Step 1 — Keyboard

- Open the laptop and locate the plastic strip just above the keyboard.

- With care, slide the prying tool into an end and lift it up until you hear an audible click, meaning it has separated.

- Slowly slide a finger or the prying tool under and follow the strip to the opposite end, completely detaching the strip.

Step 2

- Remove the four screws using the Phillips #1 screwdriver.

This document was generated on 2020-04-04 05:16:57 AM (MST).

Step 3

- Gently push the clip back as you lift the top of the keyboard towards you.

- (i) There is a cable connecting the keyboard to the motherboard so do not lift the keyboard all the way out yet.

Step 4

- Gently disconnect the connector strip by pushing the white clips forward.

- Carefully pull the strip out of its port.

- Remove the keyboard from the device.

To reassemble your device, follow these instructions in reverse order.

This document was generated on 2020-04-04 05:16:57 AM (MST).