

®
DIMENSION PBX
FEATURE TEST
SPLITTING - 1-WAY AUTOMANUAL

CONTENTS

- 1. GENERAL INFORMATION
- 2. RECORDS

- 3. TEST EQUIPMENT
- 4. PROCEDURE

1. GENERAL INFORMATION

1.1 Description

1.11 This section describes the tests to be performed whenever the Splitting - 1-Way Automanual feature is provided.

1.12 This feature allows the attendant to converse privately with the called party on attendant extended calls.

1.13 By depressing the SPLIT key, the attendant can remove the split and all three parties are connected.

2. RECORDS

2.1 Form SD-97-1313 is required for recording the results of this test.

3. TEST EQUIPMENT

3.1 Telephone Set

<u>Amount</u>	<u>Code</u>	<u>Description</u>
2	500 (or equiv.)	Telephone Set

3.2 Apparatus

<u>Amount</u>	<u>Code</u>	<u>Description</u>
2	249A	Adapter

4. PROCEDURE

4.1 Test Procedure

4.101 Select two lines from the Line Assignment section of the Customer Order Document.

4.102 Utilizing the 249A Adapters, connect the telephone sets to the circuit pack test lines associated with the stations chosen in Step 4.101. Designate one Station "A" and the other Station "B".

4.103 At Station A, dial the Attendant Access Code. Verify at the console that a loop lamp flashes, ICI is displayed and the attendant is alerted.

4.104 At the attendant console, momentarily depress the ANS key and START key. Verify dial tone, Station A is split, and the SPLIT lamp is lit.

4.105 At the console, dial code for Station B. Verify Station B is ringing.

4.106 At the console, momentarily depress the SPLIT key. Verify SPLIT lamp extinguished and Station A hears audible ringing.

4.107 Answer Station B. Verify 3-way connection.

4.108 At the console, momentarily depress the SPLIT key. Verify SPLIT lamp lit and Station A is split from the attendant and Station B.

4.109 Release the console and put Stations A and B on hook. Verify console and stations are idle.

4.110 This completes the testing of the Splitting - 1-Way Automanual feature.

Manager, Denver PBX PECC

PRIVATE

THE INFORMATION CONTAINED HEREIN SHOULD NOT BE DISCLOSED
TO UNAUTHORIZED PERSONS. IT IS MEANT SOLELY FOR USE BY
AUTHORIZED BELL SYSTEM EMPLOYEES.

Printed in U.S.A.