

PROTECTIVE CONNECTING ARRANGEMENTS
SU6AQ AND STS
KS-20721 STATION COUPLER

1. GENERAL

1.001 This addendum supplements Section 463-340-102, Issue 3. Place this pink sheet ahead of Page 1 of the section.

1.002 This addendum is issued to combine step 8 with step 7 and to renumber steps 9 through 14 in paragraph 5.05.

5.05 Tests—SU6AQ and STS

2. CHANGES TO SECTION

2.001 On Page 13, change paragraph 5.05 to read as follows:

STEP	ACTION	VERIFICATION
4	Connect test set plug to receptacle on station coupler and connect alligator clip on wire coming from test set plug to terminal VF4 in the station coupler (Fig. 5).	White lamp extinguished.
5	Rotate selector switch of test set to position 8.	White lamp lighted.
6	Rotate selector switch to OFF.	White lamp extinguished.
7	Operate switch on 1013A hand test set to TALK and connect its leads to the terminals provided on the List 15 (Fig. 5). Rotate selector switch to position 1.	White lamp lighted. Dial tone heard in hand test set receiver.
8	Using the hand test set, dial the local test desk and request the testman to call back. Proceed immediately to step 9.	
9	Rotate test set switch to position 3.	White lamp extinguished.
10	Testman returns call.	White lamp flashes in unison with ringing cycle.
11	Rotate test set switch to position 1 and answer call on 1013A.	White lamp lighted.
12	Rotate test set switch to OFF.	White lamp extinguished.
13	Disconnect test set from station coupler, replace cover, and reconnect CPE.	

NOTICE

Not for use or disclosure outside the
Bell System except under written agreement