

KS-19245, LIST 1
TELEPHONE ANSWERING SET
MECHANICAL ADJUSTMENT AND MAINTENANCE

1. GENERAL

1.001 This addendum supplements Section 514-155-300, Issue 3. Place this pink sheet ahead of Page 1 of the section.

1.002 This addendum is reissued to revise paragraphs 15.03 and 15.04.

1.003 Issue 1 of this addendum was issued to:

- Revise 2.03
- Add 2.04
- Revise 3.02

2. CHANGES TO SECTION

ISSUE 1 CHANGES

2.001 On Page 2, change paragraph 2.03 as follows.

2.03 IN-USE Lamp E2 (All Sets):

- (1) Remove top cover (2.01).
- (2) Remove List 5 amplifier (3.03).
- (3) Pull out and hold spring clip, if present, on side of lamp socket and remove lamp E2 (Fig. 4).
- (4) Replace lamp E2, List 5 amplifier, and top cover.

2.002 On Page 2 add paragraph 2.04 as follows.

2.04 AUTO-ANS Lamp E3 (All Sets):

- (1) Remove top cover (2.01).

- (2) Remove ENA relay (3.04).

- (3) Pull out and hold spring clip, if present, on side of lamp socket and remove lamp E3 (Fig. 4).

- (4) Replace lamp E3, ENA relay and top cover.

2.003 On Pages 2 and 3 change paragraph 3.02 as follows.

3.02 KS-19245, List 3 Recorder:

- (1) Remove top cover (2.01).

- (2) Remove List 6 cartridge (6.01).

- (3) Remove four screws and remove side cover (Fig. 7).

- (4) Remove three retaining screws (Fig. 2) located on the bottom of the set.



Do not lift or pry on the trim plates (Fig. 3).

- (5) Firmly grasp chassis of List 3 recorder and carefully withdraw until plug-in receptacle is disengaged (Fig. 4).

- (6) Carefully move recorder toward rear of set to clear plastic MESSAGE INDICATOR DIAL (Fig. 9) and remove recorder from set.

- (7) Plug new recorder into the plug-in receptacle (Fig. 4).

- (8) Replace and tighten the three retaining screws.

NOTICE

Not for use or disclosure outside the
Bell System except under written agreement

(9) Replace List 6 cartridge (6.02).

- List 6 cartridge properly installed

(10) Replace side and top covers.

- Lamp bulb.

ISSUE 2 CHANGES

2.004 On Page 9 change paragraph 15.03 as follows.

2.005 On Pages 9 and 12 change paragraph 15.04 as follows.

15.03 ON-OFF (medallion) lamp lighted. Check following if otherwise:

15.04 Functions (Preliminary Check).

- Function selector—Any position other than OFF
- Power cord properly installed
- Fuse not blown

A. Announcement Record and Announcement Check

Following conditions should exist:

- Function Selector—ANN-REC or ANN-CHECK position
- ON-OFF (medallion) lamp lighted
- Forward limit switch on List 3 recorder not operated.

Danger: Disconnect power cord before checking fuse.