



Monster DNA Ear Cushion Replacement

This guide gives information on how to replace the ear cushions on the Monster DNA Headphones.

Written By: Sherry Xu



INTRODUCTION

Oftentimes the ear cushions get ripped, and these will eventually need to be replaced. This has been known to be a very common issue when using these headphones.

If they are not ripped, they may just need to be put back into place and potentially glued down. Doing all this is very easy and will not require more than 5 minutes of your time.

TOOLS:

- [Super Glue](#) (1)
-

Step 1 — Ear Cushion



- Grab the ear cushion by the bottom, pull down, forward and then up to take off the cushion as a whole.

Step 2



- Apply glue to paste cushion back on by applying it to the edges of the earpiece.

Step 3



- Apply pressure on the cushion until the glue sets.
- ★ Put cushion back on first
- ⓘ If this does not work, the ear cushion may need to be replaced.

To reassemble your device, follow these instructions in reverse order.