




Vtech Kidizoom Smart Watch DX Battery Replacement

This guide will show you how to properly replace the battery on this watch.

Written By: Navin Ramkishun



INTRODUCTION

Battery dead, or not holding a charge? Follow this guide to replace it with a new one! Note: This guide requires [soldering](#).

TOOLS:


- [iFixit Opening Tools](#) (1)
- [Soldering Iron](#) (1)
- [Desoldering Braid](#) (1)
- [Phillips #00 Screwdriver](#) (1)
- [Solder](#) (1)

Step 1 — Master Switch



- ⚠ Make sure the master switch is "OFF" before disassembly, to avoid an electric shock.
- Flip the watch over with the back facing up.

Step 2



- Remove the four 6.0 mm screws on the back plate with the Phillips #00 screwdriver.

Step 3



- Gently pull the back plate from the watch casing.

Step 4



- Lift the master switch from the circuit board.

Step 5 — Circuit Board



i The speaker wires are fragile. They may break if excessive force is used to remove the circuit board.

⚠ Removal of the circuit board requires [soldering](#).

- Gently push on the display from the front, near the camera. The circuit board and display will pop out through the back.

Step 6



- Lift the circuit board carefully from the casing, without breaking or detaching the speaker wires at the bottom of the circuit board.

Step 7




- Note which wire is connected to which lead before continuing. There are no markers on the circuit board to indicate where each wire belongs.
- De-solder the black speaker wire from the circuit board.

Step 8




- De-solder the red speaker wire, as in the previous step.

Step 9



- Wait for the solder to cool down and solidify, then remove the circuit board from the casing.

Step 10 — Battery




- Using the plastic opening tool, gently pry the edges of the battery away from the circuit board.
- There is a thin layer of adhesive holding the battery to the circuit board. This will remain sticky after prying.

Step 11




- De-solder the red battery wire from the circuit board.

Step 12



- Repeat the de-soldering for the black (ground) wire.

Step 13



- Pull the battery free, and wait for the solder to cool before handling further.

To reassemble your device, follow these instructions in reverse order.