



# Boxee Box Teardown

A sneak peek inside the Boxee Box.

Written By: Walter Galan



## INTRODUCTION

The Boxee Box is a cubist deviation from the traditionally rectangular set-top box. The oddly-shaped form factor forced D-Link to make the internals equally odd. But that also made it super fun to take apart!

We're also taking action against made-for-obsolescence devices with our [Self-Repair Manifesto](#). Pay with a tweet and get a free poster!

### TOOLS:

- [Phillips #1 Screwdriver](#) (1)
- [Phillips #2 Screwdriver](#) (1)
- [Spudger](#) (1)

## Step 1 — Boxee Box Teardown




- Ladies and gentlemen, iFixit is proud to present the Boxee Box by D-Link.
- It's hard to ignore how much taller the Boxee Box is than the [Apple TV](#) and [Logitech Revue](#). This half-sunken cube will definitely stand out in your entertainment system.
- Yet, we feel that the Box has build quality that rivals Apple's, and is much more solid-looking than the Revue. The front panel is made of glass sturdy plastic and displays a Boxee logo once you power on the device.

## Step 2



- The Boxee Box looks huge when compared to the Apple TV, but it's really not that cumbersome in real life -- the Apple TV is just teeny tiny.
- The Box' remote is only a tad bigger, but features a Qwerty keyboard that would come oh-so-handy on the Apple TV. Otherwise, spelling out "[the lonely island](#)" takes a while on YouTube.
- It does remind us of a certain *other* [Apple product](#), though...

## Step 3




- We had to peel off Boxee's lime-green rubber base and the adhesive sheet underneath to expose four #1 Phillips and two #2 Phillips screws.
- The #2 Phillips screws are clearly visible when you peel off the rubber base.
- The #1 Phillips are recessed, so you'll need a screwdriver with a longer shaft to access them.

## Step 4



- The bottom cover of the Boxee Box pulls off fairly easily, exposing all of its boxy goodness.
- The Boxee Box gives us everything we want, and nothing we don't need:
  - HDMI out
  - Optical and analog (RCA) audio out
  - Ethernet
  - Two USB ports
- The RCA jacks are a great addition for people who want to hook up the Boxee directly to computer speakers or retro stereo equipment.

## Step 5



- A single #1 Phillips screw and a bunch of plastic clips hold the front panel to the side of the Boxee Box.
- The front panel can be detached by disconnecting the connector for the status panel.

## Step 6




- A little bit of prying and the status panel can be removed from the front panel.
- A soft white plate on the status panel disperses the light from a couple LEDs to illuminate the semi-transparent Boxee logo either orange (standby) or green (running).

## Step 7




- The Boxee Box' wireless board is secured to the metal frame by more Phillips screws.
  - It certainly is refreshing to see common screw types in electronics. When you don't need special tools to repair devices, it's easier to [fix it yourself](#).
- The wireless board is held on by a data connector and a couple antenna cables.

## Step 8




- The wireless card assembly is composed of a Mini PCI-E wireless card and an interconnect board where the cable from the motherboard is connected.
- On the back side of the interconnect board we found a Nordic Semiconductor NRF24LU1P transceiver.
  - This chip is most likely used to decode signals received from the awesome QWERTY wireless remote.
  - We recently found the same chip in the Boxee's direct competitor, the [Logitech Revue](#).
- The Mini PCI-E wireless card employs a Broadcom BCM4319XKUBG.
- An remote control antenna is printed into the interconnect board right below the Mini PCI-E socket. This is positioned near the top of the device when it is assembled to aid in remote control reception.

## Step 9




- Next come the dual USB ports, which are mounted on a small PCB.
- The PCB is connected by two #1 Phillips screws, as well as a connector that runs to the motherboard.
- A thorough USB board analysis reveals a 220  $\mu$ F capacitor, a PTC Fuse to protect against faulty USB devices, ESD Protection hardware (Clamp diodes and series inductors), and two USB sockets.

## Step 10




- We progress by removing the fan and heatsink assembly from the CPU. It's time to find out what makes this baby tick.
- Instead of using thermal paste, the Boxee Box uses a phase-change thermal pad much like the one found on the heat sink of the [Logitech Revue](#).

## Step 11



- A couple strips of EMI tape and a few more Phillips screws hold a very triangular power board in place.
- The tape is most likely placed around the exposed circuits to eliminate audio interference from the power conversion process.


## Step 12



- What do you find inside of an oddly-shaped device? An oddly-shaped power board, of course.
- On this board we find:
  - [Texas Instruments TPS51116 DC/DC Controller](#)


*(i)* This board is most likely used to convert the 12V received from the power adapter into the voltages used by the motherboard and all the accessory boards.

## Step 13



- After removing a couple more Phillips screws, the motherboard can be removed from the rest of the metal frame.
- Once it's lifted out, the power button connector is the only thing keeping us from getting a closer look at the board.
- Once the motherboard is out, the bottom metal frame can be removed from the plastic outer casing.
- The power button switch and dual antennas are mounted to the bottom metal frame, making it one compact unit.

## Step 14



- After popping off the top metal cover, we find:
  - Intel Atom CE4110 SOC processor
  - Wolfson [WM8524G](#) stereo DAC
  - AKM 8137A [multi-clock generator](#)
  - Nanya 1035 [NT5CB128MCN-CG](#) 512 MB DDR3 SDRAM (1/2 total RAM capacity)
  - RealTek [RTL8201N](#) 10/100 Ethernet PHYceiver
  - FE1.1 USB 2.0 HUB LG3A924A6180

## Step 15



- The other side of the motherboard:
  - Toshiba NF3662
  - TC58NVG3S0ETA00 1 GB NAND Flash
  - LB TS21C HF 1031S
  - Microchip [PIC24FJ64GA004-I/PT](#) 16-bit microcontroller
  - Nanya NT5CB128M8CN-CG 512 MB DDR3 SDRAM (1/2 total RAM capacity)

## Step 16



- The Boxee Box's remote is very impressive. The front side has a basic directional pad with a select button in addition to separate play and menu buttons.
- Instead of employing a full-sized keyboard like the [Logitech Revue](#), Boxee Box engineers cleverly applied a mini QWERTY keyboard to the backside of the remote.
- When we cracked the remote control open, we discovered a Nordic Semi NRF24LE1 for wireless connectivity to the Nordic Semi NRF24LU1P transceiver attached to the wireless interconnect board.

**i** These are the same two chips found in the Logitech Revue's wireless [transmitter](#) and [receiver](#) circuits.

## Step 17



- Boxee Box Repairability: **7 out of 10** (10 is easiest to repair)
  - The Boxee has a separate power board that can be replaced independently from the motherboard, should it ever fail.
  - All Phillips screws were used inside the device, requiring you to have just one screwdriver.
  - Once inside, all components come apart pretty logically.
  - The green rubber bottom of the Boxee Box is difficult to remove, and will never look the same once you've removed it.

To reassemble your device, follow these instructions in reverse order.