Dell Inspiron 13z 5323 Power button Replacement

Written By: David Gilleran

This document was generated on 2019-10-10 04:20:44 PM (MST).

© iFixit — CC BY-NC-SA   www.iFixit.com   Page 1 of 4

🔧 TOOLS:

- [Phillips #00 Screwdriver](#) (1)
- [Spudger](#) (1)

Step 1 — Power button

- Remove nine screws from the bottom case.

- Loosen the single captive screw on the base cover.

- ⓘ The screw in the base cover will stay inside the hole because it is held in by a small washer.

Step 2

- There are 3 slots on the top of the keyboard where you will have to use a thin tool, such as a small flathead screwdriver to push the tabs so the keyboard will pop out.

- You will have to flip a small tab up where the ribbon connector goes into the insert, so the connector can be released and the keyboard can be removed.

Step 3

- Unscrew the highlighted screw and slide out the power button assembly.

- Separate the palm rest from the base of the device using the blue separating tool. Before separating the palm rest from the device make sure to release all visible ribbon connectors.

- Flip the palm rest over and you will notice the power button assembly in the top right corner of the palm rest.

To reassemble your device, follow these instructions in reverse order.

This document was generated on 2019-10-10 04:20:44 PM (MST).