




# Ninja Coffee Bar CF080 Water Pump Replacement

Use this guide to replace the water pump from the coffee machine.

Written By: Jan Chen



## INTRODUCTION

This guide will show how to remove the water pump from the coffee machine.

### TOOLS:

- [Phillips #1 Screwdriver \(1\)](#)
- [Phillips #2 Screwdriver \(1\)](#)
- [iFixit Opening Tools \(1\)](#)
- [T10 Torx Screwdriver \(1\)](#)

## Step 1 — Heated Plate



- Face the machine bottom towards you.

## Step 2




- Unscrew six 0.6cm screws by holding the bottom board with Torx #10 screwdriver to remove the board.
- Unscrew one 0.6 cm screw with PH1 screwdriver to remove the board.

### Step 3




- With moderate force remove and place the "plastic opening tool" between the divide in order to remove the bottom board.

### Step 4




- Remove the bottom board with moderate force.

## Step 5





- Unscrew eight 0.6cm sized screws with Phillips #1 screwdriver, holding the silver secures on the sides of the heated plate.
- Four screws on each side, two silver secures to remove the securers, located on the sliver bar holding the heated plate (one on each end).*

## Step 6




- Unscrew two 0.6cm sized screws Phillips #1 screwdriver.
- The silver bar will fall off once screws are removed.*

## Step 7



- Remove the heated plate from the machine with easy glide.

## Step 8 — Power Module




- Remove the nine 0.5cm screws with Phillips #2 screwdriver.

***i*** Some screws are harder to see due to how deep the holes are.

**★** Recommend using Extender 4 with Phillips #2 screwdriver to help unscrew the screws within the deep holes of the machine.

## Step 9





- Remove the two 0.6cm with Phillips #2 screwdriver.

## Step 10




- Detach various colored cords from one another, using both hands to place thumb and index finger to hold each grip then separate by pulling with the degree of force.
- There will be 1 blue, 1 black, 1 red and 2 white.

## Step 11




- Remove the black board by maneuvering it through the cords.

## Step 12




- Grip the bottom end of the panel and pull it towards you to remove the module from the machine.

## Step 13




- Remove the three 0.6cm screws with Phillips #1 screwdriver.
- They are in the black holes, 1 at the top and two at the bottom.

## Step 14




- Remove the black board attached to the module.

## Step 15 — Water Pump




- Remove the three 0.6 cm screws, using Phillips #1 screwdriver with Extender 4.
- *i* Screws are hidden within the machine.

## Step 16




- Pull the water tube towards you to detach the water's tube top from the machine.

## Step 17



- Remove the two 0.8 cm screws with Phillips #1 screwdriver.

## Step 18



- Grip on the diamond shaped black holder lid and pull it away to separate the tube from the machine.

 Be careful and remove with ease as the lid is holding white tube below it.

To reassemble your device, follow these instructions in reverse order.