




# NuVision 10.1 Atom Glass Screen Replacement

If the screen is cracked or has other damages, follow this guide to replace the glass screen of your NuVision 10.1 Atom.

Written By: Carly Daniele




## INTRODUCTION

How to replace the glass screen on the NuVision 10.1 Atom. Be careful handling the lithium battery as they are prone to exploding when bent or punctured. Also, make sure to carefully remove the glass screen. If the glass breaks, there is a chance of cutting yourself.

### TOOLS:

- Tweezers - Pro/ESD/Angled (1)
- Phillips #000 Screwdriver (1)
- Metal Spudger (1)
- iFixit Opening Tools (1)

## Step 1 — Camera



- Turn the device screen side down.
- Carefully remove the back piece with the iFixit opening tool.

## Step 2




- Remove the yellow tape covering the motherboard gently with your fingers.

## Step 3




- Pull the camera plug upward and away from the motherboard with your fingers.
- Gently pull the camera from the device. The camera is held by tension.

## Step 4 — Speaker



- Carefully remove silver tape with your fingers.

## Step 5



- Remove speakers gently using your fingers, they pop out easily.
- Disconnect cords attached to the speaker from white pod.

## Step 6 — Motherboard



- Disconnect the press-fit black and red curly wire from where it connects on the motherboard.


## Step 7



- Gently remove the battery's three ZIF connectors from the motherboard. Use your fingers.

 Be careful not to puncture the battery.

## Step 8



- Disconnect the battery's bundled cable connector from the motherboard with fingers.

## Step 9



- Remove the four black 3.32mm screws on the corners of the motherboard using the Phillips #000 screwdriver. The motherboard should come out easily.

## Step 10 — Battery




- Pry the battery away from the display screen gently using a nylon spudger or the plastic opening tools.

**⚠** Using a metal spudger may bend or puncture the battery. Lithium batteries are prone to explode.

**ⓘ** There is a lot of adhesive, take your time and be careful.

## Step 11 — Glass Screen



- Remove six silver 2.8mm screws surrounding the battery using the Phillips #000 screwdriver.

## Step 12



- Remove tape securing the camera to the device gently using your fingers.
- Pry display screen away from screen glass gently using your fingers.

To reassemble your device, follow these instructions in reverse order.