



# XtremeMac Luna Dissassembly

Use this guide if you need to open up your XtremeMac Luna and access the inside components.

Written By: Daniel Johnson




## INTRODUCTION

This guide will show you how to open the XtremeMac Luna so that its inner components are easily accessible.

### TOOLS:

- [Phillips #1 Screwdriver \(1\)](#)

## Step 1 — Bottom Panel




- Flip the device over so that the batteries are closest to you.
- Remove the battery lid by pressing the battery cover's tab and pulling it away from the device.
- Push the battery against the spring and lift it out of the casing.
- Repeat with the other battery.

## Step 2



- Unscrew all eight 12mm Phillips head screws with a Philips #1 screwdriver.  
*(i)* The iFixit 26 bit screwdriver kit will not reach the screws. Make sure to use a screwdriver that is thin enough to not get stuck in the screw holes.

## Step 3



- Flip the Luna back over so that the buttons are facing upward and the LCD screen is facing you.
- Gently tilt the lid back 45 degrees so that the inside is exposed.

***i*** Be mindful of the wires inside of the Luna. It is easy to break a connection if a wire gets caught.

To reassemble your device, follow these instructions in reverse order.