



Avaya 1120E IP Deskphone Call Center User Guide

Avaya Communication Server 1000

Document Status: **Standard**

Document Version: **06.01**

Part Code: **NN43112-107**

Date: **November 2010**



© 2010 Avaya Inc. All Rights Reserved.

Notices

While reasonable efforts have been made to ensure that the information in this document is complete and accurate at the time of printing, Avaya assumes no liability for any errors. Avaya reserves the right to make changes and corrections to the information in this document without the obligation to notify any person or organization of such changes.

Documentation disclaimer

Avaya shall not be responsible for any modifications, additions, or deletions to the original published version of this documentation unless such modifications, additions, or deletions were performed by Avaya. End User agree to indemnify and hold harmless Avaya, Avaya's agents, servants and employees against all claims, lawsuits, demands and judgments arising out of, or in connection with, subsequent modifications, additions or deletions to this documentation, to the extent made by End User.

Link disclaimer

Avaya is not responsible for the contents or reliability of any linked Web sites referenced within this site or documentation(s) provided by Avaya. Avaya is not responsible for the accuracy of any information, statement or content provided on these sites and does not necessarily endorse the products, services, or information described or offered within them. Avaya does not guarantee that these links will work all the time and has no control over the availability of the linked pages.

Warranty

Avaya provides a limited warranty on this product. Refer to your sales agreement to establish the terms of the limited warranty. In addition, Avaya's standard warranty language, as well as information regarding support for this product, while under warranty, is available to Avaya customers and other parties through the Avaya Support Web site: <http://www.avaya.com/support>

Please note that if you acquired the product from an authorized reseller, the warranty is provided to you by said reseller and not by Avaya.

Licenses

THE SOFTWARE LICENSE TERMS AVAILABLE ON THE AVAYA WEBSITE, [HTTP://SUPPORT.AVAYA.COM/LICENSEINFO](http://support.avaya.com/LICENSEINFO) ARE APPLICABLE TO ANYONE WHO DOWNLOADS, USES AND/OR INSTALLS AVAYA SOFTWARE, PURCHASED FROM AVAYA INC., ANY AVAYA AFFILIATE, OR AN AUTHORIZED AVAYA RESELLER (AS APPLICABLE) UNDER A COMMERCIAL AGREEMENT WITH AVAYA OR AN AUTHORIZED AVAYA RESELLER. UNLESS OTHERWISE AGREED TO BY AVAYA IN WRITING, AVAYA DOES NOT EXTEND THIS LICENSE IF THE SOFTWARE WAS OBTAINED FROM ANYONE OTHER THAN AVAYA, AN AVAYA AFFILIATE OR AN AVAYA AUTHORIZED RESELLER, AND AVAYA RESERVES THE RIGHT TO TAKE LEGAL ACTION AGAINST YOU AND ANYONE ELSE USING OR SELLING THE SOFTWARE WITHOUT A LICENSE. BY INSTALLING, DOWNLOADING OR USING THE SOFTWARE, OR AUTHORIZING OTHERS TO DO SO, YOU, ON BEHALF OF YOURSELF AND THE ENTITY FOR WHOM YOU ARE INSTALLING, DOWNLOADING OR USING THE SOFTWARE (HEREINAFTER REFERRED TO INTERCHANGEABLY AS "YOU" AND "END USER"), AGREE TO THESE TERMS AND CONDITIONS AND CREATE A BINDING CONTRACT BETWEEN YOU AND AVAYA INC. OR THE APPLICABLE AVAYA AFFILIATE ("AVAYA").

Copyright

Except where expressly stated otherwise, no use should be made of the Documentation(s) and Product(s) provided by Avaya. All content in this documentation(s) and the product(s) provided by Avaya including the selection, arrangement and design of the content is owned either by Avaya or its licensors and is protected by copyright and other intellectual property laws including the sui generis rights relating to the protection of databases. You may not modify, copy, reproduce, republish, upload, post, transmit or distribute in any way any content, in whole or in part, including any code and software. Unauthorized reproduction, transmission, dissemination, storage, and or use without the express written consent of Avaya can be a criminal, as well as a civil offense under the applicable law.

Third Party Components

Certain software programs or portions thereof included in the Product may contain software distributed under third party agreements ("Third Party Components"), which may contain terms that expand or limit rights to use certain portions of the Product ("Third Party Terms"). Information regarding distributed Linux OS source code (for those Products that have distributed the Linux OS source code), and identifying the copyright holders of the Third Party Components and the Third Party Terms that apply to them is available on the Avaya Support Web site: <http://support.avaya.com/Copyright>.

Trademarks

The trademarks, logos and service marks ("Marks") displayed in this site, the documentation(s) and product(s) provided by Avaya are the registered or unregistered Marks of Avaya, its affiliates, or other third parties. Users are not permitted to use such Marks without prior written consent from Avaya or such third party which may own the Mark. Nothing contained in this site, the documentation(s) and product(s) should be construed as granting, by implication, estoppel, or otherwise, any license or right in and to the Marks without the express written permission of Avaya or the applicable third party. Avaya is a registered trademark of Avaya Inc. All non-Avaya trademarks are the property of their respective owners.

Downloading documents

For the most current versions of documentation, see the Avaya Support. Web site: <http://www.avaya.com/support>

Contact Avaya Support

Avaya provides a telephone number for you to use to report problems or to ask questions about your product. The support telephone number is 1-800-242-2121 in the United States. For additional support telephone numbers, see the Avaya Web site: <http://www.avaya.com/support>

Contents

| | |
|--|-----------|
| About the Avaya 1120E IP Deskphone | 7 |
| Basic features | 7 |
| Telephone controls | 9 |
| Telephone display | 16 |
| Agent and Supervisor features | 18 |
| Logging in without Agent ID (for basic ACD) | 18 |
| Logging in with Agent ID (for Basic ACD or Contact Center Manager) | 18 |
| Logging in using Multiple Queue Assignments (for Basic ACD) | 20 |
| Logging in with an Agent ID and MQA login options | 20 |
| Using Default Login | 22 |
| Logging out | 23 |
| Agent features | 24 |
| Answering ACD calls | 24 |
| Using Call Forcing | 25 |
| Using Return to Queue on No Answer | 26 |
| Using Activity code | 26 |
| Using Emergency | 27 |
| Using Not Ready | 28 |
| Placing or answering non-ACD calls | 28 |
| Contacting your supervisor | 29 |
| Using Record On Demand key | 31 |
| Using SAVE key | 32 |

| | |
|------------------------------------|-----------|
| Supervisor features | 33 |
| Using Answer Agent | 33 |
| Using the Agent key | 34 |
| Using Answer Emergency | 34 |
| Using Call Agent | 35 |
| Using Interflow | 35 |
| Using Night Service | 36 |
| Observing a call | 37 |
| Terms you should know | 39 |
| Index | 45 |

Revision history

November 2010

Standard 06.01. This document is up-issued to support rebranding updates.

October 2010

Standard 05.01. This document is up-issued to support rebranding updates.

June 2010

Standard 04.01. This document is up-issued to support Avaya Communication Server 1000 Release 7.0.

May 2009

Standard 03.01. This document is up-issued to support Communication Server 1000 Release 6.0.

April 2008

Standard 02.01. This document is up-issued to support Communication Server 5.5 for UNISim 3.0.

May 2007

Standard 01.01. This document reflects the new document number.

January 2006


Standard 1.00. This document is issued for Communication Server 1000 Release 4.5.

About the Avaya 1120E IP Deskphone

The Avaya 1120E IP Deskphone brings voice and data to the desktop by connecting directly to a Local Area Network (LAN) through an Ethernet connection.

Note: In this guide, self-labeled line/programmable feature key labels appear beside the keys, and context-sensitive soft key labels appear directly above the keys. Figure 1 shows the key labels.

Figure 1: Self-labeled line/programmable feature keys and context-sensitive soft key labels



Note: Some features are not available on all telephones. Consult your system administrator to verify the features that are available on your telephone.

Basic features

Your Avaya 1120E IP Deskphone supports the following features:

- four self-labeled line/programmable feature keys with labels and indicators

- four context-sensitive soft keys

For information about the context-sensitive soft keys, see *Avaya New in This Release Communication Server Release 5.0* (NN43001-115).

Note: Some Avaya 1120E IP Deskphone phones are not configured to support soft key functionality. Consult your system administrator.

- graphical, high-resolution LCD display, backlit, with adjustable contrast
- high-quality speaker phone
- volume control keys for adjusting ringer, speaker, handset, and headset volume
- six specialized feature keys:
 - Quit
 - Directory
 - Message/Inbox
 - Shift/Outbox
 - Services
 - Copy
- six call-processing fixed keys:
 - Mute
 - Handsfree
 - Goodbye
 - Expand
 - Headset
 - Hold
- gigabit Ethernet ports
- built-in gigabit Ethernet switch for shared PC access
- headset jack with an On/Off key
- USB port to support a keyboard or mouse

Note: Powered downstream 1.1-compliant USB hubs are supported, including USB 2.0 hubs, if they offer USB 1.1 backwards compliancy.

- automatic network configuration
- Graphical XAS
- hearing aid compatibility
- Accessory Expansion Module port to connect the Avaya 1100 Series Expansion Module

For information about using the Expansion Module, see the *Avaya 1100 Series Expansion Module User Guide* (NN43130-101).

Figure 2 shows the Avaya 1120E IP Deskphone.

Figure 2: Avaya 1120E IP Deskphone



Telephone controls

This section describes the controls on the Avaya 1120E IP Deskphone. In some geographic regions, the Avaya 1120E IP Deskphone is offered with key caps that have English text labels. In this document, text in

parentheses indicates the labels that appear on the key caps, for example, (Services).

Table 1: Telephone controls



Context-sensitive soft keys are located below the display area. The LCD label above each key changes based on the active feature.



When a triangle appears before a soft key label, the feature is active.

Press the **More** key to access the next layer of soft keys.



The keys on either side of the LCD display area are **self-labeled line/programmable feature keys**, with labels on the LCD. These keys also function as **line (DN)** keys.



A steady LCD light beside a line (DN) key indicates that the line is active. A flashing LCD light indicates the line is on hold or the feature is being programmed.


Note: Throughout this document, the ACD line key is indicated by the line number 2260. The ACD line number that appears on your phone can be a different number.



A steady LCD light beside a feature key indicates that the feature is active. A flashing LCD light indicates that the feature is being programmed.



(Volume +)



(Volume -)

Use the **Volume control** buttons to adjust the volume of the ringer, handset, headset, speaker, and the Handsfree feature. Press the top button to increase the volume, and press the bottom button to decrease volume.



(Mute)

Your **Mute** key functionality is enabled or disabled by your system administrator. Contact your system administrator to determine if your **Mute** key is enabled.

If your **Mute** key is enabled, press the **Mute** key to listen to the receiving

party without transmitting your voice. Press the **Mute** key again to return to two-way conversation.

If your **Mute** key is not enabled, pressing the **Mute** key places the call on hold. Press the **Mute** key again to restore the active call or press the line key to restore the active call. You cannot retrieve this call from hold by pressing the Hold key.

The **Mute** key applies to handsfree, handset, and headset microphones.

Note: The Mute LED indicator, located on the **Mute** key, flashes to indicate that the microphone is muted.



(Handsfree)

Press the **Handsfree** key to activate handsfree.

Note: The Handsfree LED indicator, located on the **Handsfree** key, lights to indicate when handsfree is active.



Use the **Navigation** keys to scroll through menus and lists appearing on the LCD display screen. The outer part of this key cluster rocks for up, down, left, and right movements.

Use **Up** and **Down** to scroll up and down in lists, and the **Left** and **Right** keys to position the cursor. In some dialog boxes that appear on your phone, you can also use the **Left** and **Right** keys to select editable fields; press the **Right** key to select the field below the current selection, or the **Left** key to select the one above.




Press the **Enter** key, at the center of the Navigation key cluster, to confirm menu selections.

In most menus, you can use the **Enter** key instead of the **Select** soft key.



(Hold)

Press the **Hold** key to put an active call on hold. Tap the flashing line (DN) soft key to return to the caller on hold.



(Expand)

Use the **Expand** key to access external server applications.



(Headset)

Press the **Headset** key to answer a call using the headset or to switch a call from the handset or handsfree to the headset.

The Headset LED indicator, located on the **Handsfree** key, lights to indicate that the headset is in use.



(Goodbye)

Use the **Goodbye** key to terminate an active call.



When a message is waiting, or there is an incoming call, the red **Message Waiting/Incoming Call** Indicator LED at the top right of the IP Deskphone flashes. The flash cadence for each alert is different.

Note: You may also hear an audio Message Waiting Indicator (stutter or beeping dial tone) when you go off-hook.




When your Avaya 1120E IP Deskphone firmware is being updated, the blue **Feature Status Lamp** indicator flashes.

Note: To find out if additional features are supported, contact your system administrator.



(Copy)

Press the **Copy** key to copy entries to your Personal Directory from other lists, such as the Callers List, the Redial List, and the Corporate Directory.



(Quit)

Press the **Quit/Stop** key to exit an active menu or dialog. Pressing the **Quit/Stop** key does not affect the status of active calls.



(Shift/Outbox)

The **Shift/Outbox** key is a fixed key that is reserved for future feature development.



(Msg/Inbox)

Press the **Message/Inbox** key to access your voice mailbox.

This function is not available on all phones; consult your system administrator.



(Directory)

Press the **Directory** key to access directory services.



(Services)

Press the **Services** key to open the Services menu, and use the navigation keys to access the following items:

- Telephone Options:
 - Volume adjustment
 - Contrast adjustment
 - Language
 - Date/Time
 - Display diagnostics
 - Local Dialpad Tone
 - Set Info
 - Diagnostics
 - Call Log Options
 - Ring type
 - Call Timer
 - On hook default path
 - Change Feature Key Label
 - Name Display Format
 - Live Dialpad
 - Caller ID display order
 - Normal mode indication
- Password Admin:
 - Station Control Password

The **Password Admin** menu is not available on all Avaya 1120E IP Deskphone sets. Consult your system administrator.

- Display Network Diagnostics Utilities

Only your system administrator or service provider can use Display Network Diagnostics Utilities to perform Internet diagnostics.



(Services)

(continued)

- Virtual Office Login and Virtual Office Logout (if Virtual Office is configured)
- Test Local Mode and Resume Local Mode (if Media Gateway 1000B is configured)

Press the **Services** key to exit from any menu or menu item.



(Services)



(Services)

Press the **Services** key twice to access the Local Tools menu, and use the navigation keys to access the following items:

- 1. Preferences
- 2. Local Diagnostics
- 3. Network Configuration
- 4. Lock Menu

Your system administrator can establish a password for the Local Tools menu. If you attempt to access the Local Tools menu and a password prompt dialog box appears, contact your system administrator.

Telephone display

Your Avaya 1120E IP Deskphone has three display areas:

- The upper display area provides labels for the four self-labeled line/programmable feature key labels.
- The middle display area contains single-line information for items such as caller number, caller name, Call Timer, feature prompt string, user-entered digits, date and time information, and phone information.


Because the Avaya 1120E IP Deskphone only has a single-line information display area, you are prompted to scroll through any additional lines of information. For example, during an incoming call,

only the Directory Number (DN) appears if the caller name is greater than 10 characters. Press the flashing arrow to display the caller name.

- The lower display area provides labels for the four context-sensitive soft keys.

Figure 3 shows an idle LCD display screen.

Figure 3: Avaya 1120E IP Deskphone LCD display screen



Agent and Supervisor features

This section describes the login features that are common to the Call Center agent and supervisor. Depending on your system configuration, choose from the following methods of logging in and out:

- “Logging in without Agent ID (for basic ACD)” on page 18
- “Logging in with Agent ID (for Basic ACD or Contact Center Manager)” on page 18
- “Logging in using Multiple Queue Assignments (for Basic ACD)” on page 20
- “Logging out” on page 23

Logging in without Agent ID (for basic ACD)

If your ACD configuration does not rely on Agent ID, which is often the case if you do not share your phone with another person, use the following procedure to log in to an Automatic Call Distribution (ACD) queue.

MakeSetBsy



1. Press the **Make Set Busy** key.

Logging in with Agent ID (for Basic ACD or Contact Center Manager)

If your ACD configuration uses Agent ID, which is often the case if you share your phone with another person, use the following procedure to log in to an Automatic Call Distribution (ACD) queue. If an Agent ID is assigned to you, the display screen prompts you to enter a four-digit code.

Note: Note: The following procedure applies if you are working in a Basic ACD environment or an Avaya NES Contact Center Manager

environment. For more information about Avaya NES Contact Center Manager, visit www.avaya.com.

To log in as an agent:



1. Lift the handset.




2. Press the **In-Calls** key.



3. If “Enter Agent ID” appears on the screen, use the dialpad to enter your ID.




4. Press the **#** key. The phone goes into a Not Ready state.



5. To join the ACD queue, choose one of the following:
 - Press the **In-Calls** key.
 - Press the **NotReady** key.

6. If you use a headset and Handset On-Hook Means Log out (HOML) is configured to **No** by your administrator, then do the following:



(Services)

- a. Press the **Headset** key and replace the handset in the cradle to receive calls on your headset.
- b. Press the **Services** key. Change the **On hook default path** to **Headset Enabled**.

Note: If HOML is configured to **Yes**, replace the handset to log out of the queue.

Logging in using Multiple Queue Assignments (for Basic ACD)

If your configuration uses Multiple Queue Assignment (MQA), use the following procedure. MQA login involves entering a four-digit Agent ID and up to five ACD Directory Numbers (DN), with the option of adding a Supervisor ID and up to five Priority values.

Choose one of the following login procedures:

- “Logging in with an Agent ID and MQA login options” on page 20
- “Using Default Login” on page 22

Logging in with an Agent ID and MQA login options

To enter ACD queues, use an Agent ID login with one of the MQA login options described on page 21.

Note: A supervisor logging in to accept ACD calls is prevented by the system from entering a Supervisor ID (including logins where agents must enter a Supervisor ID).

The login options require the following entries in sequential order:

1. a four-digit Agent ID
2. a Supervisor ID (if your queue requires one)
3. up to five ACD DN and Priority values (if Priority values are being used) terminated by ##

To log in:

2260



1. Press the **In-Calls** key.

2. Choose one of the following four login options:

No Supervisor ID, No Priority



- For No Supervisor ID, No Priority, dial your Agent ID # ACD DN 1 # ACD DN 2 # ACD DN 3 # ACD DN 4 # ACD DN 5 #.

Supervisor ID, No Priority



- For Supervisor ID, No Priority, dial your Agent ID # Supervisor ID # ACD DN 1 # ACD DN 2 # ACD DN 3 # ACD DN 4 # ACD DN 5 #.

No Supervisor ID, With Priority




- For No Supervisor ID, With Priority, dial your Agent ID # ACD DN 1 # Priority 1 # ACD DN 2 # Priority 2 # ACD DN 3 # Priority 3 # ACD DN 4 # Priority 4 # ACD DN 5 # Priority 5 #.

Supervisor ID, With Priority



- For Supervisor ID, With Priority, dial your Agent ID # Supervisor ID # ACD DN 1 # Priority 1 # ACD DN 2 # Priority 2 # ACD DN 3 # Priority 3 # ACD DN 4 # Priority 4 # ACD DN 5 # Priority 5 #.

Note: To choose the default Priority value or Supervisor ID, enter #.



3. Choose one of the following:
 - Press the **In-Calls** key.
 - Press the **NotReady** key to enter the ACD queue.

Using Default Login

Use the Default Login to log in just one time at the beginning of a shift. The Default Login uses your previous shift's login to place you in the same ACD queues with the same supervisor.

To use Default Login:



1. Lift the handset.





2. Press the **In-Calls** key.



3. When "Enter Agent ID" appears on the screen, use the dial pad to enter your ID.



4. Choose one of the following:
 - If your queue requires a Supervisor ID, press the # key three times.
 - If your queue does not require a Supervisor ID, press the # key two times.



2260 
or
Not Ready 

5. To join the ACD queue, choose one of the following:
 - Press the **In-Calls** key.
 - Press the **NotReady** key.

Logging out

You can log out of the system completely or temporarily (Not Ready state).

To log out:

MakeSetBusy 
or
Not Ready 

Choose one of the following:

- To log out completely, press the **MakeSetBusy** key.
- To log out temporarily, press the **NotReady** key.

Note: If you press the **MakeSetBusy** key during an ACD call, you log out automatically when the call finishes.

Agent features

The following sections describe features that are available to agents:

- “Answering ACD calls” on page 24
- “Using Call Forcing” on page 25
- “Using Return to Queue on No Answer” on page 26
- “Using Activity code” on page 26
- “Using Emergency” on page 27
- “Using Not Ready” on page 28
- “Placing or answering non-ACD calls” on page 28
- “Contacting your supervisor” on page 29

Answering ACD calls

Use the **In-Calls** key to answer the next queued ACD call on the primary DN. The **In-Calls** key is located in the lower right area of the self-labeled line/programmable feature keys.

To answer the call:

2260



When the LCD next to the **In-Calls** key flashes, press the **In-Calls** key.

Note: The LCD remains lit as long as you are on the call.

To terminate the call:

(Goodbye)

or

2260



or

2468



or

Not Ready



Choose one of the following:

- Press the **Goodbye** key.
- Press the **In-Calls** key.
- Press the individual DN line key (this removes you from the queue).
- Press the **Not Ready** key (this removes you from the queue but keeps you logged in as an agent position) or wait for the caller to terminate the call.

Using Call Forcing

Use the **Call Forcing** feature to automatically connect an incoming ACD call. A time interval is configured by your system administrator between each incoming call.

Note: You cannot use both **Call Forcing** and **Return To Queue on No Answer** at the same time.


A short tone indicates a new incoming call. The In-Calls indicator lights continuously, and the ACD call automatically goes to your agent position. Pressing the **In-Calls** key while call forcing (Auto Answer) is active disconnects an active ACD call.

**CAUTION**

If you are away from your phone and Call Forcing is enabled, remember to log out or activate Not Ready. Otherwise, callers continue to be connected to your phone. Because you are not at your desk, callers hear only the background noise in your work space, until they hang up.

To enable Call Forcing for headset users:

1. Log in.



2. Replace the handset.



(Services)

3. Press the **Services** key. Configure the **On-hook default path** to **Headset Enabled**.

Using Return to Queue on No Answer

If a call is not answered, the call is sent back to the ACD queue, and the your telephone is automatically placed in Not Ready state. To return to the ACD queue, log in, or press the **NotReady** key.

Using Activity code

Use Activity code to record the types of activities you are performing.

To record activities:

Activity



1. When the Activity LCD indicator is flashing, press the **Activity** key.



2. Use the dial pad to enter the Activity code.

Activity 

3. Press the **Activity** key.


If you are performing multiple tasks, repeat steps 1 and 2.

Note: If configured, you can enter Activity Codes while in the Not Ready state and run Not Ready Reason Codes by Agent report in Contact Center Manager Administration to track Not Ready time.

Using Emergency

Use the **Emergency** feature to contact your supervisor immediately in an emergency situation.


To use the Emergency feature:

Emergency 

1. During an active call, press the **Emergency** key.

Note: The Emergency LCD remains lit as long as the feature is active.

When the supervisor answers, a three-way call commences with you, your supervisor, and the caller.

Emergency 

2. Press the **Emergency** key again to transfer the caller to the supervisor and terminate your access to the caller and supervisor.

Using Not Ready

Use the Not Ready feature to take your telephone out of the call queue while completing post-call work.

Note: If you don't activate **Make Set Busy** or **Not Ready**, callers will continue to be directed to your phone.

To use Not Ready:

NotReady 

1. Press the **NotReady** key to temporarily log out of the system.

Note: The NotReady LCD remains lit as long as the feature is active.

2260 

or

NotReady 

2. To return to the queue, choose one of the following:
 - Press the **In-Calls** key.
 - Press the **NotReady** key.

Placing or answering non-ACD calls

Use this feature to place and receive calls on your individual line.

To place a call:

2498 



1. Press your individual DN key.
2. Use the dial pad to dial the telephone number.

Note: The LCD remains lit as long as you are on the call.

To answer a call:

2498



When the LCD next to your individual DN key flashes, press the DN key.

Note: The LCD remains lit as long as you are on the call.

Contacting your supervisor

Use the **Supervisor** feature to talk to your supervisor in the following ways:

- “To answer a call from your supervisor:” on page 29
- “To answer a call from your supervisor when on another call:” on page 29
- “To place a call to your supervisor:” on page 30
- “To conference in your supervisor during a call in progress:” on page 30
- “To transfer a call to your supervisor during a call in progress:” on page 31

To answer a call from your supervisor:

Supervisor



When the LCD next to the **Supervisor** key flashes, press the **Supervisor** key.

Note: The LCD remains lit as long as you are on the call.

To answer a call from your supervisor when on another call:

Supervisor



The LCD next to the **Supervisor** key flashes and a buzzer sounds.



(Hold)

1. Press the **Hold** key to put the current call on hold.

Supervisor



2. Press the **Supervisor** key.

Press the line (DN) key beside the flashing LED indicator to return to the caller on hold.

To place a call to your supervisor:

Supervisor



Press the **Supervisor** key.

Note: Calls are automatically put on hold when you use the **Supervisor** key.

To return to the ACD call:

2260



Press the **In-Calls** key.

To conference in your supervisor during a call in progress:

Supervisor



1. Press the **Supervisor** key to talk privately with your supervisor.

Supervisor



2. Press the **Supervisor** key again for a conference call with you, your supervisor, and the other caller.

To transfer a call to your supervisor during a call in progress:

Supervisor



1. Press the **Supervisor** key.

Supervisor



2. When your supervisor answers, press the **Supervisor** key again.



(Goodbye)

3. Press the **Goodbye** key to terminate your access to the call.

Using Record On Demand key

If this feature is enabled, you can use the Record on Demand (ROD) feature key to record your telephone conversation.

Press the ROD key to start or stop the call recording. This key is associated with the active user ID and is displayed only if a call is active. The ROD key blinks while it is connecting to the call recording application, and is lit when the call is recording.

The ROD key is displayed in the following scenarios:

- Normal operation - Press the ROD key during an active call to record the call.
- Call Recording (CR) application in ROD Mode - Press the ROD key during an active call to record the call
- Bulk Recording - For an active call or unregistered DN/Position ID, call recording is initiated even though the ROD key is not pressed.

1. Press the **ROD** key during an active call.

-
2. To stop the call recording, press the **ROD** key again.

Using **SAVE** key

Use the **SAVE** feature key to save the recording of an active call. This key is associated with the active user ID and is operational only if a call is active.

The **SAVE** key is displayed in the following scenarios:

- Normal operations - If the **SAVE** key is pressed during an active call, the call is saved.
- CR application in Bulk Record + Save everything mode - Recorded conversation is saved at the end of the call. If the **SAVE** key is pressed, then the call is not saved.
- CR application in Bulk Record + Delete everything mode - Recorded conversation is deleted at the end of the call. If the **SAVE** key is pressed, then the call is saved.

The **SAVE** key lamp status depends on the status of the call recording. If the call is to be saved, then the lamp is lit.

1. Press the **ROD** key during an active call.
2. To stop the call recording, press the **ROD** key again.
3. Press the **SAVE** key to save the conversation.

Supervisor features

The following sections describe features available to the supervisor:

- “Using Answer Agent” on page 33
- “Using the Agent key” on page 34
- “Using Answer Emergency” on page 34
- “Using Call Agent” on page 35
- “Using Interflow” on page 35
- “Using Night Service” on page 36
- “Observing a call” on page 37

Using Answer Agent

Use the Answer Agent feature to receive calls from agents in a non-emergency situation.

To use Answer Agent:

AnsAgent.



1. When the LCD next to the Answer Agent key flashes, press the **Answer Agent** key.

Note 1: The Agent ID of the person contacting you displays on your telephone.

Note 2: The LCD remains lit as long as you are on the call, and your status is displayed as NotReady.



(Goodbye)

2. Press the **Goodbye** key to end the call.

Using the Agent key

Use the Agent feature to connect, observe, or monitor the status of each agent position. Each **Agent** key links to a particular agent position and can be used along with the **Call Agent** or **Observe Agent** keys.

Table 2 lists the four states of the LCD indicator.

Table 2: Agent's status

| LCD display | Description |
|---------------|---|
| Off | Agent is not logged in. |
| On | Agent is logged in but is either NotReady or on a call. |
| Slow Flashing | Agent is waiting for an ACD call. |
| Fast Flashing | Agent is on a non-ACD call. |

Using Answer Emergency

Use the Answer Emergency feature to receive calls from agents in an emergency situation.

To use Answer Emergency:

AnsEmerg



1. When the LCD next to the **Answer Emergency** key flashes, press the **Answer Emergency** key.

Note 1: The Agent ID of the person contacting you displays on your telephone.

Note 2: The LCD remains lit as long as you are on the call and your status is displayed as Not Ready.



(Goodbye)

2. Press the **Goodbye** key to end the call.

Using Call Agent

Use the Call Agent feature to contact an agent.

To use Call Agent:

CallAgent



1. Press the **Call Agent** key.

AgentKey



or



2. Choose one of the following:
 - Press a selected **Agent** key.
 - Dial the agent's Position ID.



(Goodbye)

3. Press the **Goodbye** key to end the call.

Using Interflow

Use the Interflow feature to redirect calls when the backlog or wait time exceeds a pre-defined threshold.


To use Interflow:

Interflow



1. Press the **Interflow** key.

Note: The Interflow LCD flashes while the feature is active.


Interflow 

2. Press the **Interflow** key again to deactivate the feature and resume normal call flow.

Using Night Service

Use the Night Service feature to define how calls are handled outside of business hours.

To activate Night Service:

NightSvc 


1. Press the **Night Service** key.



2. Press the **6** key (6 = N for Night) to go into Night Service.

The Night Service LCD lights continuously. All calls in the queue and new calls receive Night Service.

To transition to Night Service:


NightSvc 

1. Press the **Night Service** key.



2. Press the **8** key (8 = T for Transition) to activate Transition mode.

The Night Service LCD flashes. All calls in the queue remain in the queue and new calls receive Night Service.

To deactivate Night Service:NightSvc 

1. Press the **Night Service** key.



2. Press the **3** key (3 = D for Day) to resume Day mode.

The Night Service LCD flashes. New calls enter the queue.

Observing a call

Use the Observe feature to monitor an agent in a call.

To observe a call:Observe 


1. Press the **Observe** key.

AgenKey 


or



2. Choose one of the following:
 - Press a selected **Agent** key.
 - Dial the agent's Position ID.

CallAgt 

3. Press the **Call Agent** key to talk to the agent you are monitoring.

Observe 

4. Press the **Observe** key to terminate the observation.

Terms you should know

Avaya Communication Server 1000

Your office communication system.

Calling Party Name Display

Information appearing on the LCD display screen, such as the caller's name and telephone number. The system must have CPND enabled.

Category 5 (Cat5)

Cable and associated connecting hardware capable of transmitting at speeds up to 100 MHz, used by 10BaseT, 100BaseT4, 100BaseTX.

Category 5e (Cat5e)

Most Cat5 cable manufactured after 1996 also supports 1000BaseT (GigE) installations, and is designated Cat 5e. Cat5e cable normally has four pairs of copper wire.

Category 6 (Cat6)

Cable and associated connecting hardware capable of transmitting at speeds up to 200 MHz. Designed specifically to support 1000BaseT (Gig Ethernet (GigE)), it is also compatible with 10BaseT, 100BaseT4, and 100BaseTX installations. The cable normally has four pairs of copper wire.

Context-sensitive soft keys

A set of keys programmed by your system administrator. These four keys, located directly below the display area, have four programmable layers. These keys are also used to configure parameters in the **Telephone Options** menu.

Date/time display

The current date and time when the telephone is in an idle state.

Directory Number (DN)

A number consisting of one to seven digits for a telephone, and also known as an *extension number*.

Feature display

An area that shows status information about the feature in use. It also displays the name and status of the active session.

Feature Status Lamp indicator

An LCD or an LED that indicates a data message, contact, or feature status by a flash, wink, steady on, or off.

Fixed key

The hard-labeled keys on your telephone.

Flexible Feature Codes (FFC)

Specialized codes entered using the dialpad that enable features (for example, Ring Again).

Goodbye key

A fixed key used to end an active call.

Indicator

An LCD or an LED that indicates the status of a feature by the flash, wink, steady on, or off.

Information display

Any display of call activity, lists, prompts, and status of calls. On your Avaya 1120E IP Deskphone, this information area is one line of text and symbols. If a text message exceeds this area, a scroll arrow icon indicates that you must use the scroll keys to view the remaining text.

Information line

A one-line by 24-character area that displays date and time or application information.

Interrupted dial tone

A broken or pulsed dial tone that sounds when you access some features on your telephone.

Message/Inbox

A fixed key on your Avaya 1120E IP Deskphone that connects to your voice messaging system when the key is pressed.

Navigation keys

Keys used to scroll through menus and lists appearing on the LCD display screen.

Off-hook

Any line selected to make a call or receive an incoming call. The term *off-hook* is applied when (a) the end-user lifts up the handset, (b) the end-user presses a line key, (c) the call is automatically answered at the telephone, or (d) a line is automatically selected for an outgoing call.

Paging tone

A special tone (two beeps followed by dial tone) that sounds when you use the Radio Paging feature.

Return to Queue on No Answer

If a call is not answered by the agent, the call is sent back to the ACD queue and the agent's telephone is automatically placed in the Not Ready state.

Ringback/ring tone

A sound indicating that a call you have made is ringing at its destination.

Services key

A fixed key used to access options such as Telephone Options, Password Admin, Virtual Office Login, Virtual Office Logout, Test Local Mode, and Resume Normal Mode.

Shared Directory Number

A DN (extension) that is shared by two or more persons.

Special Prefix code (SPRE)

Special codes entered using the dialpad, followed by a two-digit access code, that enable features (for example, Call Forward All Calls requires entry of SPRE code + 74).

Special dial tone

The three consecutive tones followed by dial tone that you hear when accessing telephone features.

Station Control Password (SCPW)

Enables security features on your phone to prevent others from making calls from your telephone and to prevent access to protected features (for example, Remote Call Forward).

Status Messages

A message displayed to inform the user of important information. A right arrow appears if more than one Status Message is present. Examples of Status Messages include: Message Waiting, All Lines Forwarded to: 6453, Do Not Disturb On, Ring Again active, and Ringer is OFF.

System or Switch

Your office communication system.

Switchhook

A button on which the handset presses down, disconnecting your call when you replace the handset. The handset (when lifted)

releases the switchhook, and you either answer an incoming call or you receive a dial tone to make a call.

User interface

Screen displays that interact with the end user as a result of an action or event.

Visual Alerter/Message Waiting indicator

An LCD or an LED that flashes to indicate that a message is waiting or when the ringer is on.

Index

A

About the Avaya 1120E IP Desk-phone 7
Activity code 26
Agent and MQA login options 20
Agent and Supervisor features 18
Agent features 24
Agent key 34
Agent login 18
Answer ACD calls 24
Answer Agent 33
Answer Emergency 34

B

Basic features 7

C

Call Agent 35
Call party information 39
Contact your supervisor 29
Context-sensitive soft keys 10, 39
Copy key 13

D

Date/time display 39
Default login 22
Directory key 14
Directory Number 40
display areas 16
Display Network Diagnostics Utilities 15

DN 40

E

Emergency 27
Enter key 12
Expand key 12

F

Feature display 40
Fixed key 40
Flexible Feature Code (FFC) 40
Force Call 25

G

Goodbye key 13, 40

H

Handsfree / Speaker key 11
Headset key 12
Hold key 12

I

Indicator status 40
Information display 40
Information line 41
Interflow 35
Interrupted dial tone 41

L

Line (DN) key 10
Login with Agent ID and MQA 20

M

- Message key 41
- Message waiting indicator 43
- Message/Inbox key 14
- More key 10

N

- Navigation keys 12, 41
- Night Service 36
- Not Ready 28

O

- Observe 37
- Off-hook 41

P

- Paging tone 41
- Place or answer non-ACD calls 28

Q

- Quit/Stop key 13

R

- Return to Queue on No Answer 41
- Ringback/ring tone 41

S

- Self-labeled line/programmable feature keys 10
- Services key 15, 42
- Shared Directory Numbers 42
- Shift/Outbox key 13
- Special dial tone 42
- Special Prefix code (SPRE) 42

- Station Control Password (SCPW) 42

- Status Messages 42
- Supervisor features 33
- Switchhook 42
- System or Switch 42

T

- Telephone controls 9
- Telephone display 16

U

- User Interface 43

V

- Volume control 11
- Volume control bar 11