



Preface

Objective

The Japan 2 country feature package supports the tone plan as stated in Chapter 2, “Japan 2 Tone Plan”. Except where otherwise noted, this supplement describes the installation, configuration, operation and general functionality of the Japan 2 country feature package as used with the following Virtual Central Office (VCO) and Specialty Digital Switch (SDS) platforms.

- VCO/4K running system software V5.x FSR00 PUN00 or higher
- VCO/20 running system software V4.0 FSR00 PUN00* or higher
- VCO/80 running system software V3.3 FSR00 PUN00** or higher
- SDS-1000 running system software V3.3 FSR00 PUN00** or higher
- SDS-500 running system software V3.3 FSR00 PUN00** or higher

* The PUN number was included as part of the V4.x system software numbering scheme at V4.0 FSR02 PUN00.

** The PUN number was included as part of the V3.x system software numbering scheme at V3.3 FSR05 PUN00.



Note

Within any given country, there may be more than one tone plan in use by the various telecommunication service providers who operate privately and/or publicly within the country in question. Thoroughly review the tone plan listed in Chapter 2, “Japan 2 Tone Plan” to verify that this is the country feature package that you ordered.

Audience

This document is intended for all personnel using the Japan 2 country feature package.

Document Organization

This document is organized as follows:

Chapter 1, “System Requirements” lists the system requirements for running the Japan 2 country feature package.

Chapter 2, “Japan 2 Tone Plan” details the modifications to the Digital Tone Generator (DTG or DTG-2) and Call Progress Analyzer (CPA) cards, and the SPC-CPA service cards.

Documentation Conventions

This document uses the following conventions:



Caution

Means *reader be careful*. In this situation, you might do something that could result in equipment damage or loss of data.



Note

Means *reader take note*. Notes contain helpful suggestions or references to material not covered in the manual.

Related Documentation

The *Cisco VCO/4K Japan 2 Supplement* provides important information about running the Japan 2 country feature package on the VCO and SDS platforms. If a topic is discussed in both the SDS/VCO documentation set and this supplement, refer to the information in this document.

This supplement assumes that readers have a working knowledge of R2 signaling.

Network signaling requirements appear in the following specifications.

- International Telecommunications Union (ITU, formerly Comité Consultatif International Téléphonique et Télégraphique, CCITT) Q.421 Digital Line Signaling Code
- ITU-T Q.440 Interregister Signaling

Obtaining Documentation

The following sections provide sources for obtaining documentation from Cisco Systems.

World Wide Web

You can access the most current Cisco documentation on the World Wide Web at the following sites:

- <http://www.cisco.com>
- <http://www-china.cisco.com>
- <http://www-europe.cisco.com>

Documentation CD-ROM

Cisco documentation and additional literature are available in a CD-ROM package, which ships with your product. The Documentation CD-ROM is updated monthly and may be more current than printed documentation. The CD-ROM package is available as a single unit or as an annual subscription.

Ordering Documentation

Cisco documentation is available in the following ways:

- Registered Cisco Direct Customers can order Cisco Product documentation from the Networking Products Marketplace:
http://www.cisco.com/cgi-bin/order/order_root.pl
- Registered Cisco.com users can order the Documentation CD-ROM through the online Subscription Store:
<http://www.cisco.com/go/subscription>
- Nonregistered Cisco.com users can order documentation through a local account representative by calling Cisco corporate headquarters (California, USA) at 408 526-7208 or, in North America, by calling 800 553-NETS(6387).

Documentation Feedback

If you are reading Cisco product documentation on the World Wide Web, you can submit technical comments electronically. Click **Feedback** in the toolbar and select **Documentation**. After you complete the form, click **Submit** to send it to Cisco.

You can e-mail your comments to bug-doc@cisco.com.

To submit your comments by mail, for your convenience many documents contain a response card behind the front cover. Otherwise, you can mail your comments to the following address:

Cisco Systems, Inc.
Document Resource Connection
170 West Tasman Drive
San Jose, CA 95134-9883

We appreciate your comments.

Obtaining Technical Assistance

Cisco provides Cisco.com as a starting point for all technical assistance. Customers and partners can obtain documentation, troubleshooting tips, and sample configurations from online tools. For Cisco.com registered users, additional troubleshooting tools are available from the TAC website.

Cisco.com

Cisco.com is the foundation of a suite of interactive, networked services that provides immediate, open access to Cisco information and resources at anytime, from anywhere in the world. This highly integrated Internet application is a powerful, easy-to-use tool for doing business with Cisco.

Cisco.com provides a broad range of features and services to help customers and partners streamline business processes and improve productivity. Through Cisco.com, you can find information about Cisco and our networking solutions, services, and programs. In addition, you can resolve technical issues with online technical support, download and test software packages, and order Cisco learning materials and merchandise. Valuable online skill assessment, training, and certification programs are also available.

Customers and partners can self-register on Cisco.com to obtain additional personalized information and services. Registered users can order products, check on the status of an order, access technical support, and view benefits specific to their relationships with Cisco.

To access Cisco.com, go to the following website:

<http://www.cisco.com>

Technical Assistance Center

The Cisco TAC website is available to all customers who need technical assistance with a Cisco product or technology that is under warranty or covered by a maintenance contract.

Contacting TAC by Using the Cisco TAC Website

If you have a priority level 3 (P3) or priority level 4 (P4) problem, contact TAC by going to the TAC website:

<http://www.cisco.com/tac>

P3 and P4 level problems are defined as follows:

- P3—Your network performance is degraded. Network functionality is noticeably impaired, but most business operations continue.
- P4—You need information or assistance on Cisco product capabilities, product installation, or basic product configuration.

In each of the above cases, use the Cisco TAC website to quickly find answers to your questions.

To register for Cisco.com, go to the following website:

<http://www.cisco.com/register/>

If you cannot resolve your technical issue by using the TAC online resources, Cisco.com registered users can open a case online by using the TAC Case Open tool at the following website:

<http://www.cisco.com/tac/caseopen>

Contacting TAC by Telephone

If you have a priority level 1 (P1) or priority level 2 (P2) problem, contact TAC by telephone and immediately open a case. To obtain a directory of toll-free numbers for your country, go to the following website:

<http://www.cisco.com/warp/public/687/Directory/DirTAC.shtml>

P1 and P2 level problems are defined as follows:

- P1—Your production network is down, causing a critical impact to business operations if service is not restored quickly. No workaround is available.
- P2—Your production network is severely degraded, affecting significant aspects of your business operations. No workaround is available.

System Requirements

Installation and Configuration

This chapter lists system requirements for running the Japan 2 country feature package on SDS and VCO platforms operating with system software V3.3 through V5.x. These requirements are categorized by hardware, firmware, and software. For any site-specific concerns, contact Cisco as described in the preface.

The Japan 2 country feature package consists of the following components:

- Digital Tone Generator (DTG) card or DTG-2 card
- Call Progress Analyzer (CPA) or Service Platform (SPC) cards, software-configured for CPA (displayed as SPC-CPA)
- SPC card software-configured for DTMF (displayed as SPC-DTMF)
- Diskette for the CPA and SPC cards containing the download files

**Note**

Service circuit cards must occupy only one resource group in the Resource Group Summary screen; further, different card types cannot share the same resource group. Use either the SPC or the CPA card (but not both) if your system requires CPA service circuit functionality.

Hardware Requirements

Refer to the *Cisco VCO/4K Tone Plan Release Notes* for the A-law and Mu-law rules and timing rules governing the hardware configurations of cards with jumpers/DIPs, and the software configuration of cards without jumpers/DIPs.

Refer to the *Cisco VCO/4K Card Technical Descriptions* for each service circuit card and for each network card for jumper and DIP switch settings.

Firmware Requirements

Refer to the *Cisco VCO/4K Tone Plan Release Notes* for information regarding system firmware requirements particular to the Japan 2 country feature package.

Refer to your system release notes for step-by-step instructions to install firmware on either the DTG-2 mezzanine card or the DTG card.

Software Requirements

Refer to the *Cisco VCO/4K Tone Plan Release Notes* for information regarding system software requirements particular to the Japan 2 country feature package.

System software V5.1 FSR00 PUN21, or higher, is required to operate the Japan 2 SPC software on the SPC.

Call Progress Analyzer and Service Platform Card Download Files

Your country feature package includes a single 3.5-inch diskette containing two directories. These directories contain Call Progress Analyzer (CPA) and Service Platform Card (SPC) download files. The two directories are named PRE-P24 and POST-P24. The following files are included in each directory:

cpa.dwn
cpa.nor
cpa.spc
cpa.sit
cpa.ctg
dtmf.spc

Copy the PRE-P24 directory contents to your system's C:/BOOT directory if you are using system software that is at least V5.0, but not greater than V5.1 FSR00 PUN23. Copy the POST-P24 directory contents to your system's C:/BOOT directory if you are using system software V5.1 FSR00 PUN24 or higher.

In addition, if you are using system software V4.2 FSR00 PUN28 and lower, copy only the cpa.dwn file to the C:/BOOT directory.

Refer to the *Cisco VCO/4K System Administrator's Guide* for step-by-step instructions for copying the files to your system's C:/BOOT directory.



Note

Always wear a wrist strap when installing software and handling system components.

The files are now loaded onto your hard disk. Complete the installation by loading the files from the hard disk to the cards. The method of loading depends on whether or not it is for a new installation, or for an existing installation. For new installations, refer to the "Loading the Software onto Cards—New Installations" section on page 1-2; for existing installations, refer to "Loading the Software onto Cards—Existing Installations" section on page 1-3.

Refer to the *Cisco VCO/4K System Administrator's Guide* for step-by-step instructions as you complete this installation procedure.

Loading the Software onto Cards—New Installations

To load the files from the hard disk to cards in a new installation, follow these steps:

-
- | | |
|---------------|--|
| Step 1 | Access the Card Maintenance screen from the Maintenance Menu screen, and add the CPA (the console displays this choice as Call Progress Analyzer) or the SPC (the console displays this choice as either SPC-CPA or SPC-DTMF) to the database by using the A command, if you have not already done so. |
| Step 2 | Insert your card, either the CPA or the SPC, into the appropriate slot. The card automatically runs internal diagnostics. One of two results follow, dependent upon which card you have inserted. |

**Caution**

Do not unseat or otherwise disturb the card while running internal diagnostics.

- For the CPA, the LEDs display the transition from off (all LEDs unlighted) to on (the red and yellow unlighted and the green lighted).
- For the SPC, the LED matrix display transitions from off (all LEDs unlighted) to on (the LED matrix lights the letters S, P, and C one at a time repeatedly; the lower right LED changes from unlighted to lighted repeatedly).

Step 3 Activate the card using the C command from the Card Maintenance screen. The card takes the download. The service circuit spans are active, as can be seen from the Card Maintenance screen.

**Caution**

Do not unseat or otherwise disturb the card while it is downloading.

Step 4 Verify the received FRM225, FRM226, FRM241, and FRM242 messages in your log file to ensure that the card has taken the download.

For the SPC, verify two additional messages in the log file—"Begin downloading spec file C:/boot/xxx.xxx" and "End downloading spec file C:/boot/xxx.xxx". The CPA does not have these, or any other, additional log file messages.

Step 5 Create a resource group for the CPA or the SPC service circuits.

You have completed the software installation.

Loading the Software onto Cards—Existing Installations

To load the files from the hard disk to cards in an existing installation, follow these steps.

**Caution**

This process disrupts in-progress calls and removes service circuits from operation for a few minutes.

Step 1 Access the Card Maintenance screen from the Maintenance Menu screen, and take either the CPA card or the SPC service circuits out of service (OOS), if you have not already done so.

Also, if you have a CPA, unseat it, wait 15 seconds, then insert the card into its slot. The SPC does not require, or allow, this action.

Step 2 Activate the CPA or the various SPC service circuits using the C command from the Card Maintenance screen.

**Caution**

Do not unseat or otherwise disturb the card while it is downloading.

Step 3 Verify received download messages in your log file to ensure that the card has taken the download. The messages you need to verify are dependent upon which card type you are using.

- For the CPA, verify the received FRM225, FRM226, FRM241, and FRM242 messages.
- For the SPC, verify two messages—"Begin downloading spec file C:/boot/xxx.xxx" and "End downloading spec file C:/boot/xxx.xxx".

**Note**

The SPC does not take a redownloading of the spc.dwn file.

You have completed the software installation.

Typical System Software Configurations

This section lists typical system software configurations used with the Japan 2 country feature package. For more information on how to use and configure the various system software screens and menus, refer to the *Cisco VCO/4K System Administrator's Guide*.

Database Administration

Special considerations pertain to the following Database Administration menus and screens.

Card Summary Menu

The Card Summary menu displays the status and port availability of E1, 4xE1, and ICC cards. To assign operating characteristics to E1 spans, access the Configuration screen for that card from the Card Summary menu.

**Note**

The term “E1 span” designates E1 and 4xE1 cards, or ICC cards with associated ICC-E1-I/O module.

Resource Group Summary Menu

To optimize outgoing call system performance, group E1 span outgoing ports and 4xE1 outgoing span ports into one or more resource groups.

Inpulse and Outpulse Rule Screen

For information about inpulse and outpulse rule tokens, refer to the *Cisco VCO/4K System Administrator's Guide*.

Answer Supervision Template Screen

Refer to Chapter 2, “Japan 2 Tone Plan” for information on the answer supervision template function.

Maintenance

Special considerations pertain to the Card Maintenance screen.

Use the Card Maintenance screen to add, delete, and change the card/port status for E1 spans. When an E1 span is added to the Card Maintenance screen, its span type is set to CAS/R2 by default.

For E1 spans set to CAS/R2, ports 1 and 17 of the card's 32 ports are reserved. Port 1 (Channel 0) carries the frame alignment pattern, remote alarm indication bit, and national-use bits. Port 17 (Channel 16) carries the multiframe alignment pattern, extra bits, and channel-associated signaling bits.

For 4xE1 and ICC cards, set the span type to CCS/31B from the Card Summary menu to use port 17 as a bearer port. Use E1-31B firmware on E1 cards to use port 17 as a bearer port.

Diagnostics

Special considerations pertain to the following Diagnostics screens.

Card Display Screen

The Card Display screen lists the operating status of E1 spans. Information on the Card Display screen varies according to card type and span type.

Port Display Screen

The Port Display screen lists the processing states, rule processing, links, paths, and digit collection activity of E1 spans.

Test Port Card Screen

The Test Port Card screen tests individual E1 channels. A path is set up between three elements—the selected E1 channel(s), the Service Platform Card-Dual Tone Multifrequency (SPC-DTMF) card or DTMF Receiver Card (DRC), and a Digital Tone Generator (DTG) channel. The system compares the signals sent by the DTG card with the signals received by the SPC-DTMF card or the DRC and reports discrepancies. You can test all channels on an E1 span with one command. You can select the E1 span for port card diagnostic tests. The E1 span enters a local loopback mode during the test and sends out an all 1s (ones) pattern.

Test Service Circuit Screen

The Test Service Circuit screen tests DRC and SPC-DTMF service circuits.

Host Commands and Reports

The host commands and reports are documented in the *Cisco VCO/4K Standard Programming Reference* and the *Cisco VCO/4K Extended Programming Reference*.

Japan 2 Tone Plan

This chapter details the modifications to the Digital Tone Generator (DTG or DTG-2) and Call Progress Analyzer (CPA) cards, and SPC-CPA service circuits to support the supervision tones specific to the Japan telephone network.

The information in this chapter supersedes the information in the following manuals:

- *Cisco VCO/4K System Administrator's Guide*
- *Cisco VCO/4K Standard Programming Reference*
- *Cisco VCO/4K Extended Programming Reference*
- *Cisco VCO/4K Supervision and Call Progress Tone Detection*

Tone Characteristics

Table 2-1 summarizes the characteristics of the most frequently used supervision tones in the Japan network.

Table 2-1 Japan 2 Digital Tone Generator Supervision Tones

| Tone | Frequencies (Hz) | Amplitude (dBm) | Cadence | Detected by CPA? |
|-------------|------------------|-----------------|---|------------------|
| Dial | 400 | −15 | Continuous | Yes |
| Ring Back | 400 | Variable | 1 second on, 2 seconds off, REPEATED | Yes |
| Busy | 400 | −5 | 0.5 seconds on, 0.5 seconds off REPEATED | Yes |
| Fast Busy | 400 | −5 | 0.25 seconds on, 0.25 seconds off, REPEATED | Yes |
| ISUP Tone 1 | 2010 | −12 | Continuous | Yes |
| ISUP Tone 2 | 1800 | −22 | Continuous | Yes |

Tone Detection

CPA processing is modified to support the Japan network requirements. Use the system administration answer supervision templates function to control tone detection for the tones listed in Table 2-1. Supervision template processing is described in the *Cisco VCO/4K System Administrator's Guide*.

Answer Supervision Template Screen Terminology

The supervision events and tones listed in the Answer Supervision Template screen use standard North American network terminology. Table 2-2 shows the Answer Supervision Template screen terms to use with the Japan 2 country feature package.

Table 2-2 Answer Supervision Template Screen Terminology for Japan 2

| Answer Supervision Template Event and Tone Name | Japan 2 Tone Name |
|---|-------------------------|
| Dial Tone | Dial Tone |
| Ringback | Ringback |
| Busy | Busy |
| Reorder | Fast Busy |
| SIT Tones | Not Applicable |
| Ring Cess. ¹ | Not Applicable |
| Voice Det. ¹ | Not Applicable |
| Voice Cess. ¹ | Not Applicable |
| Wink ¹ | Not Applicable |
| Answer ¹ | Not Applicable |
| Time ¹ | Not Applicable |
| Hook Flash ¹ | Not Applicable |
| Pager Cue | Not Available |
| ISUP Tone | ISUP Tone 1/ISUP Tone 2 |
| ISUP Cess. | ISUP Tone 1/ISUP Tone 2 |

1. Not a tone.

Tone Generation

Tone generation is performed through DTG output pulse and static tone channels. The allocation of these tones is controlled via impulse rules, Voice Path Control (\$66), and DTMF Collection Control (\$67) commands.

Table 2-3 supersedes the tone generator table listed in the *Cisco VCO/4K Standard Programming Reference* and the *Cisco VCO/4K Extended Programming Reference*. It also supersedes the tone output level specifications found in the *Cisco VCO/4K Card Technical Descriptions*. For more information on generating tones, refer to the *Cisco VCO/4K System Administrator's Guide*.

The tones and their corresponding output levels, decimal values, hexadecimal values, and port addresses are summarized in Table 2-3.

Table 2-3 *Tone Levels, Values, and Port Addresses*

| Tone | Output Level | Decimal Value | Hex Value | Port Addresses |
|-----------------------------------|-----------------|---------------|-----------|----------------|
| Beep | — | 0 | 00 | None |
| Quiet (PCM idle pattern 01010100) | — | 1 | 01 | 04C0 |
| 1 kHz | 0 dBm | 2 | 02 | 04C1 |
| Dial | -15 dBm | 3 | 03 | 04C2 |
| 380 Hz | -10 dBm | 4 | 04 | 04C3 |
| Beep (440 Hz) | -13 dBm | 5 | 05 | 04C4 |
| 480 Hz | -17 dBm | 6 | 06 | 04C5 |
| 1400 Hz | -24 dBm | 7 | 07 | 04C6 |
| 1000 Hz @max CODEC output | — | 8 | 08 | 04C7 |
| 920 Hz Dial | -13 dBm | 9 | 09 | 04C8 |
| 404 Hz | 0 dBm | 10 | 0A | 04C9 |
| 1004 Hz | 0 dBm | 11 | 0B | 04CA |
| 2804 Hz | 0 dBm | 12 | 0C | 04CB |
| Reserved | — | 13 | 0D | 04CC |
| Reserved | — | 14 | 0E | 04CD |
| Reserved | — | 15 | 0F | 04CE |
| Reserved | — | 16 | 10 | 04CF |
| Ringback | Variable | 17 | 11 | 04D0 |
| Busy | -5 dBm | 18 | 12 | 04D1 |
| Fast Busy | -5 dBm | 19 | 13 | 04D2 |
| Reserved | — | 20 | 14 | 04D3 |
| Reserved | — | 21 | 15 | 04D4 |
| Reserved | — | 22 | 16 | 04D5 |
| Reserved | — | 23 | 17 | 04D6 |
| Reserved | — | 24 | 18 | 04D7 |
| ISUP 2 | -22 dBm | 25 | 19 | 04D8 |
| ISUP 1 | -12 dBm | 26 | 1A | 04D9 |
| Reserved | — | 27 to 32 | 20 | 04DF |
| DTMF digit 0 (steady) | -7 dBm/freq | 33 | 21 | 04E0 |
| DTMF digit 1 (steady) | -7 dBm/freq | 34 | 22 | 04E1 |
| DTMF digit 2 (steady) | -7 dBm/freq | 35 | 23 | 04E2 |
| DTMF digit 3 (steady) | -7 dBm/freq | 36 | 24 | 04E3 |
| DTMF digit 4 (steady) | -7 dBm/freq | 37 | 25 | 04E4 |

Table 2-3 Tone Levels, Values, and Port Addresses (continued)

| Tone | Output Level | Decimal Value | Hex Value | Port Addresses |
|-----------------------|--------------|---------------|-----------|----------------|
| DTMF digit 5 (steady) | -7 dBm/freq | 38 | 26 | 04E5 |
| DTMF digit 6 (steady) | -7 dBm/freq | 39 | 27 | 04E6 |
| DTMF digit 7 (steady) | -7 dBm/freq | 40 | 28 | 04E7 |
| DTMF digit 8 (steady) | -7 dBm/freq | 41 | 29 | 04E8 |
| DTMF digit 9 (steady) | -7 dBm/freq | 42 | 2A | 04E9 |
| DTMF digit A (steady) | -7 dBm/freq | 43 | 2B | 04EA |
| DTMF digit B (steady) | -7 dBm/freq | 44 | 2C | 04EB |
| DTMF digit C (steady) | -7 dBm/freq | 45 | 2D | 04EC |
| DTMF digit D (steady) | -7 dBm/freq | 46 | 2E | 04ED |
| DTMF digit * (steady) | -7 dBm/freq | 47 | 2f | 04EE |
| DTMF digit # (steady) | -7 dBm/freq | 48 | 30 | 04EF |
| MF digit 0 (steady) | -7 dBm/freq | 49 | 31 | 04F0 |
| MF digit 1 (steady) | -7 dBm/freq | 50 | 32 | 04F1 |
| MF digit 2 (steady) | -7 dBm/freq | 51 | 33 | 04F2 |
| MF digit 3 (steady) | -7 dBm/freq | 52 | 34 | 04F3 |
| MF digit 4 (steady) | -7 dBm/freq | 53 | 35 | 04F4 |
| MF digit 5 (steady) | -7 dBm/freq | 54 | 36 | 04F5 |
| MF digit 6 (steady) | -7 dBm/freq | 55 | 37 | 04F6 |
| MF digit 7 (steady) | -7 dBm/freq | 56 | 38 | 04F7 |
| MF digit 8 (steady) | -7 dBm/freq | 57 | 39 | 04F8 |
| MF digit 9 (steady) | -7 dBm/freq | 58 | 3A | 04F9 |
| MF digit KP | -7 dBm/freq | 59 | 3B | 04FA |
| MF digit ST | -7 dBm/freq | 60 | 3C | 04FB |
| MF digit ST3P | -7 dBm/freq | 61 | 3D | 04FC |
| MF digit STP | -7 dBm/freq | 62 | 3E | 04FD |
| MF digit ST2P | -7 dBm/freq | 63 | 3F | 04FE |