



## Preface

---

### Objective

The United Kingdom country feature package supports the tone plan as stated in Chapter 2, “United Kingdom Tone Plan.”

Except where otherwise noted, this supplement describes the installation, configuration, operation and general functionality of the United Kingdom country feature package as used with the following Virtual Central Office (VCO) and Specialty Digital Switch (SDS) platforms.

- VCO/4K running system software V5.x FSR00 PUN00 or higher
- VCO/20 running system software V4.0 FSR00 PUN00\* or higher
- VCO/80 running system software V3.3 FSR00 PUN00\*\* or higher
- SDS-1000 running system software V3.3 FSR00 PUN00\*\* or higher
- SDS-500 running system software V3.3 FSR00 PUN00\*\* or higher

\* The PUN number was included as part of the V4.x system software numbering scheme at V4.0 FSR02 PUN00.

\*\* The PUN number was included as part of the V3.x system software numbering scheme at V3.3 FSR05 PUN00.



#### Note

---

Within any given country, there may be more than one tone plan in use by the various telecommunication service providers who operate privately and/or publicly within the country in question. Thoroughly review the tone plan listed in Chapter 2, “United Kingdom Tone Plan” to verify that this is the country feature package that you ordered.

---

### Audience

This document is intended for all personnel using the United Kingdom country feature package.

# Document Organization

This document is organized as follows:

Chapter 1, “System Requirements” lists the system requirements for running the United Kingdom country feature package.

Chapter 2, “United Kingdom Tone Plan” details the modifications to the Digital Tone Generator (DTG or DTG-2) and Call Progress Analyzer (CPA) cards, and the SPC-CPA service cards.

## Documentation Conventions

This document uses the following conventions:



**Caution**

Means *reader be careful*. In this situation, you might do something that could result in equipment damage or loss of data.



**Note**

Means *reader take note*. Notes contain helpful suggestions or references to material not covered in the manual.

## Related Documentation

The *Cisco VCO/4K United Kingdom Supplement* provides important information about running the United Kingdom country feature package on the VCO and SDS platforms. If a topic is discussed in both the SDS/VCO documentation set and this supplement, refer to the information in this document.

Network signaling requirements appear in the following specifications:

- International Telecommunications Union (ITU, formerly Comité Consultatif International Téléphonique et Télégraphique, CCITT) Q.421 Digital Line Signaling Code
- ITU Q.440 Interregister Signaling

## Obtaining Documentation

The following sections provide sources for obtaining documentation from Cisco Systems.

### World Wide Web

You can access the most current Cisco documentation on the World Wide Web at the following sites:

- <http://www.cisco.com>
- <http://www-china.cisco.com>
- <http://www-europe.cisco.com>

## Documentation CD-ROM

Cisco documentation and additional literature are available in a CD-ROM package, which ships with your product. The Documentation CD-ROM is updated monthly and may be more current than printed documentation. The CD-ROM package is available as a single unit or as an annual subscription.

## Ordering Documentation

Cisco documentation is available in the following ways:

- Registered Cisco Direct Customers can order Cisco Product documentation from the Networking Products Marketplace:  
[http://www.cisco.com/cgi-bin/order/order\\_root.pl](http://www.cisco.com/cgi-bin/order/order_root.pl)
- Registered Cisco.com users can order the Documentation CD-ROM through the online Subscription Store:  
<http://www.cisco.com/go/subscription>
- Nonregistered Cisco.com users can order documentation through a local account representative by calling Cisco corporate headquarters (California, USA) at 408 526-7208 or, in North America, by calling 800 553-NETS(6387).

## Documentation Feedback

If you are reading Cisco product documentation on the World Wide Web, you can submit technical comments electronically. Click **Feedback** in the toolbar and select **Documentation**. After you complete the form, click **Submit** to send it to Cisco.

You can e-mail your comments to [bug-doc@cisco.com](mailto:bug-doc@cisco.com).

To submit your comments by mail, for your convenience many documents contain a response card behind the front cover. Otherwise, you can mail your comments to the following address:

Cisco Systems, Inc.  
Document Resource Connection  
170 West Tasman Drive  
San Jose, CA 95134-9883

We appreciate your comments.

## Obtaining Technical Assistance

Cisco provides Cisco.com as a starting point for all technical assistance. Customers and partners can obtain documentation, troubleshooting tips, and sample configurations from online tools. For Cisco.com registered users, additional troubleshooting tools are available from the TAC website.

## Cisco.com

Cisco.com is the foundation of a suite of interactive, networked services that provides immediate, open access to Cisco information and resources at anytime, from anywhere in the world. This highly integrated Internet application is a powerful, easy-to-use tool for doing business with Cisco.

Cisco.com provides a broad range of features and services to help customers and partners streamline business processes and improve productivity. Through Cisco.com, you can find information about Cisco and our networking solutions, services, and programs. In addition, you can resolve technical issues with online technical support, download and test software packages, and order Cisco learning materials and merchandise. Valuable online skill assessment, training, and certification programs are also available.

Customers and partners can self-register on Cisco.com to obtain additional personalized information and services. Registered users can order products, check on the status of an order, access technical support, and view benefits specific to their relationships with Cisco.

To access Cisco.com, go to the following website:

<http://www.cisco.com>

## Technical Assistance Center

The Cisco TAC website is available to all customers who need technical assistance with a Cisco product or technology that is under warranty or covered by a maintenance contract.

### Contacting TAC by Using the Cisco TAC Website

If you have a priority level 3 (P3) or priority level 4 (P4) problem, contact TAC by going to the TAC website:

<http://www.cisco.com/tac>

P3 and P4 level problems are defined as follows:

- P3—Your network performance is degraded. Network functionality is noticeably impaired, but most business operations continue.
- P4—You need information or assistance on Cisco product capabilities, product installation, or basic product configuration.

In each of the above cases, use the Cisco TAC website to quickly find answers to your questions.

To register for Cisco.com, go to the following website:

<http://www.cisco.com/register/>

If you cannot resolve your technical issue by using the TAC online resources, Cisco.com registered users can open a case online by using the TAC Case Open tool at the following website:

<http://www.cisco.com/tac/caseopen>

### Contacting TAC by Telephone

If you have a priority level 1 (P1) or priority level 2 (P2) problem, contact TAC by telephone and immediately open a case. To obtain a directory of toll-free numbers for your country, go to the following website:

<http://www.cisco.com/warp/public/687/Directory/DirTAC.shtml>

P1 and P2 level problems are defined as follows:

- P1—Your production network is down, causing a critical impact to business operations if service is not restored quickly. No workaround is available.
- P2—Your production network is severely degraded, affecting significant aspects of your business operations. No workaround is available.





# System Requirements

## Installation and Configuration

This chapter lists system requirements for running the United Kingdom country feature package on SDS and VCO platforms operating with system software V3.3 through V5.x. These requirements are categorized by hardware, firmware, and software. For any site-specific concerns, contact Cisco Systems as described in the preface.

The United Kingdom country feature package consists of the following components:

- Digital Tone Generator (DTG) card or DTG-2 card
- Call Progress Analyzer (CPA) or Service Platform (SPC) cards, software-configured for CPA (displayed as SPC-CPA)
- SPC card software-configured for DTMF (displayed as SPC-DTMF)
- Diskette for the CPA and SPC containing the download files



Note

Service circuit cards must occupy only one resource group in the Resource Group Summary screen; further, different card types cannot share the same resource group. Use either the SPC or the CPA card (but not both) if your system requires CPA service circuit functionality.

## Hardware Requirements

Refer to the *Cisco VCO/4K Tone Plan Release Notes* for the A-law and Mu-law rules and timing rules governing the hardware configurations of cards with jumpers/DIPs, and the software configuration of cards without jumpers/DIPs.

Refer to the *Cisco VCO/4K Card Technical Descriptions* for each service circuit card and for each network card for jumper and DIP switch settings.

## Firmware Requirements

Refer to the *Cisco VCO/4K Tone Plan Release Notes* for information regarding system firmware requirements particular to the United Kingdom country feature package.

Refer to your system release notes for step-by-step instructions to install firmware on either the DTG-2 mezzanine card or DTG card.

## Software Requirements

Refer to the *Cisco VCO/4K Tone Plan Release Notes* for information regarding the cpa.dwn software file and the SPC software files particular to the United Kingdom country feature package.

System software V5.1 FSR00 PUN21, or higher, is required to operate the United Kingdom SPC software on the SPC.

### Call Progress Analyzer and Service Platform Card Download Files

Your country feature package contains a 3.5-inch diskette containing two directories. These directories contain Call Progress Analyzer (CPA) and Service Platform Card (SPC) download files. The two directories are named PRE-P24 and POST-P24. The following files are included in each directory:

cpa.dwn  
cpa.nor  
cpa.spc  
cpa.sit  
cpa.ctg  
dtmf.spc

Copy the PRE-P24 directory contents to your system's C:/BOOT directory if you are using system software that is at least V5.0, but not greater than V5.1 FSR00 PUN23. Copy the POST-P24 directory contents to your system's C:/BOOT directory if you are using system software V5.1 FSR00 PUN24, and higher.

In addition, if you are using system software V4.2 FSR00 PUN28 and lower, copy only the cpa.dwn file to the C:/BOOT directory.

Refer to the *Cisco VCO/4K System Administrator's Guide* for step-by-step instructions in order to copy the above files to your system's C:/BOOT directory.

**Note**

---

Always wear a wrist strap when installing software and handling system components.

---

The files are now loaded onto your hard disk. Complete the installation by loading the files from the hard disk to the cards. The method of loading depends on whether or not it is for a new installation, or for an existing installation. For new installations, refer to the "Loading the Software onto Cards—New Installations" section on page 1-2; for existing installations, refer to the "Loading the Software onto Cards—Existing Installations" section on page 1-3.

Refer to the *Cisco VCO/4K System Administrator's Guide* for step-by-step instructions as you complete this installation procedure.

### Loading the Software onto Cards—New Installations

To load files from the hard disk to cards in a new installation, follow these steps:

- 
- |               |  |
|---------------|--|
| <b>Step 1</b> | Access the Card Maintenance screen from the Maintenance Menu screen, and add the CPA (the console displays this choice as Call Progress Analyzer) or the SPC (the console displays this choice as either SPC-CPA or SPC-DTMF) to the database by using the A command, if you have not already done so. |
| <b>Step 2</b> | Insert your card, either the CPA or the SPC, into the appropriate slot. The card automatically runs internal diagnostics. One of two results follow, dependent upon which card you have inserted.  |

**Caution**


---

Do not unseat or otherwise disturb the card while running internal diagnostics.

---

- For the CPA, the three LEDs display the transition from off (all LEDs unlighted) to on (the red and yellow unlighted, and the green lighted).
- For the SPC, the LED matrix display transitions from off (all LEDs in the matrix display are unlighted) to on (the LED matrix display lights the letters S, P, and C, one at a time repeatedly; the lower right LED of the matrix display changes from unlighted to lighted repeatedly).

**Step 3** Activate the card using the C command from the Card Maintenance screen. The card takes the download. The service circuit spans are active, as can be seen from the Card Maintenance screen.

**Caution**


---

Do not unseat or otherwise disturb the card while it is downloading.

---

**Step 4** Verify the received FRM225, FRM226, FRM241, and FRM242 messages in your log file to ensure that the card has taken the download.

For the SPC, verify two additional messages in the log file: “Begin downloading spec file C:/boot/xxx.xxx” and “End downloading spec file C:/boot/xxx.xxx”. The CPA does not have these, or any other, additional log file messages.

**Step 5** Create a resource group for the CPA or the SPC service circuits.

You have completed the software installation.

---

## Loading the Software onto Cards—Existing Installations

To load files from the hard disk to cards on an existing installation, follow these steps.

**Caution**


---

This process disrupts in-progress calls and removes service circuits from operation for a few minutes.

---

**Step 1** Access the Card Maintenance screen from the Maintenance Menu screen, and take either the CPA card or the SPC service circuits out of service (OOS), if you have not already done so.

If you have a CPA, unseat it, wait 15 seconds, then insert the card into its slot. The SPC does not require, or allow, this action.

**Step 2** Activate the CPA or the various SPC service circuits using the C command from the Card Maintenance screen.

**Caution**


---

Do not unseat or otherwise disturb the card while it is downloading.

---

**Step 3** Verify received download messages in your log file to ensure that the card has taken the download. The messages you need to verify are dependent upon which card type you are using.

- For the CPA, verify the received FRM225, FRM226, FRM241, and FRM242 messages.
- For the SPC, verify the following two messages in the log file: “Begin downloading spec file C:/boot/xxx.xxx” and “End downloading spec file C:/boot/xxx.xxx”.

**Note**


---

The SPC does not take a redownloading of the spc.dwn file.

---

You have completed the software installation.

---

## Typical System Software Configurations

This section lists typical system software configurations used with the United Kingdom country feature package. For more information on how to use and configure the various software screens and menus, refer to the *Cisco VCO/4K System Administrator's Guide*.

### Database Administration

Special considerations pertain to the following Database Administration menus and screens.

#### Card Summary Menu

The Card Summary menu displays the status and port availability of E1, 4xE1, and ICC cards. To assign operating characteristics to E1 spans, access the Configuration screen for that card from the Card Summary menu.

**Note**


---

The term “E1 span” designates E1 and 4xE1 cards, or ICC cards with associated ICC-E1-I/O module.

---

#### Resource Group Summary Menu

To optimize outgoing call system performance, group E1 span outgoing ports into one or more resource groups.

#### Inpulse and Outpulse Rule Screen

For information about inpulse and outpulse rule tokens, refer to the *Cisco VCO/4K System Administrator's Guide*.

#### Answer Supervision Template Screen

Refer to the “Tone Detection” section on page 2-2 for information on the answer supervision template function.

### Maintenance

Special considerations pertain to the following Maintenance screen.

## Card Maintenance Screen

Use the Card Maintenance screen to add, delete, and change the card/port status for E1 spans. When an E1 span is added to the Card Maintenance screen, its span type is set to CAS/R2 by default.

For E1 spans set to CAS/R2, ports 1 and 17 of the card's 32 ports are reserved. Port 1 (Channel 0) carries the frame alignment pattern, remote alarm indication bit, and national-use bits. Port 17 (Channel 16) carries the multiframe alignment pattern, extra bits, and channel-associated signaling bits.

For 4xE1 and ICC cards, set the span type to CCS/31B from the Card Summary menu in order to use port 17 as a bearer port. Use E1-31B firmware on single span E1 cards in order to use port 17 as a bearer port.

## Diagnostics

Special considerations pertain to the following Diagnostics screens.

### Card Display Screen

The Card Display screen lists the operating status of E1 span. Information on the Card Display screen varies according to card type and span type.

### Port Display Screen

The Port Display screen lists the processing states, rule processing, links, paths, and digit collection activity of E1 spans.

### Test Port Card Screen

The Test Port Card screen tests individual E1 channels. A path is set up between three elements—the selected E1 channel(s), the Service Platform Card-Dual Tone Multifrequency (SPC-DTMF) card or DTMF Receiver Card (DRC), and a Digital Tone Generator (DTG) channel. The system compares the signals sent by the DTG card with the signals received by the SPC-DTMF card or the DRC and reports discrepancies. You can test all channels on an E1 span with one command. You can select the E1 span for port card diagnostic tests. The E1 span enters a local loopback mode during the test and sends out an all 1s (ones) pattern.

### Test Service Circuit Screen

The Test Service Circuit screen tests DRC and SPC-DTMF service circuits.

## Host Command and Reports

The host commands and reports are documented in the *Cisco VCO/4K Programming Reference* and the *Cisco VCO/4K Extended Programming Reference*.





## United Kingdom Tone Plan

This chapter details the modifications to the Digital Tone Generator (DTG or DTG-2), Call Progress Analyzer (CPA) card, and Service Platform (SPC)-CPA service circuits to support the following features:

- Supervision tones specific to the United Kingdom telephone network
- Additional tones used with the conferencing capabilities of the VCO

The information in this chapter supersedes the information in the following manuals:

- *Cisco VCO/4K System Administrator's Guide*
- *Cisco VCO/4K Standard Programming Reference*
- *Cisco VCO/4K Extended Programming Reference*
- *Cisco VCO/4K Supervision and Call Progress Tone Detection*

## Tone Characteristics

Table 2-1 summarizes the characteristics of the most frequently used supervision tones in the United Kingdom network.

**Table 2-1** *United Kingdom Digital Tone Generator Supervision Tones*

Tone	Frequencies (Hz)	Amplitude (dBm)	Cadence	Detected by CPA?
Dial	350 + 440	-18	Continuous	Yes
Audible Ringback	400 + 450	-15.5	0.4 seconds on, 0.2 seconds off, 0.4 seconds on, 2.0 seconds off, REPEATED	Yes
Busy	400	-14	0.4 seconds on, 0.4 seconds off, REPEATED	Yes
Fast Busy	400	-14	0.25 seconds on, 0.25 seconds off, REPEATED	Yes

Table 2-2 lists two additional DTG tones for VCO conferences. These tones inform conference participants when another conference party or recording device is attached to the conference.

**Table 2-2** *United Kingdom Conference Tones*

Tone	Frequency (Hz)	Amplitude (dBm)	Cadence	Detected by CPA?
Intrusion	1400	-12	150 ms on, 1.5 seconds off, REPEATED	No
Recorder Warning	1400	-12	500 ms on, 1.5 seconds off, REPEATED	No

## Tone Detection

CPA processing is modified to support the United Kingdom network requirements. Use the system administration answer supervision templates function to control tone detection for the tones listed in Table 2-1. Supervision template processing is described in the *Cisco VCO/4K System Administrator's Guide*.

## Answer Supervision Template Screen Terminology

The supervision events and tones listed in the Answer Supervision Template screen use standard North American network terminology. Table 2-3 shows the Answer Supervision Template screen terms to use with the United Kingdom country feature package.

Because the conference tones are used only in conference structures and are not transmitted or received over the network, no detection functions are required.

**Table 2-3** *Answer Supervision Template Screen Terminology for the United Kingdom*

Answer Supervision Template Event and Tone Names	United Kingdom Tone Name or Meaning
Dial Tone	Dial
Ringback	Audible Ringback
Busy	Busy
Reorder	Fast Busy
SIT Tones	Not Available
Ring Cess. <sup>1</sup>	Not Applicable
Voice Det. <sup>1</sup>	Not Applicable
Voice Cess. <sup>1</sup>	Not Applicable
Wink <sup>1</sup>	Not Applicable
Answer <sup>1</sup>	Not Applicable
Time <sup>1</sup>	Not Applicable

**Table 2-3 Answer Supervision Template Screen Terminology for the United Kingdom (continued)**

Answer Supervision Template Event and Tone Names	United Kingdom Tone Name or Meaning
Hook Flash <sup>1</sup>	Not Applicable
Pager Cue	Not Available
ISUP Tone	Not Available
ISUP Cess. <sup>1</sup>	Not Applicable

1. Not a tone.

## Tone Generation

Tone generation is performed through DTG outpulse and static tone channels. The allocation of these tones is controlled via inpulse rules, Voice Path Control (\$66) commands, and DTMF Collection Control (\$67) commands.

Table 2-4 supersedes the tone generation table listed in the *Cisco VCO/4K Standard Programming Reference* and the *Cisco VCO/4K Extended Programming Reference*. It also supersedes the tone output level specifications found in the *Cisco VCO/4K Card Technical Descriptions*. For more information on generating tones, refer to the *Cisco VCO/4K System Administrator's Guide*.

The tones and their corresponding output levels, decimal values, hexadecimal values, and port addresses are summarized in Table 2-4.

**Table 2-4 Tone Levels, Values, and Port Addresses**

Tone	Output Level	Decimal Value	Hex Value	Port Addresses
Beep		0	00	None
Quiet (PCM idle pattern 01010100)	—	1	01	04C0
1 KHz Test Tone	0 dBm	2	02	04C1
<b>Dial</b>	<b>–18 dBm/freq</b>	<b>3</b>	<b>03</b>	<b>04C2</b>
380 Hz Digit Trip	–10 dBm	4	04	04C3
440 Hz	–13 dBm	5	05	04C4
480 Hz High Tone	–17 dBm	6	06	04C5
1400 Hz	–12 dBm	7	07	04C6
1000 Hz @max CODEC output	5.79 dBm	8	08	04C7
920 Hz	–13 dBm	9	09	04C8
404 Hz Test Tone	0 dBm	10	0A	04C9
1004 Hz Test Tone	0 dBm	11	0B	04CA
2804 Hz Test Tone	0 dBm	12	0C	04CB
400+450 Hz Steady Ringback	–15.5 dBm/freq	13	0D	04CC
1760 Hz	–10 dBm	14	0E	04CD
Digital Test Pattern	—	15	0F	04CE

*Table 2-4 Tone Levels, Values, and Port Addresses (continued)*

Tone	Output Level	Decimal Value	Hex Value	Port Addresses
400 Hz	-14 dBm	16	10	04CF
<b>Audible Ringback</b>	<b>-15.5 dBm/freq</b>	<b>17</b>	<b>11</b>	<b>04D0</b>
<b>Busy</b>	<b>-14 dBm</b>	<b>18</b>	<b>12</b>	<b>04D1</b>
<b>Fast Busy</b>	<b>-14 dBm</b>	<b>19</b>	<b>13</b>	<b>04D2</b>
380 Hz Digit Trip	-10 dBm	20	14	04D3
Reserved	—	21	15	04D4
Intrusion	-12 dBm	—	16	04D5
<b>Recorder Warning</b>	<b>-12 dBm</b>	<b>—</b>	<b>17</b>	<b>04D6</b>
Reserved	—	24 to 32	18 to 20	04D7 to 04 DF
DTMF digit 0 (steady)	-13/-11 dBm/freq	33	21	04E0
DTMF digit 1 (steady)	-13/-11 dBm/freq	34	22	04E1
DTMF digit 2 (steady)	-13/-11 dBm/freq	35	23	04E2
DTMF digit 3 (steady)	-13/-11 dBm/freq	36	24	04E3
DTMF digit 4 (steady)	-13/-11 dBm/freq	37	25	04E4
DTMF digit 5 (steady)	-13/-11 dBm/freq	38	26	04E5
DTMF digit 6 (steady)	-13/-11 dBm/freq	39	27	04E6
DTMF digit 7 (steady)	-13/-11 dBm/freq	40	28	04E7
DTMF digit 8 (steady)	-13/-11 dBm/freq	41	29	04E8
DTMF digit 9 (steady)	-13/-11 dBm/freq	42	2A	04E9
DTMF digit A (steady)	-13/-11 dBm/freq	43	2B	04EA
DTMF digit B (steady)	-13/-11 dBm/freq	44	2C	04EB
DTMF digit C (steady)	-13/-11 dBm/freq	45	2D	04EC
DTMF digit D (steady)	-13/-11 dBm/freq	46	2E	04ED
DTMF digit * (steady)	-13/-11 dBm/freq	47	2F	04EE

*Table 2-4 Tone Levels, Values, and Port Addresses (continued)*

Tone	Output Level	Decimal Value	Hex Value	Port Addresses
DTMF digit # (steady)	–13/–11 dBm/freq	48	30	04EF
MF digit 0 (steady)	–7 dBm/freq	49	31	04F0
MF digit 1 (steady)	–7 dBm/freq	50	32	04F1
MF digit 2 (steady)	–7 dBm/freq	51	33	04F2
MF digit 3 (steady)	–7 dBm/freq	52	34	04F3
MF digit 4 (steady)	–7 dBm/freq	53	35	04F4
MF digit 5 (steady)	–7 dBm/freq	54	36	04F5
MF digit 6 (steady)	–7 dBm/freq	55	37	04F6
MF digit 7 (steady)	–7 dBm/freq	56	38	04F7
MF digit 8 (steady)	–7 dBm/freq	57	39	04F8
MF digit 9 (steady)	–7 dBm/freq	58	3A	04F9
MF digit KP (steady)	–7 dBm/freq	59	3B	04FA
MF digit ST (steady)	–7 dBm/freq	60	3C	04FB
MF digit ST3P	–7 dBm/freq	61	3D	04FC
MF digit STP	–7 dBm/freq	62	3E	04FD
MF digit ST2P	–7 dBm/freq	63	3F	04FE

