

Command Control Interface Installation and Configuration Guide

Hitachi Virtual Storage Platform G200, G400, G600, G800

Hitachi Virtual Storage Platform F400, F600, F800

Hitachi Virtual Storage Platform G1000

Hitachi Unified Storage VM

Hitachi Virtual Storage Platform

Hitachi Universal Storage Platform V/VM

© 2010, 2015 Hitachi, Ltd. All rights reserved.

No part of this publication may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopying and recording, or stored in a database or retrieval system for any purpose without the express written permission of Hitachi, Ltd.

Hitachi, Ltd., reserves the right to make changes to this document at any time without notice and assumes no responsibility for its use. This document contains the most current information available at the time of publication. When new or revised information becomes available, this entire document will be updated and distributed to all registered users.

Some of the features described in this document might not be currently available. Refer to the most recent product announcement for information about feature and product availability, or contact Hitachi Data Systems Corporation at https://support.hds.com/en_us/contact-us.html.

Notice: Hitachi, Ltd., products and services can be ordered only under the terms and conditions of the applicable Hitachi Data Systems Corporation agreements. The use of Hitachi, Ltd., products is governed by the terms of your agreements with Hitachi Data Systems Corporation.

Hitachi is a registered trademark of Hitachi, Ltd., in the United States and other countries. Hitachi Data Systems is a registered trademark and service mark of Hitachi, Ltd., in the United States and other countries.

Archivas, Essential NAS Platform, HiCommand, Hi-Track, ShadowImage, Tagmaserve, Tagmasoft, Tagmasolve, Tagmastore, TrueCopy, Universal Star Network, and Universal Storage Platform are registered trademarks of Hitachi Data Systems.

AIX, AS/400, DB2, Domino, DS6000, DS8000, Enterprise Storage Server, ESCON, FICON, FlashCopy, IBM, Lotus, MVS, OS/390, RS/ 6000, S/390, System z9, System z10, Tivoli, VM/ESA, z/OS, z9, z10, zSeries, z/VM, and z/VSE are registered trademarks or trademarks of International Business Machines Corporation.

All other trademarks, service marks, and company names in this document or web site are properties of their respective owners.

Microsoft product screen shots are reprinted with permission from Microsoft Corporation.

Notice on Export Controls: The technical data and technology inherent in this Document may be subject to U.S. export control laws, including the U.S. Export Administration Act and its associated regulations, and may be subject to export or import regulations in other countries. Reader agrees to comply strictly with all such regulations and acknowledges that Reader has the responsibility to obtain licenses to export, re-export, or import the Document and any Compliant Products.



Contents

Preface.....	V
Intended audience.....	vi
Product version.....	vi
Release notes.....	vi
Document revision level.....	vi
Changes in this revision.....	vii
Referenced documents.....	vii
Conventions.....	vii
Convention for storage capacity values.....	ix
Accessing product documentation.....	x
Getting help.....	x
Comments.....	x
1 Installation requirements.....	1-1
System requirements.....	1-2
Requirements and restrictions for z/Linux.....	1-5
Requirements and restrictions for VM.....	1-7
Restrictions for VMware ESX Server.....	1-8
Restrictions on AIX VIO.....	1-9
Restrictions on Windows Hyper-V (Windows 2012/2008).....	1-11
Restrictions on Oracle VM.....	1-12
About platforms supporting IPv6.....	1-13
Library and system call for IPv6.....	1-13
Environment variable.....	1-14
Porting notice for OpenVMS.....	1-15
Requirements and restrictions for OpenVMS.....	1-15
Known issues	1-20
Startup procedures using detached process on DCL.....	1-21
Command examples in DCL.....	1-24
Start-up procedures in bash.....	1-27
Using CCI with Hitachi and other storage systems.....	1-29
2 Installing and configuring CCI.....	2-1
Installing the CCI hardware.....	2-2
Installing the CCI software.....	2-2

UNIX installation.....	2-3
Changing the CCI user (UNIX systems).....	2-4
Windows installation.....	2-5
Changing the CCI user (Windows systems).....	2-6
OpenVMS installation.....	2-7
In-band and out-of-band operations.....	2-8
Setting up UDP ports.....	2-12
Setting the command device.....	2-12
Setting the command device and virtual command device by in-band and out-	
of-band methods.....	2-14
About alternate command devices.....	2-15
Creating/editing the configuration definition file.....	2-16
3 Upgrading CCI.....	3-1
Upgrading CCI in a UNIX environment.....	3-2
Upgrading CCI in a Windows environment.....	3-2
Upgrading CCI in an OpenVMS environment.....	3-3
4 Removing CCI.....	4-1
Removing CCI in a UNIX environment.....	4-2
Removing CCI in a Windows environment.....	4-3
Removing CCI in an OpenVMS environment.....	4-3
Removing the CCI components.....	4-3
5 Troubleshooting.....	5-1
Troubleshooting.....	5-2
A Fibre-to-SCSI address conversion.....	A-1
Fibre/FCoE-to-SCSI address conversion.....	A-2
LUN configurations on the RAID storage systems.....	A-4
Fibre address conversion tables.....	A-5
B Sample configuration definition files.....	B-1
Sample configuration definition files.....	B-2
Examples of CCI configurations.....	B-16
Correspondence of the configuration definition file for cascading volume and	
mirror descriptors.....	B-39
Cascade function and configuration files.....	B-40
ShadowImage.....	B-41
Cascading connections for TrueCopy and ShadowImage.....	B-43

Index



Preface

This document describes and provides instructions for installing Command Control Interface (CCI) software for the Hitachi RAID storage systems, including upgrading and removing CCI.

Please read this document carefully to understand how to use this product, and maintain a copy for reference purposes.

- ☐ [Intended audience](#)
- ☐ [Product version](#)
- ☐ [Release notes](#)
- ☐ [Document revision level](#)
- ☐ [Changes in this revision](#)
- ☐ [Referenced documents](#)
- ☐ [Conventions](#)
- ☐ [Convention for storage capacity values](#)
- ☐ [Accessing product documentation](#)
- ☐ [Getting help](#)
- ☐ [Comments](#)

Intended audience

This document is intended for system administrators, Hitachi Data Systems representatives, and authorized service providers who install, configure, and use the Command Control Interface software for the Hitachi RAID storage systems.

Readers of this document should be familiar with the following:

- Data processing and RAID storage systems and their basic functions.
- The Hitachi RAID storage system and the manual for the storage system (for example, *Hitachi Virtual Storage Platform G1000 Hardware User Guide*, *Hitachi Virtual Storage Platform User and Reference Guide*).
- The management software for the storage system (for example, Hitachi Command Suite, Hitachi Device Manager - Storage Navigator, Storage Navigator) and the applicable user manuals (for example, *Hitachi Command Suite User Guide*, *Hitachi Virtual Storage Platform G1000 System Administrator Guide*, *Hitachi Storage Navigator User Guide* for VSP, HUS VM, USP V/VM).
- The host systems attached to the Hitachi RAID storage systems.

Product version

This document revision applies to Command Control Interface software version 01-35-03/xx or later.

Release notes

The CCI Release Notes are available on Hitachi Data Systems Support Connect: https://support.hds.com/en_us/documents.html. Read the release notes before installing and using this product. They may contain requirements or restrictions that are not fully described in this document or updates or corrections to this document.

Document revision level

Revision	Date	Description
MK-90RD7008-00	October 2010	Initial release
MK-90RD7008-01	December 2010	Supersedes and replaces MK-90RD7008-00
MK-90RD7008-02	April 2011	Supersedes and replaces MK-90RD7008-01
MK-90RD7008-03	March 2012	Supersedes and replaces MK-90RD7008-02
MK-90RD7008-04	September 2012	Supersedes and replaces MK-90RD7008-03
MK-90RD7008-05	November 2012	Supersedes and replaces MK-90RD7008-04
MK-90RD7008-06	July 2013	Supersedes and replaces MK-90RD7008-05

Revision	Date	Description
MK-90RD7008-07	October 2013	Supersedes and replaces MK-90RD7008-06
MK-90RD7008-08	April 2014	Supersedes and replaces MK-90RD7008-07
MK-90RD7008-09	August 2014	Supersedes and replaces MK-90RD7008-08
MK-90RD7008-10	October 2014	Supersedes and replaces MK-90RD7008-09
MK-90RD7008-11	February 2015	Supersedes and replaces MK-90RD7008-10
MK-90RD7008-12	April 2015	Supersedes and replaces MK-90RD7008-11
MK-90RD7008-13	August 2015	Supersedes and replaces MK-90RD7008-12
MK-90RD7008-14	November 2015	Supersedes and replaces MK-90RD7008-13

Changes in this revision

- Added a note about a hardware configuration change that changes the special file name for the command device, and a procedure for preventing the failure associated with this situation (see the new note in (2) HORCM_CMD in [Sample configuration definition files on page B-2](#)).

Referenced documents

Command Control Interface documents:

- Command Control Interface Command Reference*, MK-90RD7009
- Command Control Interface User and Reference Guide*, MK-90RD7010

Storage system documents:

- Hardware Guide or User and Reference Guide* for the storage system
- Open-Systems Host Attachment Guide*, MK-90RD7037
- Hitachi Command Suite User Guide*, MK-90HC172
- System Administrator Guide or Storage Navigator User Guide* for the storage system
- Storage Navigator Messages* for the storage system
- Provisioning/LUN Manager/Virtual LUN User Guide* for the storage system

Conventions

This document uses the following terminology conventions:






Convention	Description
Hitachi RAID storage system, storage system	Refers to all storage system models, unless otherwise noted.

Convention	Description
VSP Gx00 models	Refers to all models of the Hitachi Virtual Storage Platform G200, G400, G600, G800 storage systems, unless otherwise noted.
VSP Fx00 models	Refers to all models of the Hitachi Virtual Storage Platform F400, F600, F800 storage systems, unless otherwise noted.

This document uses the following typographic conventions:

Convention	Description
Bold	<ul style="list-style-type: none"> Indicates text in a window, including window titles, menus, menu options, buttons, fields, and labels. Example: Click OK. Indicates emphasized words in list items.
<i>Italic</i>	<ul style="list-style-type: none"> Indicates a document title or emphasized words in text. Indicates a variable, which is a placeholder for actual text provided by the user or for output by the system. Example: <code>pairdisplay -g group</code> (For exceptions to this convention for variables, see the entry for angle brackets.)
Monospace	Indicates text that is displayed on screen or entered by the user. Example: <code>pairdisplay -g oradb</code>
< > (angle brackets)	Indicates variables in the following scenarios: <ul style="list-style-type: none"> Variables are not clearly separated from the surrounding text or from other variables. Example: <code>Status-<report-name><file-version>.csv</code> Variables in headings.
[] (square brackets)	Indicates optional values. Example: [a b] indicates that you can choose a, b, or nothing.
{ } (braces)	Indicates required or expected values. Example: { a b } indicates that you must choose either a or b.
(vertical bar)	Indicates that you have a choice between two or more options or arguments. Examples: [a b] indicates that you can choose a, b, or nothing. { a b } indicates that you must choose either a or b.
↓value↓ floor floor(value)	Floor function (round down value to the next integer)
↑value↑ ceiling ceiling(value)	Ceiling function (round up value to the next integer)
_ (underlined text)	Default value

This document uses the following icons to draw attention to information:

Icon	Label	Description
	Note	Calls attention to important or additional information.
	Tip	Provides helpful information, guidelines, or suggestions for performing tasks more effectively.
	Important	Calls attention to important or additional information.
	Caution	Warns the user of adverse conditions or consequences (for example, disruptive operations).
	WARNING	Warns the user of severe conditions or consequences (for example, destructive operations).

Convention for storage capacity values

Physical storage capacity values (for example, disk drive capacity) are calculated based on the following values:

Physical capacity unit	Value
1 KB	1,000 (10^3) bytes
1 MB	1,000 KB or $1,000^2$ bytes
1 GB	1,000 MB or $1,000^3$ bytes
1 TB	1,000 GB or $1,000^4$ bytes
1 PB	1,000 TB or $1,000^5$ bytes
1 EB	1,000 PB or $1,000^6$ bytes

Logical storage capacity values (for example, logical device capacity) are calculated based on the following values:

Logical capacity unit	Value
1 block	512 bytes
1 cylinder	Mainframe: 870 KB Open-systems: <ul style="list-style-type: none"> • OPEN-V: 960 KB • Others: 720 KB
1 KB	$1,024 (2^{10})$ bytes
1 MB	1,024 KB or $1,024^2$ bytes

Logical capacity unit	Value
1 GB	1,024 MB or 1,024 ³ bytes
1 TB	1,024 GB or 1,024 ⁴ bytes
1 PB	1,024 TB or 1,024 ⁵ bytes
1 EB	1,024 PB or 1,024 ⁶ bytes

Accessing product documentation

Product documentation is available on Hitachi Data Systems Support Connect: https://support.hds.com/en_us/documents.html. Check this site for the most current documentation, including important updates that may have been made after the release of the product.

Getting help

[Hitachi Data Systems Support Connect](#) is the destination for technical support of products and solutions sold by Hitachi Data Systems. To contact technical support, log on to Hitachi Data Systems Support Connect for contact information: https://support.hds.com/en_us/contact-us.html.

[Hitachi Data Systems Community](#) is a new global online community for HDS customers, partners, independent software vendors, employees, and prospects. It is the destination to get answers, discover insights, and make connections. **Join the conversation today!** Go to community.hds.com, register, and complete your profile.

Comments

Please send us your comments on this document: doc.comments@hds.com. Include the document title and number, including the revision level (for example, -07), and refer to specific sections and paragraphs whenever possible. All comments become the property of Hitachi Data Systems Corporation.

Thank you!

Installation requirements

This chapter describes the installation requirements for the Command Control Interface (CCI) software.

- ☐ [System requirements](#)
- ☐ [Requirements and restrictions for z/Linux](#)
- ☐ [Requirements and restrictions for VM](#)
- ☐ [About platforms supporting IPv6](#)
- ☐ [Porting notice for OpenVMS](#)
- ☐ [Using CCI with Hitachi and other storage systems](#)

System requirements

[Table 1-1 System requirements on page 1-2](#) lists and describes the system requirements for Command Control Interface.

Table 1-1 System requirements

Item	Requirement
Command Control Interface software product	The CCI software is supplied on the media for the program product (for example, DVD-ROM). The CCI software files take up 2.5 MB of space. The log files can take up to 3 MB of space.
Hitachi RAID storage systems	<p>The requirements for the RAID storage systems are:</p> <ul style="list-style-type: none">• Microcode. The availability of features and functions depends on the level of microcode installed on the storage system.• Command device. The CCI command device must be defined and accessed as a raw device (no file system, no mount operation).• License keys. The option for each software product to be used (for example, Universal Replicator, Dynamic Tiering) must be installed and enabled on the storage system.• System option modes. Before you begin operations, the system option modes (SOMs) must be set on the storage system by your Hitachi Data Systems representative. For details about the SOMs, see the <i>Hardware Guide</i> or <i>User and Reference Guide</i> for your storage system. <p>Note: Check the appropriate manuals (for example, <i>Hitachi TrueCopy® for Mainframe User Guide</i>) for SOMs that are required or recommended for your operational environment.</p> <ul style="list-style-type: none">• System requirements for Hitachi software products. Make sure that your system meets the requirements for operation of the Hitachi software products. For example: TrueCopy, Universal Replicator, global-active device: Bi-directional swap must be enabled between the primary and secondary volumes. The port attributes (for example, initiator, target, RCU target) and the MCU-RCU paths must be defined. Copy-on-Write Snapshot: ShadowImage is a prerequisite for Copy-on-Write Snapshot. Thin Image: Dynamic Provisioning is a prerequisite for Thin Image. <p>Note: Check the appropriate manuals (for example, <i>Hitachi Universal Replicator User Guide</i>) for the system requirements for your operational environment.</p> <p>For details about other storage systems, see Using CCI with Hitachi and other storage systems on page 1-29.</p>
Host platforms for in-band operations	<p>In-band (host-based) CCI operations are supported on the following host platforms:</p> <ul style="list-style-type: none">• AIX• HP-UX• IRIX• Red Hat Enterprise Linux (RHEL)• OpenVMS• Oracle Linux (OEL)• Solaris

Item	Requirement
	<ul style="list-style-type: none"> • SUSE Linux Enterprise Server (SLES) • Tru64 UNIX • VMware • Windows • z/Linux <p>When a vendor discontinues support of a host software version, CCI that is released at or after that time will not support that version of the host software.</p> <p>For detailed support information (for example, OS versions), refer to the Hitachi Data Systems interoperability matrix: http://www.hds.com/products/interoperability</p>
Host platforms for out-of-band operations (raidcom command)	<p>Out-of-band (LAN-based) CCI operations (raidcom command) are supported on the following host platforms:</p> <ul style="list-style-type: none"> • AIX • HP-UX • IRIX • Red Hat Enterprise Linux (RHEL) • Oracle Linux (OEL) • Solaris • SUSE Linux Enterprise Server (SLES) • Tru64 UNIX • VMware • Windows • z/Linux <p>When a vendor discontinues support of a host software version, CCI that is released at or after that time will not support that version of the host software.</p> <p>For details about supported OS versions and browsers, see the Hitachi Storage Navigator User Guide.</p>
I/O interface	<p>For details about I/O interface support (Fibre, SCSI, iSCSI), refer to the Hitachi Data Systems interoperability matrix: http://www.hds.com/products/interoperability</p>
Host access	<p>Root/administrator access to the host is required to perform CCI operations.</p>
Host memory	<p>This product requires static memory and dynamic memory for executing the load module.</p> <ul style="list-style-type: none"> • Static memory capacity: 600KB min. to 1200KB max. • Dynamic memory capacity: determined by the description of the configuration file. <p>The minimum is: (Number of unit IDs × 200 KB) + (Number of LDEVs × 360B) + (Number of entries × 180B)</p> <ul style="list-style-type: none"> ◦ Number of unit IDs: number of storage chassis ◦ Number of LDEVs: number of LDEVs (each instance) ◦ Number of entries: number of paired entries (pairs) <p>Example for a 1:3 pair configuration:</p> <ul style="list-style-type: none"> • Number of LDEVs in the primary instance = 1 • Number of entries (pairs) in the primary instance = 3

Item	Requirement
	<ul style="list-style-type: none"> Number of LDEVs in the secondary instance = 3 Number of entries (pairs) in the secondary instance = 3
IPv6, IPv4	<p>The minimum OS platform versions for CCI/IPv6 support are:</p> <ul style="list-style-type: none"> HP-UX: HP-UX 11.23 (PA/IA) or later Solaris: Solaris 9/Sparc or later, Solaris 10/x86/64 or later AIX: AIX 5.3 or later Windows: Windows 2008(LH) Linux: Linux Kernel 2.4 (RH8.0) or later Tru64: Tru64 v5.1A or later. Note that v5.1A does not support the getaddrinfo() function, so this must be specified by IP address directly. OpenVMS: OpenVMS 8.3 or later <p>UDP ports: Contact your network administrator for appropriate UDP port numbers to use in your network. The network administrator must enable these ports to allow traffic between CCI servers. For details about the setting up UDP ports, see Setting up UDP ports on page 2-12.</p> <p>See the following tables for details about IPv6/IPv4 support:</p> <ul style="list-style-type: none"> Table 1-2 Supported Platforms: IPv6 vs IPv6 on page 1-4 Table 1-3 Supported Platforms: IPv4 vs IPv6 on page 1-5
Supported guest OS for VMware	CCI needs to use guest OS that is supported by CCI, and also VMware supported guest OS (for example, Windows Server 2008, Red Hat Linux, SuSE Linux). For details about guest OS support for VMware, refer to the Hitachi Data Systems interoperability matrix: http://www.hds.com/products/interoperability
Failover	CCI supports many industry-standard failover products. For details, refer to the Hitachi Data Systems interoperability matrix (http://www.hds.com/products/interoperability) or contact your Hitachi Data Systems representative.
Volume manager	CCI supports many industry-standard volume manager products. For details, refer to the Hitachi Data Systems interoperability matrix (http://www.hds.com/products/interoperability) or contact your Hitachi Data Systems representative.
High availability (HA) configurations	<p>The system that runs and operates TrueCopy in an HA configuration must be a duplex system having a hot standby or mutual hot standby (mutual takeover) configuration. The remote copy system must be designed for remote backup among servers and configured so that servers cannot share the primary and secondary volumes at the same time. The information in this document does not apply to fault-tolerant system configurations such as Oracle Parallel Server (OPS) in which nodes execute parallel accesses. However, two or more nodes can share the primary volumes of the shared OPS database, and must use the secondary volumes as exclusive backup volumes.</p> <p>Host servers that are combined when paired logical volumes are defined should run on operating systems of the same architecture. If not, one host might not be able to recognize a paired volume of another host, even though CCI runs properly.</p>

Table 1-2 Supported Platforms: IPv6 vs IPv6

IPv6		CCI / IPv6*						
		HP-UX	Solaris	AIX	Windows	Linux	Tru64	OpenVMS

IPv6		CCI / IPv6*						
CCI / IPv6	HP-UX	AV	AV	AV	AV	AV	AV	N/A
	Solaris	–	AV	AV	AV	AV	AV	N/A
	AIX	–	–	AV	AV	AV	AV	N/A
	Windows	–	–	–	AV	AV	AV	N/A
	Linux	–	–	–	–	AV	AV	N/A
	Tru64	–	–	–	–	–	AV	N/A
	OpenVMS	–	–	–	–	–	–	AV
<p>*See About platforms supporting IPv6 on page 1-13.</p> <p>Legend:</p> <p>AV: Available for communicating with different platforms.</p> <p>N/A: Not applicable (Windows LH does not support IPv4 mapped IPv6).</p>								

Table 1-3 Supported Platforms: IPv4 vs IPv6

IPv4		CCI / IPv6*						
		HP-UX	Solaris	AIX	Windows	Linux	Tru64	OpenVMS
CCI / IPv4	HP-UX	AV	AV	AV	N/A	AV	AV	N/A
	Solaris	AV	AV	AV	N/A	AV	AV	N/A
	AIX	AV	AV	AV	N/A	AV	AV	N/A
	Windows	AV	AV	AV	N/A	AV	AV	N/A
	Linux	AV	AV	AV	N/A	AV	AV	N/A
	Tru64	AV	AV	AV	N/A	AV	AV	N/A
	OpenVMS	AV	AV	AV	N/A	AV	AV	AV
	IRIX64	AV	AV	AV	N/A	AV	AV	N/A
<p>*See About platforms supporting IPv6 on page 1-13.</p> <p>Legend:</p> <p>AV: Available for communicating with different platforms.</p> <p>N/A: Not applicable (Windows LH does not support IPv4 mapped IPv6).</p>								

Requirements and restrictions for z/Linux

In the following example, z/Linux defines the open volumes that are connected to FCP as /dev/sd*. Also, the mainframe volumes (3390-xx) that are connected to FICON are defined as /dev/dasd*.




Figure 1-1 Example of a CCI Configuration on z/Linux

The restrictions for using CCI with z/Linux are:

- **SSB information.** SSB information might not be displayed correctly.
- **Command device.** CCI uses a SCSI Path-through driver to access the command device. As such, the command device must be connected through FCP adaptors.
- **Open Volumes via FCP.** You can control the local and remote replication pair operations without any restrictions.
- **Mainframe (3390-9A) Volumes via FICON.** You cannot control the volumes (3390-9A) that are directly connected to FICON for ShadowImage pair operations. Also, mainframe volumes must be mapped to a CHF(FCP) port to access target volumes using a command device, as shown in [Figure 1-1 Example of a CCI Configuration on z/Linux on page 1-6](#). The mainframe volume does not have to be connected to an FCP adaptor.

ShadowImage supports only 3390-9A multiplatform volumes. TrueCopy does not support multiplatform volumes (including 3390-9A) via FICON.

- **Volume discovery via FICON.** The `inqraid` command discovers the FCP volume information by using SCSI inquiry. FICON volumes can be discovered only by using CCI to convert the mainframe interface (Read_device_characteristics or Read_configuration_data) to SCSI Inquiry. As such, the information that is required to run the `inqraid` command cannot be implemented, as shown in the following example.

```
sles8z:/HORCM/usr/bin# ls /dev/dasd* | ./inqraid
/dev/dasda -> [ST] Unknown Ser =      1920 LDEV =    4 [HTC      ]
[0704_3390_0A]
/dev/dasdaa -> [ST] Unknown Ser =    62724 LDEV =4120 [HTC      ]
```



```

[C018_3390_0A]
/dev/dasdab -> [ST] Unknown Ser = 62724 LDEV =4121 [HTC      ]
[C019_3390_0A]
sles8z:/HORCM/usr/bin# ls /dev/dasd* | ./inqraid -CLI
DEVICE_FILE      PORT      SERIAL  LDEV CTG  H/M/12  SSID R:Group
PRODUCT_ID
dasda             -          1920    4    -      -    00C0    -
0704_3390_0A
dasdaa           -          62724   4120  -      -    9810    -
C018_3390_0A
dasdab           -          62724   4121  -      -    9810    -
C019_3390_0A

```

The Inqraid command displays only five-digit number at the end of serial number of the FICON volume.

In the previous example, the Product_ID, C019_3390_0A, has the following associations:

- C019 indicates the Devno
- 3390 indicates the Dev_type
- 0A indicates the Dev_model

The following commands cannot be used because there is no PORT information:

- raidscan -pd <device>, raidar -pd <device>, raidvchkscan -pd <device>
- raidscan -find [conf], mkconf

Requirements and restrictions for VM

The following table lists the requirements and restrictions for VM vendors. A guest OS that is not supported by VM is not supported.

Table 1-4 VM vendor requirements and restrictions

VM Vendor	Layer	Volume Mapping	I/O interface
VMware ESX Server See Restrictions for VMware ESX Server on page 1-8 .	Guest	RDM*	Fibre
	SVC	Direct	Fibre
IBM AIX See Restrictions on AIX VIO on page 1-9 .	Client	Physical mode	Fibre
	Server	Direct	Fibre
Windows 2008 Hyper-V See Restrictions on Windows Hyper-V (Windows 2012/2008) on page 1-11 .	Child	Path-thru	Fibre
	Parent	Direct	Fibre
Oracle VM See Restrictions on Oracle VM on page 1-12 .	Guest	See Restrictions on Oracle VM on page 1-12	See Restrictions on Oracle VM on page 1-12

VM Vendor	Layer	Volume Mapping	I/O interface
HPVM	Guest	Mapping by NPIV	Fibre
*RDM: Raw Device Mapping using Physical Compatibility Mode.			

Restrictions for VMware ESX Server

Whether CCI (RM) runs or not depends on the support of guest OS by VMware. In addition, the guest OS depends on VMware support of virtual H/W (HBA). Therefore, the following guest OS and restrictions must be followed when using CCI on VMware.




Figure 1-2 CCI Configuration on Guest OS/VMware

The restrictions for using CCI with VMware are:

1. **Guest OS.** CCI needs to use guest OS that is supported by CCI, and also VMware supported guest OS (for example, Windows, Red Hat Linux). For specific support information, refer to the Hitachi Data Systems interoperability matrix: <http://www.hds.com/products/interoperability>
2. **Command device.** CCI uses SCSI path-through driver to access the command device. Therefore, the command device must be mapped as **Raw Device Mapping** using Physical Compatibility Mode. At least one command device must be assigned for each guest OS.
CCI (RM) instance numbers among different guest OS must be different, even if the command device is assigned for each guest OS, because the

command device cannot distinguish a difference among guest OS due to the same WWN as VMHBA.

3. **About invisible Lun.** Assigned Lun for the guest OS must be visible from SCSI Inquiry when VMware (host OS) is started. For example, the S-VOL on VSS is used as Read Only and Hidden, and this S-VOL is hidden from SCSI Inquiry. If VMware (host OS) is started on this volume state, the host OS will hang.
4. **Lun sharing between Guest and Host OS.** It is not supported to share a command device or a normal Lun between guest OS and host OS.
5. **About running on SVC.** The ESX Server 3.0 SVC (service console) is a limited distribution of Linux based on Red Hat Enterprise Linux 3, Update 6 (RHEL 3 U6). The service console provides an execution environment to monitor and administer the entire ESX Server host. The CCI user can run CCI by installing "CCI for Linux" on SVC. The volume mapping (/dev/sd) on SVC is a physical connection without converting SCSI Inquiry, so CCI will perform like running on Linux regardless of guest OS. However, VMware protects the service console with a firewall. According to current documentation, the firewall allows only PORT# 902,80,443,22(SSH) and ICMP(ping), DHCP, DNS as defaults, so the CCI user must enable a PORT for CCI (HORCM) using the "iptables" command.

Restrictions on AIX VIO

Whether CCI can function completely or not depends on how VIO client/server supports virtual HBA (vscsi), and there are some restrictions in the case of volume discovery. The following figure shows CCI configuration on an AIX VIO client.




Figure 1-3 CCI Configuration on VIO Client

The restrictions for using CCI on AIX VIO are:

1. **Command device.** CCI uses the SCSI Path-through driver for accessing the command device. Therefore, the command device must be mapped as RAW device of Physical Mapping Mode. At least one command device must be assigned for each VIO Client. The CCI instance numbers among different VIO Clients must be different, even if the command is assigned for each VIO Client, because the command device cannot distinguish between VIO Clients due to use of the same WWN via vscsi.
2. **LUN sharing between VIO Server and VIO Clients.** It is not possible to share a command device between VIO Server and VIO Clients, and a normal Lun also cannot be shared between VIO Server and VIO Clients.
3. **Volume discovery via vscsi on VIO Client.** The inqraid command discovers the volume information by using SCSI inquiry, but VIO Client cannot report the real SCSI inquiry (Page0 and Page83) as shown below.

Example for inqraid command:

```
lsdev -Cc disk | /HORCM/usr/bin/inqraid
hdisk0 -> NOT supported INQ.      [AIX   ] [VDASD   ]
hdisk1 -> NOT supported INQ.      [AIX   ] [VDASD   ]
hdisk2 -> NOT supported INQ.      [AIX   ] [VDASD   ]
:
:
hdisk19 -> NOT supported INQ.     [AIX   ] [VDASD   ]
```

The following commands discover the volumes by issuing SCSI inquiry. These commands cannot be used, because there is no port/LDEV for RAID information.

```

raidscan -pd <device>, raidar -pd <device>, raidvchkscan -pd
<device>
raidscan -find [conf] , mkconf.sh, inqraid
pairxxx -d[g] <device>, raidvchkdsp -d[g] <device>,
raidvchkset -d[g] <device>
\\.\CMD-Serial#-LDEV#-Port#:/dev/rhdisk on horcm.conf

```

Therefore, you need to know the volume mapping information (/dev/rhdisk) on the VIO Client by referring to the physical volume mapping through the VIO Server.

4. **About running on VIO Server.** The volume mapping (/dev/rhdisk) on a VIO Server is a physical connection without converting SCSI Inquiry, so CCI will perform as if running on AIX 5.3. However, IBM does not allow running applications in the VIO server. Since commands or scripts would have to be run outside the restricted shell, it might be necessary to get IBM approval to run in the VIO server. So you would have to change your scripts to run on a VIO server to issue the oem_setup_env command to access the non-restricted shell.

Restrictions on Windows Hyper-V (Windows 2012/2008)

Whether CCI can perform or not depends on the support of the guest OS by Windows Hyper-V, and then the guest OS depends on how Hyper-V supports front-end SCSI interfaces.




Figure 1-4 CCI Configuration on Hyper-V

The restrictions for using CCI on Hyper-V are as follows:

1. **Guest OS.** CCI needs to use the guest OS that is supported by CCI and also the Hyper-V supported guest OS (e.g., Windows Server 2008, SuSE Linux). For specific support information, refer to the Hitachi Data Systems interoperability matrix: <http://www.hds.com/products/interoperability>
2. **Command device.** CCI uses the SCSI path-through driver to access the command device. Therefore the command device must be mapped as RAW device of the path-through disk. At least one command device must be assigned for each guest OS (Child Partition).
The RM instance number among different guest OSs must be used as a different instance number even if the command is assigned for each guest OS. This is because the command device cannot distinguish a difference among the guest OSs because the same WWN via Fscsi is used.
3. **Lun sharing between guest OS and console OS.** It is not possible to share a command device as well as a normal Lun between a guest OS and a console OS.
4. **Running CCI on Console OS.** The console OS (management OS) is a limited Windows, like Windows 2008/2012 Server Core, and the Windows standard driver is used. Also the console OS provides an execution environment to monitor and administer the entire Hyper-V host.
Therefore, you can run CCI by installing "CCI for Windows NT" on the console OS. In that case, the CCI (RM) instance number between the console OS and the guest OS must be a different instance number, even if the command is assigned for each console and guest OS.

Restrictions on Oracle VM

Whether Command Control Interface runs or not, it depends on the guest OS supported by Oracle VM. The restrictions for using Command Control Interface with Oracle VM are:

- **Guest OS:** Command Control Interface must use the guest OS supported by Command Control Interface and the guest OS supported by Oracle VM.
- **Command device:** You cannot connect the command device of fibre channel directly to the guest OS. If you have to execute the command by an In-Band method, you must configure the system as shown in the figure below. In this configuration, Command Control Interface on the guest domain (RM#1 to RM#n) transfers the command to another Command Control Interface on the control domain (RM#0) by an Out-of-Band method. RM#0 executes the command by In-Band method, and then transfer the result to RM#1 to RM#n. RM#0 fulfills the same role as a virtual command device in the SVP/GUM/CCI server.




Figure 1-5 CCI configuration of Oracle VM

- Volumes on the guest OS must be mapped physically to the LDEVs on the disk machine.
- If you specify the system disk of OS as an object of copying, the OS might not start on the system disk of the copy destination.

About platforms supporting IPv6

Library and system call for IPv6

CCI uses the following functions of IPv6 library to get and convert from hostname to IPv6 address.

- IPv6 library to resolve hostname and IPv6 address:
 - `getaddrinfo()`
 - `inet_pton()`
 - `inet_ntop()`
- Socket System call to communicate using UDP/IPv6:
 - `socket(AF_INET6)`
 - `bind()`, `sendmsg()`, `sendto()`, `rcvmsg()`, `recvfrom()`...

If CCI links above function in the object(exe), a core dump might occur if an old platform (for example, Windows NT, HP-UX 10.20, Solaris 5) does not support it. So CCI links dynamically above functions by resolving the symbol after determining whether the shared library and function for IPv6 exists. It depends on supporting of the platform whether CCI can support IPv6 or not. If platform does not support IPv6 library, then CCI uses its own internal function corresponding to "`inet_pton()`,`inet_ntop()`"; in this case, IPv6 address is not allowed to describe hostname.




Figure 1-6 Library and System Call for IPv6

Environment variable

CCI loads and links the library for IPv6 by specifying a PATH as follows.

For Windows systems: **Ws2_32.dll**

For HP-UX (PA/IA) systems: **/usr/lib/libc.sl**

However, CCI might need to specify a different PATH to use the library for IPv6. After this consideration, CCI also supports the following environment variables for specifying a PATH:

- **\$IPV6_DLLPATH** (valid for only HP-UX, Windows): This variable is used to change the default PATH for loading the Library for IPv6. For example:
`export IPV6_DLLPATH=/usr/lib/hpux32/lib.so`
`horcmstart.sh 10`
- **\$IPV6_GET_ADDR**: This variable is used to change "AI_PASSIVE" value as default for specifying to the `getaddrinfo()` function for IPv6. For example:
`export IPV6_GET_ADDR=9`
`horcmstart.sh 10`

HORCM Start-Up Log

Support level of IPv6 feature depends on the platform and OS version. In certain OS platform environments, CCI cannot perform IPv6 communication completely, so CCI logs the results of whether the OS environment supports the IPv6 feature or not.

/HORCM/log/curlog/horcm_*HOST NAME*.log

```

*****
- HORCM STARTUP LOG - Fri Aug 31 19:09:24 2007
*****
19:09:24-cc2ec-02187- horcmgr started on Fri Aug 31 19:09:24 2007
  
```



```

:
:
19:09:25-3f3f7-02188- ***** starts Loading library for IPv6 *****
[ AF_INET6 = 26, AI_PASSIVE = 1 ]
19:09:25-47ca1-02188- dlsym() : Syml = 'getaddrinfo' : dlsym:
symbol "getaddrinfo" not found in "/etc/horcmgr"
getaddrinfo() : Unlinked on itself
inet_pton()    : Linked on itself
inet_ntop()    : Linked on itself
19:09:25-5ab3e-02188- ***** finished Loading library *****
:
HORCM set to IPv6 ( INET6 value = 26)
:

```

Porting notice for OpenVMS

In the OpenVMS, the system call on UNIX is supported as the functions of CRTL (C Run Time Library) on the user process. Also the CRTL for OpenVMS does not support the POSIX and POSIX Shell fully as does UNIX. In addition, CCI uses the UNIX domain socket for IPC (Inter Process Communication), but OpenVMS does not support the AF_UNIX socket. As an alternate method, CCI accomplishes IPC between CCI and HORCM daemon by using the Mailbox driver on OpenVMS.

Therefore, CCI has the following restrictions in porting for OpenVMS.

Requirements and restrictions for OpenVMS

(1) Version of OpenVMS

CCI uses the CRTL and needs the following version supported on the ROOT directory for POSIX.

- OpenVMS Version 8.3 or later
- CRTL version must be installed prior to running CCI. (I64VMS C V7.3-18 was used in testing.)

(2) Defining the SYS\$POSIX_ROOT

CCI requires that POSIX_ROOT is existing on the system, so you must define the POSIX_ROOT before running CCI. For example:

```
$ DEFINE/TRANSLATION=(CONCEALED,TERMINAL) SYS$POSIX_ROOT
"Device:[directory]"
```

where **Device:[directory]** is defined as SYS\$POSIX_ROOT

(3) IPC method using MailBox driver

As an alternate method of the UNIX domain socket for IPC (Inter Process Communication), CCI use the mailbox driver to enable the communication between CCI and HORCM.

Therefore, if CCI and HORCM are executing in different jobs (different terminal), then you must redefine **LNMT\$TEMPORARY_MAILBOX** in the **LNMT\$PROCESS_DIRECTORY** table as follows:

```
$ DEFINE/TABLE=LNMT$PROCESS_DIRECTORY LNMT$TEMPORARY_MAILBOX
LNMT$GROUP
```

(4) Start-up method for HORCM daemon

HORCM can start as the daemon process from a UNIX Shell. But in the case of 'vfork' of CRTL, if a parent process has exit() then a child process also ends at the same time. In other words, OpenVMS cannot make a daemon process from the POSIX program. Therefore, horcmstart.exe has been changed to wait until HORCM has been exiting by horcmshutdown.exe after start-up of the horcmgr. According to the rule for creating process in OpenVMS, to start-up the horcmstart.exe is to create the detached process or Batch JOB by using DCL command, as this method closely resembles the horcmd process on UNIX.

For example, using the Detached process:

If you want to have the HORCM daemon running in the background, you need to make the Detached LOGINOUT.EXE Process by using the 'RUN /DETACHED' command of the OpenVMS, and need to make the commands file for LOGINOUT.EXE.

The following are examples of "loginhorcm*.com" file given to SYS\$INPUT for LOGINOUT.EXE, and are examples that "**VMS4\$DKB100:[SYS0.SYSMGR.]**" was defined as SYS\$POSIX_ROOT.

loginhorcm0.com

```
$ DEFINE/TRANSLATION=(CONCEALED,TERMINAL) SYS$POSIX_ROOT
"VMS4$DKB100:[SYS0.SYSMGR.]"
$ DEFINE DCL$PATH SYS$POSIX_ROOT:[horcm.usr.bin],SYS$POSIX_ROOT:
[horcm.etc]
$ DEFINE/TABLE=LNMT$PROCESS_DIRECTORY LNMT$TEMPORARY_MAILBOX LNMT$GROUP
$ horcmstart 0
```

loginhorcm1.com

```
$ DEFINE/TRANSLATION=(CONCEALED,TERMINAL) SYS$POSIX_ROOT
"VMS4$DKB100:[SYS0.SYSMGR.]"
$ DEFINE DCL$PATH SYS$POSIX_ROOT:[horcm.usr.bin],SYS$POSIX_ROOT:
[horcm.etc]
$ DEFINE/TABLE=LNMT$PROCESS_DIRECTORY LNMT$TEMPORARY_MAILBOX LNMT$GROUP
$ horcmstart 1

$ run /DETACHED SYS$SYSTEM:LOGINOUT.EXE /PROCESS_NAME=horcm0 -
_$ /INPUT=VMS4$DKB100:[SYS0.SYSMGR.][horcm]loginhorcm0.com -
_$ /OUTPUT=VMS4$DKB100:[SYS0.SYSMGR.][horcm]run0.out -
_$ /ERROR=VMS4$DKB100:[SYS0.SYSMGR.][horcm]run0.err
%RUN-S-PROC_ID, identification of created process is 00004160
$
$
$$ run /DETACHED SYS$SYSTEM:LOGINOUT.EXE /PROCESS_NAME=horcm1 -
_$ /INPUT=VMS4$DKB100:[SYS0.SYSMGR.][horcm]loginhorcm1.com -
_$ /OUTPUT=VMS4$DKB100:[SYS0.SYSMGR.][horcm]run1.out -
_$ /ERROR=VMS4$DKB100:[SYS0.SYSMGR.][horcm]run1.err
%RUN-S-PROC_ID, identification of created process is 00004166
```

You can also verify that HORCM daemon is running as Detached Process by using 'SHOW PROCESS' command.

```
$ show process horcm0
25-MAR-2003 23:27:27.72    User: SYSTEM                Process ID:
00004160
                                Node: VMS4                Process name:

"HORCM0"
Terminal:
User Identifier:    [SYSTEM]
Base priority:      4
Default file spec:  Not available
Number of Kthreads: 1
Soft CPU Affinity: off
$$ horcmshutdown 0 1
inst 0:
HORCM Shutdown inst 0 !!!
inst 1:
HORCM Shutdown inst 1 !!!
$
```

(5) Command device

CCI uses the SCSI class driver for accessing the command device on the 9900V, because OpenVMS does not provide the raw I/O device such as UNIX, and defines "DG*,DK*,GK*" as the logical name for the device. The SCSI class driver requires the following privileges: DIAGNOSE and PHY_IO or LOG_IO (for details see the OpenVMS manual).

In CCI version 01-12-03/03 or earlier, you need to define the Physical device as either DG* or DK* or GK* by using DEFINE/SYSTEM command. For example:

```
$ show device
Device          Device  Error   Volume   Free  Trans Mnt
Name            Status  Count   Label    Blocks Count Cnt
VMS4$DKB0:      Online    0
VMS4$DKB100:    Mounted    0    ALPHASYS 30782220   414   1
VMS4$DKB200:    Online    0
VMS4$DKB300:    Online    0
VMS4$DQA0:      Online    0
$1$DGA145: (VMS4) Online    0
$1$DGA146: (VMS4) Online    0
:
:
$1$DGA153: (VMS4) Online    0
$ DEFINE/SYSTEM DKA145 $1$DGA145:
$ DEFINE/SYSTEM DKA146 $1$DGA146:
:
:
$ DEFINE/SYSTEM DKA153 $1$DGA153:
```

(6) -zx option for CCI commands

The -zx option for CCI commands uses the select() function to wait for an event from STDIN. But the OpenVMS select() function does not support any wait events from STDIN, and select() for terminal(STDIN) is unable to echo back the terminal input.

Therefore, the -zx option for CCI commands is not supported, and is deleted from the Help & Usage display for the -zx option.

(7) Syslog function

The OpenVMS does not support the syslog function as does UNIX. Therefore, CCI does not support the syslog function. An alternative is to use the HORCM logging file for HORCM daemon.

(8) Start up log files

In start up of HORCM, CCI does share a start up log file by two process for start-up, but CRTL does not work correctly to share from two processes.

As workaround, CCI has two start-up log files separated by using PID as follows.

For example, under the SYS\$POSIX_ROOT:[HORCM.LOG*.CURLOG] directory:

```
HORCMLOG_VMS4 HORCM_VMS4_10530.LOG HORCM_VMS4_10531.LOG
```

(9) Option syntax and Case sensitivity

VMS users are not accustomed to commands being case sensitive and using option syntax, as on UNIX. Therefore, CCI changes "case sensitivity" and "-xxx" syntax for options in order to match the expectations of VMS users as much as possible. CCI allows "/xxx" syntax for options as well as "-xxx" option, but this is a minor option.

The followings upper-case strings are not case sensitive:

- **DG* or DK* or GK* for Logical Device Name**
- **-CLI or -FCA(-FHORC) or -FBC(-FMRCF) for the pair* command options**
- **-CLI or -CLIWP or -CLIWN or -CM for the inqraid options**
- **Environmental variable name such as HORCMINST ... controlled by CRTL**

Also you need to define the following logical name to your **login.com** in order to distinguish the uppercase and the lowercase:

```
$ DEFINE DECC$ARGV_PARSE_STYLE ENABLE$ SET PROCESS/  
PARSE_STYLE=EXTENDED
```

(10) Regarding using spawn command

You can also start the HORCM process easily by using the spawn command. The following examples used SPAWN command on DCL.

For example, using spawn:

```
$ spawn /NOWAIT /PROCESS=horcm0 horcmstart 0  
%DCL-S-SPAWNED, process HORCM0 spawned  
$  
    starting HORCM inst 0
```

```
$ spawn /NOWAIT /PROCESS=horcm1 horcmstart 1
%DCL-S-SPAWNED, process HORCM1 spawned
$
    starting HORCM inst 1
$
```

The subprocess (HORCM) created by SPAWN is terminated when the terminal is LOGOFF or the session is terminated. If you want independence Process to the terminal LOGOFF, then use the "RUN /DETACHED" command.

(11) Privileges for using CCI

- **A user account for CCI must have the same privileges as "SYSTEM" that can use the SCSI Class driver and Mailbox driver directly.**

Some OpenVMS system administrators might not allow CCI to run from the system account (equivalent to root on UNIX). Therefore, create another CCI account on the system, such as "RMadmin," that has the equivalent privileges to "SYSTEM". In this way, it is not necessary for system administrators to share the system passwords.

- **CCI uses the Mailbox driver to enable communication between CCI and HORCM. Therefore, CCI and HORCM must have the same privileges.**

If CCI and HORCM are executing in different privileges (different user), then CCI hangs or is unable to attach to HORCM because CCI and HORCM are denied communication through the Mailbox.

(12) Installation

CCI is provided a file for installing, for example the following PCSI (PolyCenter Software Installation) file.

- HITACHI-ARMVMS-RM-V0122-2-1.PCSI - HITACHI-I64VMS-RM-V0122-2-1.PCSI

CCI also requires that **POSIX_ROOT** be on the system, so you must define the **POSIX_ROOT** before installing CCI.

It is recommended that you previously define the three logical names shown below for CCI in LOGIN.COM.

```
$ DEFINE/TRANSLATION=(CONCEALED,TERMINAL) SYS$POSIX_ROOT "Device:
[directory]"
$ DEFINE DCL$PATH SYS$POSIX_ROOT:[horcm.usr.bin],SYS$POSIX_ROOT:
[horcm.etc]
$ DEFINE/TABLE=LNМ$PROCESS_DIRECTORY LNМ$TEMPORARY_MAILBOX LNМ$GROUP
$ DEFINE DECC$ARGV_PARSE_STYLE ENABLE
$ SET PROCESS/PARSE_STYLE=EXTENDED
```

where **Device:[directory]** is defined as SYS\$POSIX_ROOT

For Installing:

```
$ PRODUCT INSTALL RM /source=Device:[directory]/LOG -
    $ /destination=SYS$POSIX_ROOT:[000000]
    Device:[directory] where HITACHI-ARMVMS-RM-V0122-2-1.PCSI exists
:
```

```

:
$ PRODUCT SHOW PRODUCT RM
-----
PRODUCT                                KIT TYPE    STATE
-----
HITACHI ARMVMS RM V1.22-2              Full LP      Installed
-----

$ raidqry -h
Model   : RAID-Manager/OpenVMS
Ver&Rev: 01-29-03/05
:
:

```

For Installation history:

```
$ PRODUCT SHOW HISTORY RM /FULL
```

For removing :

```
$ PRODUCT REMOVE RM /LOG
```

(13) About exit code of the command on DCL

CCI return codes are the same for all platforms. However, if the process was invoked by the DCL, the status is interpreted by DCL and a message appears as below.

```

-----on DCL of OpenVMS-----
$ pairdisplay jjj
PAIRDISPLAY: requires '-jjj' or '/jjj' as argument
PAIRDISPLAY: [EX_REQARG] Required Arg list
Refer to the command log(SYS$POSIX_ROOT:[HORCM.LOG]HORCC_RMOVMS.LOG
(/HORCM/log/horcc_rmovms.log)) for details.
$ sh sym $status
  $STATUS == "%X0035A7F1"
$
$ pairdisplay -g aaa
PAIRDISPLAY: [EX_ATTHOR] Can't be attached to HORC manager
Refer to the command log(SYS$POSIX_ROOT:[HORCM.LOG]HORCC_RMOVMS.LOG
(/HORCM/log/horcc_rmovms.log)) for details.
$ sh sym $status
  $STATUS == "%X0035A7D9"
-----on DCL of OpenVMS-----

```

You can calculate the CCI "Exit code" from \$status of DCL using the formula below.

```
Exit code of RM command = ( $status % 2048 ) / 8
```

Known issues

Rebooting on PAIR state (Writing disable)

OpenVMS does not show the volumes of writing disable (for example, SVOL_PAIR) at start-up of system, therefore the S-VOLs are hidden when rebooting in PAIR state or SUSPEND(read only) mode. You are able to verify that the "show device" and "inqraid" command does not show the S-VOLs after reboot as below (notice that **DGA148** and **DGA150** devices are SVOL_PAIR).

```

$ sh dev dg
Device                               Device      Error      Volume   Free   Trans  Mnt
  Name                               Status      Count      Label   Blocks Count  Cnt
$1$DGA145:   (VMS4) Online          0
$1$DGA146:   (VMS4) Online          0
$1$DGA147:   (VMS4) Online          0
$1$DGA149:   (VMS4) Online          0
$1$DGA151:   (VMS4) Online          0
$1$DGA152:   (VMS4) Online          0
$1$DGA153:   (VMS4) Online          0

$ inqraid DKA145-153 -cli
DEVICE_FILE  PORT  SERIAL  LDEV CTG  H/M/12  SSID  R:Group  PRODUCT_ID
DKA145       CL1-H  30009   145  -    -      -    -    OPEN-9-CM
DKA146       CL1-H  30009   146  -    s/P/ss 0004  5:01-11 OPEN-9
DKA147       CL1-H  30009   147  -    s/S/ss 0004  5:01-11 OPEN-9
DKA148      -      -      -    -    -      -    -    -
DKA149       CL1-H  30009   149  -    P/s/ss 0004  5:01-11 OPEN-9
DKA150      -      -      -    -    -      -    -    -
DKA151       CL1-H  30009   151  -    P/s/ss 0004  5:01-11 OPEN-9
DKA152       CL1-H  30009   152  -    s/s/ss 0004  5:01-11 OPEN-9
DKA153       CL1-H  30009   153  -    s/s/ss 0004  5:01-11 OPEN-9
$ inqraid DKA148
sys$assign : DKA148 -> errcode = 2312
DKA148 -> OPEN: no such device or address

```

After making the S-VOL for Writing enable by using **"pairsplit"** or **"horctakeover"** command, you need to perform the **"mcr sysman"** command in order to use the S-VOLs for back-up or disaster recovery.

```

$ pairsplit -g CAVG -rw
$ mcr sysman
SYSMAN> io auto
SYSMAN> exit
$ sh dev dg
Device                               Device      Error      Volume   Free   Trans  Mnt
  Name                               Status      Count      Label   Blocks Count  Cnt
$1$DGA145:   (VMS4) Online          0
$1$DGA146:   (VMS4) Online          0
$1$DGA147:   (VMS4) Online          0
$1$DGA148:   (VMS4) Online          0
$1$DGA149:   (VMS4) Online          0
$1$DGA150:   (VMS4) Online          0
$1$DGA151:   (VMS4) Online          0
$1$DGA152:   (VMS4) Online          0
$1$DGA153:   (VMS4) Online          0

```

Startup procedures using detached process on DCL

(1) Create the shareable Logical name for RAID if undefined initially.

CCI needs to define the physical device (**\$1\$DGA145...**) as either DG* or DK* or GK* by using SHOW DEVICE command and **DEFINE/SYSTEM** command, but then does not need to be mounted in CCI version 01-12-03/03 or earlier.

```

$ show device
Device                               Device      Error      Volume   Free   Trans  Mnt
  Name                               Status      Count      Label   Blocks Count  Cnt

```

```

$1$DGA145:      (VMS4) Online      0
$1$DGA146:      (VMS4) Online      0
:
:
$1$DGA153:      (VMS4) Online      0
$
$ DEFINE/SYSTEM DKA145 $1$DGA145:
$ DEFINE/SYSTEM DKA146 $1$DGA146:
:
:
$ DEFINE/SYSTEM DKA153 $1$DGA153:

```

(2) Define the CCI environment in LOGIN.COM.

You need to define the Path for the CCI commands to **DCL\$PATH** as the foreign command. See the section about Automatic Foreign Commands in the OpenVMS user documentation.

```

$ DEFINE DCL$PATH SYS$POSIX_ROOT:[horcm.usr.bin],SYS$POSIX_ROOT:
[horcm.etc]

```

If CCI and HORCM are executing in different jobs (different terminal), then you must redefine **LNМ\$TEMPORARY_MAILBOX** in the LNM \$PROCESS_DIRECTORY table as follows:

```

$ DEFINE/TABLE=LNМ$PROCESS_DIRECTORY LNМ$TEMPORARY_MAILBOX LNМ$GROUP

```

(3) Discover and describe the command device on SYS\$POSIX_ROOT: [etc]horcm0.conf.

```

$ ingraid DKA145-151 -CLI
DEVICE_FILE PORT  SERIAL LDEV CTG H/M/12 SSID R:Group  PRODUCT_ID
DKA145      CL1-H   30009 145  -    -    -    -    -    OPEN-9-CM
DKA146       CL1-H   30009  146  -  s/S/ss 0004 5:01-11  OPEN-9
DKA147       CL1-H   30009  147  -  s/P/ss 0004 5:01-11  OPEN-9
DKA148       CL1-H   30009  148  -  s/S/ss 0004 5:01-11  OPEN-9
DKA149       CL1-H   30009  149  -  s/P/ss 0004 5:01-11  OPEN-9
DKA150       CL1-H   30009  150  -  s/S/ss 0004 5:01-11  OPEN-9
DKA151       CL1-H   30009  151  -  s/P/ss 0004 5:01-11  OPEN-9
SYS$POSIX_ROOT:[etc]horcm0.conf
HORCM_MON
#ip_address      service      poll(10ms)      timeout(10ms)
127.0.0.1        30001        1000            3000
HORCM_CMD
#dev_name        dev_name      dev_name
DKA145

```

You will have to start HORCM without a description for HORCM_DEV and HORCM_INST because the target ID & LUN are Unknown.

You can determine a mapping of a physical device with a logical name easily by using the **raidscan -find** command option.

(4) Execute an 'horcmstart 0'.

```

$ run /DETACHED SYS$SYSTEM:LOGINOUT.EXE /PROCESS_NAME=horcm0 -
_$ /INPUT=VMS4$DKB100:[SYS0.SYSMGR.][horcm]loginhorcm0.com -
_$ /OUTPUT=VMS4$DKB100:[SYS0.SYSMGR.][horcm]run0.out -
_$ /ERROR=VMS4$DKB100:[SYS0.SYSMGR.][horcm]run0.err
%RUN-S-PROC_ID, identification of created process is 00004160

```

(5) Verify a physical mapping of the logical device.


```

$ HORCMINST := 0
$ raidscan -pi DKA145-151 -find
DEVICE_FILE      UID  S/F  PORT  TARG  LUN  SERIAL  LDEV  PRODUCT_ID
DKA145           0   F   CL1-H  0     1   30009   145   OPEN-9-CM
DKA146           0   F   CL1-H  0     2   30009   146   OPEN-9
DKA147           0   F   CL1-H  0     3   30009   147   OPEN-9
DKA148           0   F   CL1-H  0     4   30009   148   OPEN-9
DKA149           0   F   CL1-H  0     5   30009   149   OPEN-9
DKA150           0   F   CL1-H  0     6   30009   150   OPEN-9
DKA151           0   F   CL1-H  0     7   30009   151   OPEN-9
$ horcmshutdown 0
inst 0:
HORCM Shutdown inst 0 !!!

```

(6) Describe the known HORCM_DEV on SYS\$POSIX_ROOT: [etc]horcm*.conf

For horcm0.conf

```

HORCM_DEV
#dev_group      dev_name      port#      TargetID      LU#      MU#
VG01            oradb1        CL1-H      0              2         0
VG01            oradb2        CL1-H      0              4         0
VG01            oradb3        CL1-H      0              6         0
HORCM_INST
#dev_group      ip_address      service
VG01            HOSTB           horcm1

```

For horcm1.conf

```

HORCM_DEV
#dev_group      dev_name      port#      TargetID      LU#      MU#
VG01            oradb1        CL1-H      0              3         0
VG01            oradb2        CL1-H      0              5         0
VG01            oradb3        CL1-H      0              7         0
HORCM_INST
#dev_group      ip_address      service
VG01            HOSTA           horcm0

```

Defines the UDP port name for HORCM communication in the **SYS**
\$SYSROOT:[000000.TCPIP\$ETC]SERVICES.DAT file, as in the example
below.

```
horcm0 30001/udp horcm1 30002/udp
```

(7) Start **horcm0** and **horcm1** as the Detached process.

```

$ run /DETACHED SYS$SYSTEM:LOGINOUT.EXE /PROCESS_NAME=horcm0 -
_$ /INPUT=VMS4$DKB100:[SYS0.SYSMGR.] [horcm] loginhorcm0.com -
_$ /OUTPUT=VMS4$DKB100:[SYS0.SYSMGR.] [horcm] run0.out -
_$ /ERROR=VMS4$DKB100:[SYS0.SYSMGR.] [horcm] run0.err
%RUN-S-PROC_ID, identification of created process is 00004160
$
$$ run /DETACHED SYS$SYSTEM:LOGINOUT.EXE /PROCESS_NAME=horcm1 -
_$ /INPUT=VMS4$DKB100:[SYS0.SYSMGR.] [horcm] loginhorcm1.com -
_$ /OUTPUT=VMS4$DKB100:[SYS0.SYSMGR.] [horcm] run1.out -
_$ /ERROR=VMS4$DKB100:[SYS0.SYSMGR.] [horcm] run1.err
%RUN-S-PROC_ID, identification of created process is 00004166

```

You can verify that HORCM daemon is running as Detached Process by using
the **SHOW PROCESS** command.

```

$ show process horcm0
25-MAR-2003 23:27:27.72 User: SYSTEM      Process ID: 0004160
                        Node: VMS4        Process name: "HORCM0"

Terminal:
User Identifier:      [SYSTEM]
Base priority:        4
Default file spec:    Not available
Number of Kthreads:   1

Soft CPU Affinity: off

```

Command examples in DCL

(1) Setting the environment variable by using Symbol.

```

$ HORCMINST := 0 $ HORCC_MRCF := 1
$ raidqry -l
No Group      Hostname      HORCM ver      Uid  Serial#  Micro_ver  Cache(MB)
1 ---        VMS4          01-29-03/05     0    30009   50-04-00/00   8192
$
$ pairedisplay -g VG01 -fdc
Group PairVol(L/R) Device_File M,Seq#,LDEV#.P/S,Status, % ,P-LDEV# M
VG01 oradb1(L)   DKA146    0 30009  146..S-VOL PAIR, 100 147 -
VG01 oradb1(R)   DKA147    0 30009  147..P-VOL PAIR, 100 146 -
VG01 oradb2(L)   DKA148    0 30009  148..S-VOL PAIR, 100 149 -
VG01 oradb2(R)   DKA149    0 30009  149..P-VOL PAIR, 100 148 -
VG01 oradb3(L)   DKA150    0 30009  150..S-VOL PAIR, 100 151 -
VG01 oradb3(R)   DKA151    0 30009  151..P-VOL PAIR, 100 150 -
$

```

(2) Removing the environment variable.

```

$ DELETE/SYMBOL HORCC_MRCF
$ pairedisplay -g VG01 -fdc
Group PairVol(L/R) Device_File ,Seq#,LDEV#.P/S,Status,Fence, % ,P-
LDEV# M
VG01 oradb1(L)   DKA146    30009 146..SMPL ---- -,-----,----- ---- -
VG01 oradb1(R)   DKA147    30009 147..SMPL ---- -,-----,----- ---- -
VG01 oradb2(L)   DKA148    30009 148..SMPL ---- -,-----,----- ---- -
VG01 oradb2(R)   DKA149    30009 149..SMPL ---- -,-----,----- ---- -
VG01 oradb3(L)   DKA150    30009 150..SMPL ---- -,-----,----- ---- -
VG01 oradb3(R)   DKA151    30009 151..SMPL ---- -,-----,----- ---- -
$

```

(3) Changing the default log directory.

```

$ HORCC_LOG := /horcm/horcm/TEST
$ pairedisplay
PAIRDISPLAY: requires '-x xxx' as argument
PAIRDISPLAY: [EX_REQARG] Required Arg list
Refer to the command log(SYS$POSIX_ROOT:
[HORCM.HORCM.TEST]HORCC VMS4.LOG (/HORCM
/HORCM/TEST/horcc_VMS4.log)) for details.

```

(4) Turning back to the default log directory.

```

$ DELETE/SYMBOL HORCC_LOG

```

(5) Specifying the device described in scandev.LIS.

```

$ define dev_file SYS$POSIX_ROOT:[etc]SCANDEV
$ type dev_file
DKA145-150

```

```
$
$ pipe type dev_file | inqraid -CLI
DEVICE_FILE  PORT  SERIAL LDEV CTG H/M/12 SSID R:Group PRODUCT_ID
DKA145       CL1-H  30009  145  -      -      -      -      -      OPEN-9-CM
DKA146       CL1-H  30009  146  -  s/S/ss 0004 5:01-11 OPEN-9
DKA147       CL1-H  30009  147  -  s/P/ss 0004 5:01-11 OPEN-9
DKA148       CL1-H  30009  148  -  s/S/ss 0004 5:01-11 OPEN-9
DKA149       CL1-H  30009  149  -  s/P/ss 0004 5:01-11 OPEN-9
DKA150       CL1-H  30009  150  -  s/S/ss 0004 5:01-11 OPEN-9
```

(6) Making the configuration file automatically.

You can omit steps from (3) to (6) on the Start-up procedures by using the **mkconf** command.

```
$ type dev_file
DKA145-150
$
$ pipe type dev_file | mkconf -g URA -i 9
starting HORCM inst 9
HORCM Shutdown inst 9 !!!
A CONFIG file was successfully completed.
HORCM inst 9 finished successfully.
starting HORCM inst 9
DEVICE_FILE  Group  PairVol  PORT  TARG  LUN M  SERIAL  LDEV
DKA145       -      -      -      -      -  -  30009  145
DKA146       URA  URA_000  CL1-H  0      2  0  30009  146
DKA147       URA  URA_001  CL1-H  0      3  0  30009  147
DKA148       URA  URA_002  CL1-H  0      4  0  30009  148
DKA149       URA  URA_003  CL1-H  0      5  0  30009  149
DKA150       URA  URA_004  CL1-H  0      6  0  30009  150
HORCM Shutdown inst 9 !!!
Please check 'SYS$SYSROOT:[SYSMGR]HORCM9.CONF', 'SYS$SYSROOT:
[SYSMGR.LOG9.CURLOG]
HORCM*.LOG', and modify 'ip_address & service'.
HORCM inst 9 finished successfully.
$
SYS$SYSROOT:[SYSMGR]horcm9.conf (/sys$sysroot/sysmgr/horcm9.conf)
```

```
# Created by mkconf on Thu Mar 13 20:08:41
```

```
HORCM_MON
#ip_address      service      poll(10ms)      timeout(10ms)
127.0.0.1        52323          1000             3000
```

```
HORCM_CMD
#dev_name      dev_name      dev_name
#UnitID 0 (Serial# 30009)
DKA145
```

```
# ERROR [CMDDEV] DKA145          SER =      30009  LDEV =  145
[ OPEN-9-CM `
```

```
HORCM_DEV
#dev_group  dev_name      port#      TargetID      LU#      MU#
# DKA146    SER =      30009  LDEV =  146 [ FIBRE FCTBL = 3 ]
URA        URA_000      CL1-H      0             2         0
# DKA147    SER =      30009  LDEV =  147 [ FIBRE FCTBL = 3 ]
URA        URA_001      CL1-H      0             3         0
# DKA148    SER =      30009  LDEV =  148 [ FIBRE FCTBL = 3 ]
URA        URA_002      CL1-H      0             4         0
# DKA149    SER =      30009  LDEV =  149 [ FIBRE FCTBL = 3 ]
```

```

URA          URA_003          CL1-H          0          5          0
# DKA150      SER =          30009 LDEV = 150 [ FIBRE FCTBL = 3 ]
URA          URA_004          CL1-H          0          6          0

HORCM_INST
#dev_group    ip_address      service
URA          127.0.0.1      52323

```

(7) Using \$1\$* naming as native device name.

You can use the native device without DEFINE/SYSTEM command by specifying \$1\$* naming directly.

```

$ ingraid $1$DGA145-155 -CLI
DEVICE_FILE  PORT  SERIAL LDEV CTG H/M/12 SSID R:Group PRODUCT_ID
$1$DGA145    CL2-H  30009  145  -   -   -   -   - OPEN-9-CM
$1$DGA146    CL2-H  30009  146  - s/P/ss 0004 5:01-11 OPEN-9
$1$DGA147    CL2-H  30009  147  - s/S/ss 0004 5:01-11 OPEN-9
$1$DGA148    CL2-H  30009  148  0 P/s/ss 0004 5:01-11 OPEN-9

$ pipe show device | INQRAID -CLI
DEVICE_FILE  PORT  SERIAL LDEV CTG H/M/12 SSID R:Group PRODUCT_ID
$1$DGA145    CL2-H  30009  145  -   -   -   -   - OPEN-9-CM
$1$DGA146    CL2-H  30009  146  - s/P/ss 0004 5:01-11 OPEN-9
$1$DGA147    CL2-H  30009  147  - s/S/ss 0004 5:01-11 OPEN-9
$1$DGA148    CL2-H  30009  148  0 P/s/ss 0004 5:01-11 OPEN-9

$ pipe show device | MKCONF -g URA -i 9
starting HORCM inst 9
HORCM Shutdown inst 9 !!!
A CONFIG file was successfully completed.
HORCM inst 9 finished successfully.
starting HORCM inst 9
DEVICE_FILE  Group  PairVol  PORT  TARG  LUN M  SERIAL  LDEV
$1$DGA145    -      -      -      -      -  -   30009  145
$1$DGA146    URA    URA_000  CL2-H  0      2  0   30009  146
$1$DGA147    URA    URA_001  CL2-H  0      3  0   30009  147
$1$DGA148    URA    URA_002  CL2-H  0      4  0   30009  148
HORCM Shutdown inst 9 !!!
Please check 'SYS$SYSROOT:[SYSMGR]HORCM9.CONF', 'SYS$SYSROOT:
[SYSMGR.LOG9.CURLOG]
HORCM *.LOG', and modify 'ip_address & service'.
HORCM inst 9 finished successfully.
$

$ pipe show device | RAIDSCAN -find
DEVICE_FILE  UID  S/F PORT  TARG  LUN  SERIAL  LDEV  PRODUCT_ID
$1$DGA145    0   F  CL2-H  0      1   30009  145  OPEN-9-CM
$1$DGA146    0   F  CL2-H  0      2   30009  146  OPEN-9
$1$DGA147    0   F  CL2-H  0      3   30009  147  OPEN-9
$1$DGA148    0   F  CL2-H  0      4   30009  148  OPEN-9

$ pairdisplay -g BCFG -fdc
Group PairVol(L/R) Device_File M ,Seq#,LDEV#..P/S,Status, % ,P-LDEV#
M
BCVG oradb1(L) $1$DGA146 0 30009 146..P-VOL PAIR, 100 147 -
BCVG oradb1(R) $1$DGA147 0 30009 147..S-VOL PAIR, 100 146 -
$
$ pairdisplay -dg $1$DGA146
Group PairVol(L/R) (Port#,TID, LU-M) ,Seq#,LDEV#..P/S,Status, Seq#,P-
LDEV# M

```

```
BCVG oradb1 (L) (CL1-H,0, 2-0) 30009 146..P-VOL PAIR, 30009 147 -
BCVG oradb1 (R) (CL1-H,0, 3-0) 30009 47..S-VOL PAIR, ----- 146 -
$
```

Start-up procedures in bash

Do not use CCI through the bash, because the bash is not provided as an official release in OpenVMS.

(1) Create the shareable Logical name for RAID if undefined initially.

You need to define the Physical device (**\$1\$DGA145...**) as either DG* or DK* or GK* by using the SHOW DEVICE command and the **DEFINE/SYSTEM** command, but then it does not need to be mounted.

```
$ show device
Device
Name
$1$DGA145: (VMS4) Online
$1$DGA146: (VMS4) Online
:
:
$1$DGA153: (VMS4) Online
$$ DEFINE/SYSTEM DKA145 $1$DGA145:
$ DEFINE/SYSTEM DKA146 $1$DGA146:
:
:
$ DEFINE/SYSTEM DKA153 $1$DGA153:
```

(2) Define the CCI environment in LOGIN.COM.

If CCI and HORCM are executing in different jobs (different terminal), then you must redefine **LNМ\$TEMPORARY_MAILBOX** in the LNM \$PROCESS_DIRECTORY table as follows:

```
$ DEFINE/TABLE=LNМ$PROCESS_DIRECTORY LNM
$TEMPORARY_MAILBOX LNM$GROUP
```

(3) Discover and describe the command device on /etc/horcm0.conf.

```
bash$ inqraid DKA145-151 -CLI
DEVICE_FILE PORT SERIAL LDEV CTG H/M/12 SSID R:Group PRODUCT_ID
DKA145 CL1-H 30009 145 - s/S/ss 0004 5:01-11 OPEN-9-CM
DKA146 CL1-H 30009 146 - s/S/ss 0004 5:01-11 OPEN-9
DKA147 CL1-H 30009 147 - s/P/ss 0004 5:01-11 OPEN-9
DKA148 CL1-H 30009 148 - s/S/ss 0004 5:01-11 OPEN-9
DKA149 CL1-H 30009 149 - s/P/ss 0004 5:01-11 OPEN-9
DKA150 CL1-H 30009 150 - s/S/ss 0004 5:01-11 OPEN-9
DKA151 CL1-H 30009 151 - s/P/ss 0004 5:01-11 OPEN-9
```

/etc/horcm0.conf

```
HORCM_MON
#ip_address service poll(10ms) timeout(10ms)
127.0.0.1 52000 1000 3000

HORCM_CMD
#dev_name dev_name dev_name
DKA145

HORCM_DEV
```

```

#dev_group      dev_name      port#      TargetID      LU#      MU#

HORCM_INST
#dev_group      ip_address      service

```

You will have to start HORCM without a description for HORCM_DEV and HORCM_INST **because target ID & Lun are Unknown.**

You can determine a mapping of a physical device with a logical name easily by using the **raidscan -find** command option.

(4) Execute an 'horcmstart 0' as background.

```

bash$ horcmstart 0 &
18
bash$
    starting HORCM inst 0

```

(5) Verify a physical mapping of the logical device.

```

bash$ export HORCMINST=0
bash$ raidscan -pi DKA145-151 -find
DEVICE_FILE      UID      S/F      PORT      TARG      LUN      SERIAL      LDEV      PRODUCT_ID
DKA145            0        F        CL1-H      0         1        30009      145      OPEN-9-CM
DKA146            0        F        CL1-H      0         2        30009      146      OPEN-9
DKA147            0        F        CL1-H      0         3        30009      147      OPEN-9
DKA148            0        F        CL1-H      0         4        30009      148      OPEN-9
DKA149            0        F        CL1-H      0         5        30009      149      OPEN-9
DKA150            0        F        CL1-H      0         6        30009      150      OPEN-9
DKA151            0        F        CL1-H      0         7        30009      151      OPEN-9

```

(6) Describe the known HORCM_DEV on /etc/horcm*.conf.

FOR horcm0.conf

```

HORCM_DEV
#dev_group      dev_name      port#      TargetID      LU#      MU#
VG01            oradb1        CL1-H      0             2         0
VG01            oradb2        CL1-H      0             4         0
VG01            oradb3        CL1-H      0             6         0
HORCM_INST
#dev_group      ip_address      service
VG01            HOSTB          horcm1

```

FOR horcm1.conf

```

HORCM_DEV
#dev_group      dev_name      port#      TargetID      LU#      MU#
VG01            oradb1        CL1-H      0             3         0
VG01            oradb2        CL1-H      0             5         0
VG01            oradb3        CL1-H      0             7         0
HORCM_INST
#dev_group      ip_address      service
VG01            HOSTA          horcm0

```

(7) Start 'horcmstart 0 1'.

The subprocess(HORCM) created by bash is terminated when the bash is EXIT.

```

bash$ horcmstart 0 &
19
bash$
    starting HORCM inst 0

```

```

bash$ horcmstart 1 &
20
bash$
    starting HORCM inst 1

```

Using CCI with Hitachi and other storage systems

[Table 1-5 Relationship between CCI and RAID Storage System on page 1-29](#) shows the related two controls between CCI and the RAID storage system type (Hitachi or HP). [Figure 1-7 Relationship between application, CCI, and storage system on page 1-30](#) shows the relationship between the application, CCI, and RAID storage system.

- The following common API/CLI commands are rejected with EX_ERPERM(*1) by connectivity of CCI with RAID storage system:


```

horctakeover
paircurchk
paircreate
pairsplit
pairresync
pairvolchk
pairevtwait
pairstisplay
raidscan (-find option only)
raidar
raidvchkset
raidvchkdsp
raidvchkscan

```
- The following XP API/CLI commands are rejected with EX_ERPERM(*2) on the storage system even when both CCI and RAID Manager XP (provided by HP) are installed:


```

pairvolchk -s
pairstisplay -CLI
raidscan -CLI
paircreate -m noread for TrueCopy/TrueCopy Async/Universal Replicator
paircreate -m dif/inc for ShadowImage

```

Table 1-5 Relationship between CCI and RAID Storage System

Version	Installation Order	RAID System	Common API/CLI	XP API/CLI
CCI 01-08-03/00 or higher	CCI	Hitachi	Enable	Cannot use (except CLI)
		HP	EX_ERPERM	

Version	Installation Order	RAID System	Common API/CLI	XP API/CLI
RAID Manager XP 01.08.00 or higher (provided by HP)	Install CCI after installing RAID Manager XP	Hitachi	Enable	
		HP	Enable	
	RAID Manager XP	HP	Enable	Enable
		Hitachi	EX_ERPERM	EX_ERPERM
	Install RAID Manager XP after installing CCI	HP	Enable	Enable
		Hitachi	Enable	EX_ERPERM




Figure 1-7 Relationship between application, CCI, and storage system

Installing and configuring CCI

This chapter describes and provides instructions for installing and configuring CCI.

- ☐ [Installing the CCI hardware](#)
- ☐ [Installing the CCI software](#)
- ☐ [In-band and out-of-band operations](#)
- ☐ [Setting the command device](#)
- ☐ [Creating/editing the configuration definition file](#)

Installing the CCI hardware

Installation of the hardware required for CCI is performed by the user and the HDS representative. To install the hardware required for CCI operations:

1. User:
 - a. Make sure that the UNIX/PC server hardware and software are properly installed and configured. For specific support information, refer to the Hitachi Data Systems interoperability matrix: <http://www.hds.com/products/interoperability>.
 - b. If you will be performing remote replication operations (for example, Universal Replicator, TrueCopy), identify the primary and secondary volumes, so that the hardware and software components can be installed and configured properly.
2. HDS representative:
 - a. Connect the RAID storage system(s) to the UNIX/PC server host(s). Refer to the Maintenance Manual for the storage system and the Open-Systems Host Attachment Guide (MK-90RD7037). Make sure to set the appropriate system option modes (SOMs) and host mode options (HMOs) for the operational environment.
 - b. Configure the RAID storage systems that will contain primary volumes for replication to report sense information to the host(s).
 - c. Set the clock on the SVP/GUM to local time so the time stamps are correct.
 - d. Remote replication: Install the remote copy connections between the RAID storage systems. For detailed information, see the applicable user guide (for example, *Hitachi Universal Replicator User Guide*).
3. User and HDS representative:
 - a. Ensure that the storage systems are accessible via Storage Navigator. For details, see the Storage Navigator User Guide for the storage system.
 - b. Ensure that the storage systems are accessible via Hitachi Command Suite. For details, see the *Hitachi Command Suite User Guide*.
 - c. Install and enable the applicable options (for example, TrueCopy, ShadowImage, LUN Manager, Universal Replicator for Mainframe) on the RAID storage system(s).
4. User: Configure the RAID storage systems for operations as described in the user documentation. For example, before you can create TrueCopy volume pairs using CCI, you need to configure the ports on the storage systems and establish the MCU-RCU paths.

Installing the CCI software

Installation of the CCI software on the host server(s) is performed by the user with assistance as needed from the HDS representative.

The installation must be done in the following order:

1. Install the CCI software.
2. Set the command device.
3. Create the configuration definition files.
4. Set the environmental variables.

UNIX installation

If you are installing CCI from the media for the program product, use the RMinstsh and RMuninst scripts on the program product media to automatically install and remove the CCI software. (For LINUX/IA64 or LINUX/X64, move to the LINUX/IA64 or LINUX/X64 directory and then execute `../RMinstsh`.) For other media, use the following instructions. The following instructions refer to UNIX commands that might be different on your platform. Consult your OS documentation (for example, UNIX man pages) for platform-specific command information.

To install the CCI software into the root directory:

1. Insert the installation media into the I/O device properly.
2. Move to the current root directory: `# cd /`
3. Copy all files from the installation media using the `cpio` command:
`# cpio -idmu < /dev/XXXX` XXXX = I/O device
Preserve the directory structure (d flag) and file modification times (m flag), and copy unconditionally (u flag). For floppy disks, load them sequentially, and repeat the command. An I/O device name of floppy disk designates a surface partition of the raw device file (unpartitioned raw device file).
4. Execute the CCI installation command:
`# /HORCM/horcminstall.sh`
5. Verify installation of the proper version using the `raidqry` command:
`# raidqry -h`
Model: RAID-Manager/HP-UX
Ver&Rev: 01-29-03/05
Usage: `raidqry [options]`

To install the CCI software into a non-root directory:

1. Insert the installation media into the proper I/O device.
2. Move to the desired directory for CCI. The specified directory must be mounted by a partition of except root disk or an external disk.
`# cd /Specified Directory`
3. Copy all files from the installation media using the `cpio` command:
`# cpio -idmu < /dev/XXXX` XXXX = I/O device
Preserve the directory structure (d flag) and file modification times (m flag), and copy unconditionally (u flag). For floppy disks, load them sequentially, and repeat the command. An I/O device name of floppy disk designates a surface partition of the raw device file (unpartitioned raw device file).

4. Make a symbolic link for /HORCM:

```
# ln -s /Specified Directory/HORCM /HORCM
```
5. Execute the CCI installation command:

```
# /HORCM/horcminstall.sh
```
6. Verify installation of the proper version using the raidqry command:

```
# raidqry -h
Model: RAID-Manager/HP-UX
Ver&Rev: 01-29-03/05
Usage: raidqry [options]
```

Changing the CCI user (UNIX systems)

The CCI software is initially configured to allow only the root user (system administrator) to execute CCI commands. If desired (for example, CCI administrator does not have root access), the system administrator can change the CCI user from root to another user name.

To change the CCI user:

1. Change the owner of the following CCI files from the root user to the desired user name:
 - /HORCM/etc/horcmgr
 - All CCI commands in the /HORCM/usr/bin directory
 - All CCI log directories in the /HORCM/log* directories
2. Change the owner of the raw device file of the HORCM_CMD (control device) command device in the configuration definition file from the root user to the desired user name.
3. Optional: Establishing the HORCM (/etc/horcmgr) start environment: If you have designation of the full environment variables (HORCM_LOG HORCM_LOGS), then start the horcmstart.sh command without an argument. In this case, the HORCM_LOG and HORCM_LOGS directories must be owned by the CCI administrator. The environment variable (HORCMINST, HORCM_CONF) establishes as the need arises.
4. Optional: Establishing the command execution environment: If you have designation of the environment variables (HORCC_LOG), then the HORCC_LOG directory must be owned by the CCI administrator. The environment variable (HORCMINST) establishes as the need arises.
5. Establish UNIX domain socket: If the execution user of CCI is different from user of the command, a system administrator needs to change the owner of the following directory, which is created at each HORCM(/etc/horcmgr) start-up:
 - /HORCM/.uds/.lcmcl directory

To reset the security of UNIX domain socket to OLD version:

- Gives writing permission to /HORCM/.uds directory
- Starts horcmstart.sh .. setting "HORCM EVERYCLI=1" environment variable



Note: A user account for the Linux system must have the "CAP_SYS_ADMIN" and "CAP_SYS_RAWIO" privileges to use the SCSI Class driver (Command device). The system administrator can apply these privileges by using the PAM_capability module. However, if the system administrator cannot set those user privileges, then use the following method. This method starts the HORCM daemon only with the root user; as an alternative, you can execute CCI commands.

- **System administrator:** Place the script that starts up horcmstart.sh in the following directory so that the system can start HORCM from /etc/rc.d/rc: **/etc/init.d**
- **Users:** When the log directory is only accessible by the system administrator, you cannot use the **inraid** or **raidscan -find** commands. Therefore, set the command log directory by setting the environment variables (HORCC_LOG), and executing the RM command.



Note: AIX does not allow ioctl() with the exception of the root user. CCI tries to use **ioctl(DK_PASSTHRU)** or **SCSI_Path_thru** as much as possible, if it fails, changes to **RAW_IO** follows conventional ways. Even so, CCI might encounter the AIX FCP driver, which does not support **ioctl(DK_PASSTHRU)** fully in the customer site. After this consideration, CCI also supports by defining either the following environment variable or **/HORCM/etc/USE_OLD_IOCTLfile(size=0)** that uses the RAW_IO forcibly.

Example:

```
export USE_OLD_IOCTL=1
horcmstart.sh 10
HORCM/etc:
-rw-r--r--  1 root root      0 Nov 11 11:12 USE_OLD_IOCTL
-r--r--r--  1 root sys   32651 Nov 10 20:02 horcm.conf
-r-xr--r--  1 root sys  282713 Nov 10 20:02 horcmgr
```

Windows installation

Make sure to install CCI on all servers involved in CCI operations. If network (TCP/IP) is not established, install a network of Windows attachment, and add TCP/IP protocol.

To install the CCI software on a Windows system:

1. Insert the media for the program product into the proper I/O device.
2. Run Setup.exe (\program\RM\WIN_NT\RMHORCRMXP\Setup.exe or \program\RM\WIN_NT\RMHORCRMXP_X64\Setup.exe on the CD), and follow the instructions on screen to complete the installation. The install directory is HORCM (fixed value) directly under the drive.
3. Reboot the Windows server, and verify that the correct version of the of the CCI software is running on your system by executing the raidqry command:

```
D:\HORCM\etc> raidqry -h
Model: RAID-Manager/WindowsNT
Ver&Rev: 01-30-03/xx
Usage: raidqry [options] for HORC
```

A warning message for security might appear at the initial start-up depending on the OS settings. Specify "Temporarily Allow" or "Always Allow" in the dialog box.

Changing the CCI user (Windows systems)

Usually, CCI commands can be executed only by the system administrator in order to directly open the PhysicalDrive.

When an administrator of CCI does not have an "administrator" privilege or there is a difference between the system administrator and the CCI administrator, the CCI administrator can use CCI commands as follows:

System Administrator Tasks

1. Add a user_name to the PhysicalDrive.

Add the user name of the CCI administrator to the Device Objects of the command device for HORCM_CMD in the configuration definition file. For example:

```
C:\HORCM\tool\>chgacl /A:RAdmin Phys
PhysicalDrive0 -> \Device\Harddisk0\DR0
\\.\PhysicalDrive0 : changed to allow 'RAdmin'
```

2. Add a user_name to the Volume{GUID}.

If the CCI administrator needs to use the "-x mount/umount" option for CCI commands, the system administrator must add the user name of the CCI administrator to the Device Objects of the Volume{GUID}. For example:

```
C:\HORCM\tool\>chgacl /A:RAdmin Volume
Volume{b0736c01-9b14-11d8-b1b6-806d6172696f} -> \Device\CdRom0
\\.\Volume{b0736c01-9b14-11d8-b1b6-806d6172696f} : changed to
allow 'RAdmin'
Volume{b0736c02-9b14-11d8-b1b6-806d6172696f} -> \Device\Floppy0
\\.\Volume{b0736c02-9b14-11d8-b1b6-806d6172696f} : changed to
allow 'RAdmin'
Volume{b0736c00-9b14-11d8-b1b6-806d6172696f} -> \Device
\HarddiskVolume1
\\.\Volume{b0736c00-9b14-11d8-b1b6-806d6172696f} : changed to
allow 'RAdmin'
```

3. Add a user_name to the ScsiX.

If the CCI administrator needs to use the "-x portscan" option for CCI commands, the system administrator must add the user name of the CCI administrator to the Device Objects of the ScsiX. For example:

```
C:\HORCM\tool\>chgacl /A:RAdmin Scsi
Scsi0: -> \Device\Ide\IdePort0
\\.\Scsi0: : changed to allow 'RAdmin'
Scsi1: -> \Device\Ide\IdePort1
\\.\Scsi1: : changed to allow 'RAdmin '
```

Because the ACL (Access Control List) of the Device Objects is set every time Windows starts-up, the Device Objects are also required when Windows starts-up. The ACL is also required when new Device Objects are created.

CCI Administrator Tasks

1. Establish the HORCM (/etc/horcmgr) startup environment.
By default, copy the configuration definition file in the following directory:
%SystemRoot%\windows

Because users cannot write to this directory, the CCI administrator must change the directory by using the HORCM_CONF variable. For example:

```
C:\HORCM\etc\>set HORCM_CONF=C:\Documents and Settings\RMadmin
\horcm10.conf
C:\HORCM\etc\>set HORCMINST=10
C:\HORCM\etc\>horcmstart [This must be started without
arguments]
```

The mountvol command is denied use by user privilege, therefore "the directory mount" option of RM commands using the mountvol command cannot be executed.

The inqraid "-gvinf" option uses **%SystemDrive%:\windows** directory, so this option cannot use unless system administrator allow to write.

However, CCI can change from **%SystemDrive%:\windows** directory to **%TEMP%** directory by setting "HORCM_USE_TEMP" environment variable.

For example:

```
C:\HORCM\etc\>set HORCM_USE_TEMP=1
C:\HORCM\etc\>inqraid $Phys -gvinf
```

2. Ensure that CCI command and the HORCM have the same privileges. If CCI command and the HORCM are executing different privileges (different users), then CCI command can not attach to HORCM (CCI command and HORCM are denied communication through the Mailslot).

However, CCI does permit a HORCM connection through the "HORCM_EVERYCLI" environment variable, as shown in the following example.

```
C:\HORCM\etc\>set HORCM_CONF=C:\Documents and Settings\RMadmin
\horcm10.conf
C:\HORCM\etc\>set HORCMINST=10
C:\HORCM\etc\>set HORCM_EVERYCLI=1
C:\HORCM\etc\>horcmstart [This must be started without
arguments]
```

In this example, users who execute CCI commands must be restricted to use only CCI commands. This can be done using the Windows "explore" or "cacls" commands.

OpenVMS installation

Make sure to install CCI on all servers involved in CCI operations. Establish the network (TCP/IP), if not already established. CCI is provided as the following PolyCenter Software Installation (PCSI) file:

HITACHI-ARMVMS-RM-V0122-2-1.PCSI HITACHI-I64VMS-RM-V0122-2-1.PCSI

Follow the requirements and restrictions in [Porting notice for OpenVMS on page 1-15](#).

CCI also requires that POSIX_ROOT exist on the system, so you must define the POSIX_ROOT before installing the CCI software. It is recommended that you define the following three logical names for CCI in **LOGIN.COM**:

```
$ DEFINE/TRANSLATION=(CONCEALED,TERMINAL) SYS$POSIX_ROOT "Device:
[directory]"
$ DEFINE DCL$PATH SYS$POSIX_ROOT:[horcm.usr.bin],SYS$POSIX_ROOT:
[horcm.etc]
$ DEFINE/TABLE=LNK$PROCESS_DIRECTORY LNK$TEMPORARY_MAILBOX LNK$GROUP
$ DEFINE DECC$ARGV_PARSE_STYLE ENABLE
$ SET PROCESS/PARSE_STYLE=EXTENDED
```

where Device:[directory] is defined as SYS\$POSIX_ROOT

To install the CCI software on an OpenVMS system:

1. Insert and mount the provided CD or diskette.
2. Execute the following command:

```
$ PRODUCT INSTALL RM /source=Device:[PROGRAM.RM.OVMS]/LOG -
_$ /destination=SYS$POSIX_ROOT:[000000]
Device:[PROGRAM.RM.OVMS] where HITACH-ARMVMS-RM-
V0122-2-1.PCSI exists
```
3. Verify installation of the proper version using the raidqry command:

```
$ raidqry -h
Model: RAID-Manager/OpenVMS
Ver&Rev: 01-29-03/05
Usage: raidqry [options]
```
4. Follow the requirements and restrictions in [Porting notice for OpenVMS on page 1-15](#).

In-band and out-of-band operations

CCI operations can be performed using either the in-band method (all storage systems) or the out-of-band method (VSP and later).

- In-band (host-based) method. CCI commands are transferred from the client or server to the command device in the storage system via the host fibre-channel interface. The command device must be defined in the configuration definition file, as shown in the following figure.
- Out-of-band (LAN-based) method. CCI commands are transferred from the client or server to the virtual command device in the SVP/GUM via the LAN. The virtual command device and the IP address of the SVP/GUM must be specified in the configuration definition file, as shown in the following figure.

A virtual command device can also be created on the CCI server, which is a remote CCI installation that is connected by LAN. The location of the virtual command device depends on the type of storage system. The following table lists the storage system types and indicates the allowable locations of the virtual command device.

Storage system type	Location of virtual command device		
	SVP	GUM	CCI server
VSP Gx00 models, VSP Fx00 models	Not allowed*	OK	OK
VSP G1000	OK	Not allowed	OK
HUS VM	OK	Not allowed	OK
VSP	OK	Not allowed	OK
*You can use the SVP of VSP Gx00 models and VSP Fx00 models on which CCI is installed as the CCI server. If you use a CCI server, you can do the same operations on the VSP Gx00 models and VSP Fx00 models as when using a virtual command device on the SVP of the VSP G1000, HUS VM, or VSP.			

The following figure shows a system configuration example and a setting example of a command device and a virtual command device by the in-band and out-of-band methods.





Figure 2-1 System Configuration Example and Setting Example of Command Device and Virtual Command Device by In-Band and Out-of-Band Methods (VSP G1000, VSP, HUS VM shown)

In the following figure, CCI B is the CCI server for CCI A. You can issue commands from CCI A to the storage system through the virtual command device of CCI B. You can also issue commands from CCI B directly to the storage system (without CCI A). When you issue commands directly from CCI B, CCI A is optional.



* When you actually write the configuration definition file, replace *IP1* with IP address of GUM#1 and *IP2* with IP address of GUM#2.

Figure 2-2 System Configuration Example and Setting Example of Command Device and Virtual Command Device by In-Band and Out-of-Band Methods (VSP Gx00 models and VSP Fx00 models)




Figure 2-3 System Configuration Example when the CCI server is connected to the storage system by In-Band

Setting up UDP ports

This section contains information about setting up strict firewalls.

If you do not have a HORCM_MON IP address in your configuration definition file, CCI (horcm) opens the following ports on horcmstart:

- For in-band or out-of-band: [31000 + horcminstance + 1]
- For out-of-band: [34000 + horcminstance + 1]

If you have a HORCM_MON IP address in your configuration definition file, you need to open up the port that is defined in this entry.

Setting the command device

For in-band CCI operations, commands are issued to the RAID storage system via the command device. The command device is a user-selected, dedicated logical volume on the storage system that functions as the interface to the CCI software on the host. The command device is dedicated to CCI operations and cannot be used by any other applications. The command device accepts read and write commands that are executed by the storage system and returns read requests to the host.

The command device can be any OPEN-V device that is accessible to the host. A LUSE volume cannot be used as a command device. The command device uses 16 MB, and the remaining volume space is reserved for CCI and its utilities. A Virtual LUN volume as small as 36 MB can be used as a command device.

First you set the command device using Hitachi Command Suite or Device Manager - Storage Navigator, and then you define the command device in the HORCM_CMD section of the configuration definition file for the CCI instance on the attached host. When you use a command for provisioning, user authentication is required. Set enable the user authentication on the security attribute of a command device.

For specifying the command device and the virtual command device, you can enter up to 511 characters on a line.

To set a command device:

1. Make sure the device that will be set as a command device does not contain any user data. Once a volume is set as a command device, it is inaccessible to the host.
2. Log on to Hitachi Command Suite or Storage Navigator, and connect to the storage system on which you want to set a command device.
3. Configure the device as needed before setting it as a command device. For example, you can create a custom-size device that has 36 MB of storage capacity for use as a command device. For instructions, see the Provisioning manual or the Virtual LUN manual for the storage system.
4. Locate and select the device, and set the device as a command device. If you want to use the CCI Protection Facility, also enable command device security at this time. For instructions, see the Provisioning manual or the LUN Manager manual for the storage system. For information about the Protection Facility, see the *Command Control Interface User and Reference Guide*.
5. Write down the system raw device name (character-type device file name) of the command device (for example, /dev/rdisk/c0t0d1s2 in Solaris, \\.\CMD-Ser#-ldev#-Port# in Windows). You will need this information when you define the command device in the configuration definition file.
6. To set an alternate command device, repeat this procedure for another volume. For details about alternate command devices, see [About alternate command devices on page 2-15](#).



Note:

- For Solaris operations, the command device must be labeled.
- To enable dual pathing of the command device under Solaris systems, include all paths to the command device on a single line in the HORCM_CMD section of the configuration definition file. [Example 2-1 Example of dual path for command device for Solaris systems on page 2-14](#) shows an example with two controller paths (c1 and c2) to the command device. Putting the path information on separate lines might

cause parsing issues, and failover might not occur unless the HORCM startup script is restarted on the Solaris system.

```
HORCM_CMD
#dev_name dev_name dev_name
/dev/rdisk/clt66d36s2 /dev/rdisk/c2t66d36s2
```

Example 2-1 Example of dual path for command device for Solaris systems

Setting the command device and virtual command device by in-band and out-of-band methods

For executing a command by the in-band method, set an LU path in a configuration definition file and create a command device. The command device in the storage system specified by the LU path accepts the command from the client, and executes the operation instruction.

Meanwhile, for executing a command by the out-of-band method, create a virtual command device. The virtual command device creates an IP address of the SVP, a UDP communication port number (fixed at 31001), and a storage system unit number in the configuration definition file.

By creating the virtual command device, transfer the command from the client or the server via LAN to the virtual command device of the set IP address in the SVP, and assign an operation instruction to the storage system.

A setting example of a command device and a virtual command device (by the in-band and out-of-band methods) in a configuration definition file is shown below. For details, see the *Command Control Interface User and Reference Guide*.

```
HORCM_CMD
#dev_name dev_name dev_name
\\.\CMD-64015:/dev/rdisk/*
```

Example 2-2 Setting Example of Command Device in Configuration Definition File (in-band method)

Example for SVP IP address 192.168.1.100 and UDP communication port number 31001:

```
HORCM_CMD
#dev_name dev_name dev_name
\\.\IPCMD-192.168.1.100-31001
```

Example 2-3 Setting Example of Virtual Command Device in Configuration Definition File (out-of-band method)

Example for GUM IP addresses 192.168.0.16, 192.168.0.17 and UDP communication port numbers 31001, 31002. In this case, enter the IP addresses without line feed.

```
HORCM_CMD
#dev_name dev_name dev_name
```

```
\\.\IPCMD-192.168.0.16-31001 \\.\IPCMD-192.168.0.17-31001 \\.\  
\\IPCMD-192.168.0.16-31002 \\.\IPCMD-192.168.0.17-31002
```

Example 2-4 Setting Example of Virtual Command Device in Configuration Definition File (out-of-band method)

About alternate command devices

If CCI receives an error notification in reply to a read or write request to a command device, the CCI software can switch to an alternate command device, if one is defined. If a command device is unavailable (for example, blocked due to online maintenance), you can switch to an alternate command device manually. If no alternate command device is defined or available, all commands terminate abnormally, and the host cannot issue CCI commands to the storage system. To ensure that CCI operations continue when a command device becomes unavailable, you should set one or more alternate command devices.

Because the use of alternate I/O pathing depends on the platform, restrictions are placed upon it. For example, on HP-UX systems only devices subject to the LVM can use the alternate path PV-LINK. To prevent command device failure, CCI supports an alternate command device function.

- **Definition of alternate command devices.** To use an alternate command device, define two or more command devices for the HORCM_CMD item in the configuration definition file. When two or more devices are defined, they are recognized as alternate command devices. If an alternate command device is not defined in the configuration definition file, CCI cannot switch to the alternate command device.
- **Timing of alternate command devices.** When the HORCM receives an error notification in reply from the operating system via the raw I/O interface, the command device is alternated. It is possible to alternate the command device forcibly by issuing an alternating command provided by TrueCopy (horcctl -C).
- **Operation of alternating command.** If the command device is blocked due to online maintenance (for example, microcode replacement), the alternating command should be issued in advance. When the alternating command is issued again after completion of the online maintenance, the previous command device is activated again.
- **Multiple command devices on HORCM startup.** If at least one command device is available during one or more the command devices that was described to the configuration definition file, then HORCM starts with a warning message to startup log by using available command device. The user needs to confirm that all command devices can be changed by using horcctl -C command option, or HORCM has been started without warning message to the HORCM start up log.




Figure 2-4 Alternate Command Device Function

Creating/editing the configuration definition file

The configuration definition file is a text file that is created and edited using any standard text editor (for example, UNIX vi editor, Windows Notepad). The configuration definition file defines correspondences between the server and the volumes used by the server. There is a configuration definition file for each host server. When the CCI software starts up, it refers to the definitions in the configuration definition file.

The configuration definition file defines the devices in copy pairs and is used for host management of the copy pairs, including ShadowImage, ShadowImage for Mainframe, TrueCopy, TrueCopy for Mainframe, Copy-on-Write Snapshot, Thin Image, Universal Replicator, and Universal Replicator for Mainframe.ShadowImage, ShadowImage for Mainframe, Copy-on-Write Snapshot, and Thin Image use the same configuration files and commands, and the RAID storage system determines the type of copy pair based on the S-VOL characteristics and (for Copy-on-Write Snapshot and Thin Image) the pool type.

The configuration definition file contains the following sections:

- **HORCM_MON:** Defines information about the local host.
- **HORCM_CMD:** Defines information about the command (CMD) devices.
- **HORCM_VCMD:** Defines information about the virtual storage machine.
- **HORCM_DEV or HORCM_LDEV:** Defines information about the copy pairs.
- **HORM_INST or INSTP:** Defines information about the remote host.
- **HORCM_LDEVG:** Defines information about the device group.
- **HORCM_ALLOW_INST:** Defines information about user permissions.

A sample configuration definition file, HORCM_CONF (/HORCM/etc/horcm.conf), is included with the CCI software. This file should be used as the basis for creating your configuration definition files. The system administrator

should make a copy of the sample file, set the necessary parameters in the copied file, and place the file in the proper directory.

The following table lists the parameters defined in the configuration file and specifies the default value, type, and limit for each parameter. For details about parameters in the configuration file, see the manual *Command Control Interface User and Reference Guide*. See [Sample configuration definition files on page B-2](#) for detailed descriptions of configuration definition files for sample CCI configurations.

Table 2-1 Configuration (HORCM_CONF) parameters

Parameter	Default	Type	Limit
ip_address	None	Character string	64 characters
Service	None	Character string or numeric value	15 characters
poll (10 ms)	1000	Numeric value*	None
timeout (10 ms)	3000	Numeric value*	None
dev_name for HORCM_DEV	None	Character string	31 characters
dev_group	None	Character string	31 characters Recommended value = 8 char. or less
port #	None	Character string	31 characters
target ID	None	Numeric value*	7 characters
LU#	None	Numeric value*	7 characters
MU#	0	Numeric value*	7 characters
Serial#	None	Numeric value*	12 characters
CU:LDEV(LDEV#)	None	Numeric value	6 characters
dev_name for HORCM_CMD	None	Character string	63 characters Recommended value = 8 char. or less
*Use decimal notation (not hexadecimal) for these numeric values.			

Do not edit the configuration definition file while CCI is running. Shut down CCI, edit the configuration file as needed, and then restart CCI.

Do not mix pairs created with the "pair splitting with specifying the consistency group" option (-m grp) and pairs created without this option in the same group defined in the CCI configuration file. If you do, a pairsplit operation might end abnormally, or S-VOLs of the P-VOLs in the same consistency group (CTG) might not be created correctly at the time the pairsplit request is received.

Upgrading CCI

For upgrading the CCI software, use the RMuninst scripts on the media for the program product.

For other media, please use the instructions in this chapter to upgrade the CCI software. The instructions might be different on your platform. Please consult your operating system documentation (for example, UNIX man pages) for platform-specific command information.

- ☐ [Upgrading CCI in a UNIX environment](#)
- ☐ [Upgrading CCI in a Windows environment](#)
- ☐ [Upgrading CCI in an OpenVMS environment](#)

Upgrading CCI in a UNIX environment

Use the RMinstsh script on the media for the program product to upgrade the CCI software to a later version.

For other media, use the following instructions to upgrade the CCI software to a later version. The following instructions refer to UNIX commands that might be different on your platform. Please consult your operating system documentation (for example, UNIX man pages) for platform-specific command information.

To update the CCI software version on a UNIX system:

1. Confirm that HORCM is not running. If it is running, shut it down:
One CCI instance: `# horcmshutdown.sh` Two CCI instances: `# horcmshutdown.sh 0 1`
If CCI commands are running in the interactive mode, terminate the interactive mode and exit these commands using `-q` option.
2. Insert the installation media into the proper I/O device. Use the RMinstsh (RMINSTSH) under `./program/RM` directory on the CD for the installation. For LINUX/IA64 and LINUX/X64, execute `../../RMinstsh` after moving to LINUX/IA64 or LINUX/X64 directory.
3. Move to the directory containing the HORCM directory (for example, `# cd /` for the root directory).
4. Copy all files from the installation media using the `cpio` command: `# cpio -idmu < /dev/XXXX`
where XXXX = I/O device
Preserve the directory structure (d flag) and file modification times (m flag), and copy unconditionally (u flag). For floppy disks, load them sequentially, and repeat the command. An input/output device name of floppy disk designates a surface partition of the raw device file (unpartitioned raw device file).
5. Execute the CCI installation command: `# /HORCM/horcminstall.sh`
6. Verify installation of the proper version using the `raidqry` command:
`# raidqry -h`
Model: RAID-Manager/HP-UX
Ver&Rev: 01-29-03/05
Usage: `raidqry [options]`
7. Changing the CCI user: see [Changing the CCI user \(UNIX systems\) on page 2-4](#) to ensure that the CCI user is appropriately set for the upgraded/installed files.

Upgrading CCI in a Windows environment



Caution: When you upgrade the CCI software, the sample script file is overwritten. If you have edited the sample script file and want to keep the changes, first back up the edited sample script file, and then upgrade the CCI software. After the upgrade installation, restore the data of the sample script

file using the backup file. For details about the sample script file, see the *CCI User and Reference Guide*.

To update the CCI software version on a Windows system:

1. You can upgrade the CCI software only when CCI is not running. If CCI is running, shut down CCI using the **horcmshutdown** command to ensure a normal end to all functions.
2. On the Control panel select **Add or Remove Programs**.
3. When the Add/Remove Program Properties window opens, select **RAID Manager for WindowsNT** from the program products list.
4. Click **Remove** to remove the CCI software.
5. Insert the installation media for the program product into the proper I/O device.
6. Execute Setup.exe (\program\RM\WIN_NT\RMHORC\Setup.exe or \program\RM\WIN_NT\RMHORC_X64\Setup.exe on the CD) and follow the instructions on the screen to complete the installation. The installation directory is HORCM (fixed value) at the root directory.
7. In the InstallShield window, follow the instructions on screen to install the CCI software.
8. Reboot the Windows server, and verify that the correct version of the CCI software is running on your system by executing the `raidqry -h` command. Example:

```
C:\HORCM\etc>raidqry -h
Model   : RAID-Manager/WindowsNT
Ver&Rev: 01-30-03/xx
Usage   : raidqry [options] for HORC
```
9. Changing the CCI user: see [Changing the CCI user \(Windows systems\) on page 2-6](#) to ensure that the CCI user is appropriately set for the upgraded/installed files.

Upgrading CCI in an OpenVMS environment

To update the CCI software version on an OpenVMS system:

1. You can upgrade the CCI software only when CCI is not running. If CCI is running, shut down CCI using the **horcmshutdown** command to ensure a normal end to all functions:
`$horcmshutdown` for one HORCM instance `$horcmshutdown 0 1` for two HORCM instances
When a command is being used in interactive mode, terminate it using the "-q" option.
2. Insert and mount the provided installation media.
3. Execute the following command:

```
$ PRODUCT INSTALL RM /source=Device:[PROGRAM.RM.OVMS]/LOG
                        Device:[PROGRAM.RM.OVMS] where HITACH-ARMVMS-RM-
V0122-2-1.PCSI exists
```
4. Verify installation of the proper version using the `raidqry` command:

```
$ raidqry -h
Model: RAID-Manager/OpenVMS
Ver&Rev: 01-29-03/05
Usage: raidqry [options]
```

5. Follow the requirements and restrictions in [Porting notice for OpenVMS on page 1-15](#).

Removing CCI

This chapter describes and provides instructions for removing the CCI software.

- ☐ [Removing CCI in a UNIX environment](#)
- ☐ [Removing CCI in a Windows environment](#)
- ☐ [Removing CCI in an OpenVMS environment](#)
- ☐ [Removing the CCI components](#)

Removing CCI in a UNIX environment

To remove the CCI software:

1. If you are discontinuing local or remote copy functions (for example, ShadowImage, TrueCopy), delete all volume pairs and wait until the volumes are in simplex status.
If you will continue copy operations using Hitachi Command Suite or Storage Navigator, do not delete any volume pairs.
2. You can remove the CCI software only when CCI is not running. If CCI is running, shut down CCI using the **horcmshutdown.sh** command to ensure a normal end to all functions:
One CCI instance: # horcmshutdown.sh Two CCI instances: # horcmshutdown.sh 0 1
If CCI commands are running in the interactive mode, terminate the interactive mode and exit these commands using **-q** option.
3. Use the **RMuninst** script on the installation media for the program product to remove the CCI software.

If you do not have the installation media for the program product, you can remove the CCI software manually as follows:

1. When HORCM is installed in the root directory (/HORCM is not a symbolic link) (see [Example 4-1 Uninstalling the CCI Software from a Root Directory on page 4-2](#)):
 - a. Execute the horcmuninstall command: # /HORCM/horcmuninstall.sh
 - b. Move to the root directory: # cd /
 - c. Delete the product using the rm command: # rm -rf /HORCM
2. When HORCM is not installed in the root directory (/HORCM is a symbolic link) (see [Example 4-2 Uninstalling the CCI Software from a Non-Root Directory on page 4-2](#)):
 - a. Execute the horcmuninstall command: # HORCM/horcmuninstall.sh
 - b. Move to the root directory: # cd /
 - c. Delete the symbolic link for /HORCM: # rm /HORCM
 - d. Delete the product using the rm command: # rm -rf /Directory/HORCM

#/HORCM/horcmuninstall.sh	-> Issue the uninstall command.
#cd /	-> Change directories.
#rm -rf /HORCM	-> Delete the CCI directory.

Example 4-1 Uninstalling the CCI Software from a Root Directory

#/HORCM/horcmuninstall.sh	-> Issue the uninstall command.
#cd /	-> Change directories.
#rm /HORCM	-> Delete the CCI link.
#rm -rf /non-root_directory_name/HORCM	->Delete the CCI directory.

Example 4-2 Uninstalling the CCI Software from a Non-Root Directory

Removing CCI in a Windows environment

To remove the CCI software on a Windows system:

1. If you are discontinuing local and/or remote copy functions (for example, ShadowImage, TrueCopy), delete all volume pairs and wait until the volumes are in simplex status. If you will continue copy operations using Hitachi Command Suite or Storage Navigator, do not delete any volume pairs.
2. You can remove the CCI software only when CCI is not running. If CCI software is running, shut down CCI using the **horcmshutdown** command to ensure a normal end to all functions:
One CCI instance: **D:\HORCM\etc> horcmshutdown** Two CCI instances: **D:\HORCM\etc> horcmshutdown 0 1**
3. Delete the CCI software using the **Add or Remove Programs** control panel:
 - a. Open the Control Panel, and double-click **Add or Remove Programs**.
 - b. On the **Add or Remove Programs** dialog, select **RAID Manager for WindowsNT** in the program list, and click **Remove**.

Removing CCI in an OpenVMS environment

To remove the CCI software on an OpenVMS system:

1. If you are discontinuing local and/or remote copy functions (for example, ShadowImage, TrueCopy), delete all volume pairs and wait until the volumes are in simplex status. If you will continue copy operations using Hitachi Command Suite or Storage Navigator, do not delete any volume pairs.
2. You can remove the CCI software only when CCI is not running. If CCI software is running, shut down CCI using the **horcmshutdown** command to ensure a normal end to all functions:
For one instance: **\$ horcmshutdown** For two instances: **\$ horcmshutdown 0 1**
If a command is being used in interactive mode, terminate it using the **-q** option.
3. Delete the installed CCI software by using the following command:
\$ PRODUCT REMOVE RM /LOG

Removing the CCI components

After removing the CCI software, perform the following tasks to remove the remaining CCI components:

1. Release command device security using Hitachi LUN Manager.
2. Delete the command devices using Hitachi LUN Manager.

You can now configure the volumes that were used as command devices for operations from the connected hosts.

Troubleshooting

This chapter provides troubleshooting information for CCI.

□ [Troubleshooting](#)

Troubleshooting

If you have a problem installing or upgrading the CCI software, make sure that all system requirements and restrictions have been met. If you need to call Hitachi Data Systems customer support, please provide as much information about the problem as possible, including:

- The circumstances surrounding the error or failure.
- The content of any error messages displayed on the host systems.
- The content of any error messages displayed by Device Manager - Storage Navigator.
- The Device Manager - Storage Navigator configuration information (use the Dump Tool).
- The service information messages (SIMs), including reference codes and severity levels, displayed by Device Manager - Storage Navigator.

The Hitachi Data Systems customer support staff is available 24 hours a day, seven days a week. If you need technical support, log on to Hitachi Data Systems Support Connect for contact information: https://support.hds.com/en_us/contact-us.html.

Fibre-to-SCSI address conversion

Disks connected with fibre channel display as SCSI disks on UNIX hosts. Disks connected with fibre channel connections can be fully utilized. CCI converts fibre-channel physical addresses to SCSI target IDs (TIDs) using a conversion table (see [Figure A-1 Example Fibre Address Conversion on page A-2](#)). [Table A-1 Limits for Target IDs and LUNs on page A-2](#) shows the current limits for SCSI TIDs and LUNs on various operating systems.

- ☐ [Fibre/FCoE-to-SCSI address conversion](#)
- ☐ [LUN configurations on the RAID storage systems](#)
- ☐ [Fibre address conversion tables](#)

Fibre/FCoE-to-SCSI address conversion




Figure A-1 Example Fibre Address Conversion

For iSCSI, the AL_PA is the fixed value 0xFE.

Table A-1 Limits for Target IDs and LUNs

-	HP-UX, other Systems		Solaris, IRIX Systems		Windows Systems	
Port	TID	LUN	TID	LUN	TID	LUN
Fibre	0 to 15	0 to 1023	0 to 125	0 to 1023	0 to 31	0 to 1023
SCSI	0 to 15	0 to 7	0 to 15	0 to 7	0 to 15	0 to 7

Conversion table for Windows. The conversion table for Windows is based on conversion by an Emulex driver. If the fibre-channel adapter is different (for example, Qlogic, HP), the target ID that is indicated by the **raidscan** command might be different from the target ID on the Windows host.

[Example A-1 Using Raidscan to Display TID and LUN for Fibre-Channel Devices on page A-3](#) shows an example of using the **raidscan** command to display the TID and LUN of Harddisk6 (HP driver). You must start HORCM without the descriptions of HORCM_DEV or HORCM_INST in the configuration definition file because of the unknown TIDs and LUNs.

```
C:\>raidscan -pd hd6 -x drivescan hd6
Harddisk 6... Port[ 2] PhId[ 4] TId[ 3] Lun[ 5] [HITACHI      ]
[OPEN-3      ]
          Port[CL1-J] Ser#[ 30053] LDEV#[ 14(0x00E)]
          HORC = SMPL HOMRCF[MU#0 = SMPL MU#1 = SMPL MU#2 =
SMPL]
          RAID5[Group 1- 2] SSID = 0x0004
PORT# /ALPA/C,TID#,LU#.Num(LDEV#....) ...P/S, Status,Fence,LDEV#,P-
Seq#,P-LDEV#
CL1-J / e2/4, 29, 0.1(9).....SMPL ---- - - - - - ,
---- - - - - -
CL1-J / e2/4, 29, 1.1(10).....SMPL ---- - - - - - ,
---- - - - - -
CL1-J / e2/4, 29, 2.1(11).....SMPL ---- - - - - - ,
---- - - - - -
CL1-J / e2/4, 29, 3.1(12).....SMPL ---- - - - - - ,
---- - - - - -
```

```

-----
CL1-J / e2/4, 29, 4.1(13).....SMPL ---- -,
-----
CL1-J / e2/4, 29, 5.1(14).....SMPL ---- -,
-----
CL1-J / e2/4, 29, 6.1(15).....SMPL ---- -,
-----
Specified device is LDEV# 0014

```

Example A-1 Using Raidscan to Display TID and LUN for Fibre-Channel Devices

In this case, the target ID indicated by the **raidscan** command must be used in the configuration definition file. This can be accomplished using either of the following two methods:

- Using default conversion table. Use the TID# and LU# indicated by the **raidscan** command in the HORCM configuration definition file (TID=29 LUN=5 in [Example A-1 Using Raidscan to Display TID and LUN for Fibre-Channel Devices on page A-3](#)).
- Changing default conversion table. Change the default conversion table using the HORCMFCTBL environmental variable (see [Example A-2 Using HORCMFCTBL to Change the Default Fibre Conversion Table on page A-4](#)) (TID=3 LUN=5 in [Example A-2 Using HORCMFCTBL to Change the Default Fibre Conversion Table on page A-4](#)).

```

C:\> set HORCMFCTBL=X                               → 'X' is fibre
conversion table number.
C:\> horcmstart ...                                   → Start of HORCM.
:
:
Result of "set HORCMFCTBL=X" command:
C:\>raidscan -pd hd6 -x drivescan hd6
Harddisk 6... Port[ 2] PhId[ 4] TId[ 3] Lun[ 5] [HITACHI    ]
[OPEN-3      ]
Port[CL1-J] Ser#[ 30053] LDEV#[ 14(0x00E)]
HORC = SMPL HOMRCF[MU#0 = SMPL MU#1 = SMPL MU#2 =
SMPL]
RAID5[Group 1- 2] SSID = 0x0004
PORT# /ALPA/C,TID#,LU#.Num(LDEV#....) ...P/S,Status,Fence,LDEV#,P-
Seq#,P-LDEV#
CL1-J / e2/0, 3, 0.1(9).....SMPL ---- -,
-----
CL1-J / e2/0, 3, 1.1(10).....SMPL ---- -,
-----
CL1-J / e2/0, 3, 2.1(11).....SMPL ---- -,
-----
CL1-J / e2/0, 3, 3.1(12).....SMPL ---- -,
-----
CL1-J / e2/0, 3, 4.1(13).....SMPL ---- -,
-----
CL1-J / e2/0, 3, 5.1(14).....SMPL ---- -,
-----
CL1-J / e2/0, 3, 6.1(15).....SMPL ---- -,
-----

```

Specified device is LDEV# 0014

Example A-2 Using HORCMFCTBL to Change the Default Fibre Conversion Table

LUN configurations on the RAID storage systems

The RAID storage systems (9900V and later) manage the LUN configuration on a port through the LUN security as shown in the following figure.




Figure A-2 LUN Configuration

CCI uses absolute LUNs to scan a port, whereas the LUNs on a group are mapped for the host system so that the target ID & LUN, which is indicated by the **raidscan** command, is different from the target ID & LUN shown by the host system. In this case, the target ID & LUN indicated by the **raidscan** command should be used.

In this case, you must start HORCM without a description for HORCM_DEV and HORCM_INST because target ID & LUN are unknown. Use the port, target ID, and LUN displayed by the **raidscan -find** or **raidscan -find conf** command for HORCM_DEV (see [Example A-3 Displaying the Port, TID, and LUN Using raidscan on page A-4](#)).

For details on LUN discovery based on a host group, see Host Group Control in the *Command Control Interface User and Reference Guide*.

```
# ls /dev/rdsk/* | raidscan -find
DEVICE_FILE      UID  S/F PORT  TARG  LUN   SERIAL  LDEV  PRODUCT_ID
/dev/rdsk/c0t0d4  0    S  CL1-M    0     4    31168   216  OPEN-3-
CVS-CM
/dev/rdsk/c0t0d1  0    S  CL1-M    0     1    31168   117  OPEN-3-CVS
/dev/rdsk/c1t0d1  -    -  CL1-M    -     -    31170   121  OPEN-3-CVS
```

Example A-3 Displaying the Port, TID, and LUN Using raidscan

UID: displays the UnitID for multiple RAID configuration. If UID appears as '-' then the command device for HORCM_CMD is not found.

S/F: displays that a PORT is SCSI or fibre.

PORT: displays the RAID storage system port number.

TARG: displays the target ID (converted by the fibre conversion table, see [Fibre address conversion tables on page A-5](#)).

LUN: displays the Logical Unit Number (converted by the fibre conversion table).

SERIAL: displays the production number (serial#) of the RAID storage system.

LDEV: displays the LDEV# within the RAID storage system.

PRODUCT_ID: displays product-id field in the STD inquiry page.

Fibre address conversion tables

[Table A-2 Fibre Address Conversion Table for HP-UX Systems \(Table0\) on page A-6](#), [Table A-3 Fibre Address Conversion Table for Solaris and IRIX Systems \(Table1\) on page A-6](#), [Table A-4 Fibre Address Conversion Table for Windows Systems \(Table2\) on page A-7](#) and show the fibre address conversion tables:

- Table number 0 = HP-UX systems (see [Table A-2 Fibre Address Conversion Table for HP-UX Systems \(Table0\) on page A-6](#))
- Table number 1 = Solaris and IRIX systems (see [Table A-3 Fibre Address Conversion Table for Solaris and IRIX Systems \(Table1\) on page A-6](#))
- Table number 2 = Windows systems (see [Table A-4 Fibre Address Conversion Table for Windows Systems \(Table2\) on page A-7](#))

The conversion table for Windows systems is based on the Emulex driver. If a different fibre-channel adapter is used, the target ID indicated by the raidscan command might be different than the target ID indicated by the Windows system.

Note on Table 3 for other Platforms: Table 3 is used to indicate the LUN without Target ID for unknown FC_AL conversion table or fibre-channel fabric (fibre-channel world wide name). In this case, the Target ID is always zero, thus **Table 3 is not described in this document**. Table 3 is used as the default for platforms other than those listed above. If the host will use the WWN notation for the device files, then this table number should be changed by using the \$HORCMFCTBL variable.

If the TID displayed on the system is different than the TID indicated in the fibre address conversion table, you must use the TID (or LU#) returned by the raidscan command to specify the device(s).

Table A-2 Fibre Address Conversion Table for HP-UX Systems (Table0)

C0		C1		C2		C3		C4		C5		C6		C7	
AL-PA	TI D	AL-PA	TI D	AL-PA	TI D	AL-PA	TI D	AL-PA	TI D	AL-PA	TI D	AL-PA	TI D	AL-PA	TI D
EF	0	CD	0	B2	0	98	0	72	0	55	0	3A	0	25	0
E8	1	CC	1	B1	1	97	1	71	1	54	1	39	1	23	1
E4	2	CB	2	AE	2	90	2	6E	2	53	2	36	2	1F	2
E2	3	CA	3	AD	3	8F	3	6D	3	52	3	35	3	1E	3
E1	4	C9	4	AC	4	88	4	6C	4	51	4	34	4	1D	4
E0	5	C7	5	AB	5	84	5	6B	5	4E	5	33	5	1B	5
DC	6	C6	6	AA	6	82	6	6A	6	4D	6	32	6	18	6
DA	7	C5	7	A9	7	81	7	69	7	4C	7	31	7	17	7
D9	8	C3	8	A7	8	80	8	67	8	4B	8	2E	8	10	8
D6	9	BC	9	A6	9	7C	9	66	9	4A	9	2D	9	0F	9
D5	10	BA	10	A5	10	7A	10	65	10	49	10	2C	10	08	10
D4	11	B9	11	A3	11	79	11	63	11	47	11	2B	11	04	11
D3	12	B6	12	9F	12	76	12	5C	12	46	12	2A	12	02	12
D2	13	B5	13	9E	13	75	13	5A	13	45	13	29	13	01	13
D1	14	B4	14	9D	14	74	14	59	14	43	14	27	14	-	-
CE	15	B3	15	9B	15	73	15	56	15	3C	15	26	15	-	-

Table A-3 Fibre Address Conversion Table for Solaris and IRIX Systems (Table1)

C0		C1		C2		C3		C4		C5		C6		C7	
AL-PA	TI D	AL-PA	TID	AL-PA	TI D	AL-PA	TI D	AL-PA	TI D	AL-PA	TI D	AL-PA	TI D	AL-PA	TID
EF	0	CD	16	B2	32	98	48	72	64	55	80	3A	96	25	112
E8	1	CC	17	B1	33	97	49	71	65	54	81	39	97	23	113
E4	2	CB	18	AE	34	90	50	6E	66	53	82	36	98	1F	114
E2	3	CA	19	AD	35	8F	51	6D	67	52	83	35	99	1E	115
E1	4	C9	20	AC	36	88	52	6C	68	51	84	34	100	1D	116
E0	5	C7	21	AB	37	84	53	6B	69	4E	85	33	101	1B	117
DC	6	C6	22	AA	38	82	54	6A	70	4D	86	32	101	18	118

C0		C1		C2		C3		C4		C5		C6		C7	
AL-PA	TID	AL-PA	TID	AL-PA	TID	AL-PA	TID	AL-PA	TID	AL-PA	TID	AL-PA	TID	AL-PA	TID
DA	7	C5	23	A9	39	81	55	69	71	4C	87	31	103	17	119
D9	8	C3	24	A7	40	80	56	67	72	4B	88	2E	104	10	120
D6	9	BC	25	A6	41	7C	57	66	73	4A	89	2D	105	0F	121
D5	10	BA	26	A5	42	7A	58	65	74	49	90	2C	106	08	122
D4	11	B9	27	A3	43	79	59	63	75	47	91	2B	107	04	123
D3	12	B6	28	9F	44	76	60	5C	76	46	92	2A	108	02	124
D2	13	B5	29	9E	45	75	61	5A	77	45	93	29	109	01	125
D1	14	B4	30	9D	46	74	62	59	78	43	94	27	110	-	-
CE	15	B3	31	9B	47	73	63	56	79	3C	95	26	111	-	-

Table A-4 Fibre Address Conversion Table for Windows Systems (Table2)

C5 (PhId5)		C4 (PhId4)				C3 (PhId3)				C2 (PhId2)				C1 (PhId1)			
AL-PA	TID	AL-PA	TID	AL-PA	TID	AL-PA	TID	AL-PA	TID	AL-PA	TID	AL-PA	TID	AL-PA	TID	AL-PA	TID
-	-	-	-	CC	15	-	-	98	15	-	-	56	15	-	-	27	15
-	-	E4	30	CB	14	B1	30	97	14	72	30	55	14	3C	30	26	14
-	-	E2	29	CA	13	AE	29	90	13	71	29	54	13	3A	29	25	13
-	-	E1	28	C9	12	AD	28	8F	12	6E	28	53	12	39	28	23	12
-	-	E0	27	C7	11	AC	27	88	11	6D	27	52	11	36	27	1F	11
-	-	DC	26	C6	10	AB	26	84	10	6C	26	51	10	35	26	1E	10
-	-	DA	25	C5	9	AA	25	82	9	6B	25	4E	9	34	25	1D	9
-	-	D9	24	C3	8	A9	24	81	8	6A	24	4D	8	33	24	1B	8
-	-	D6	23	BC	7	A7	23	80	7	69	23	4C	7	32	23	18	7
-	-	D5	22	BA	6	A6	22	7C	6	67	22	4B	6	31	22	17	6
-	-	D4	21	B9	5	A5	21	7A	5	66	21	4A	5	2E	21	10	5

C5 (PhId5)		C4 (PhId4)				C3 (PhId3)				C2 (PhId2)				C1 (PhId1)			
AL-PA	TI D	AL-PA	TI D	AL-PA	TI D	AL-PA	TI D	AL-PA	TI D	AL-PA	TI D	AL-PA	TI D	AL-PA	TI D	AL-PA	TI D
-	-	D3	20	B6	4	A3	20	79	4	65	20	49	4	2D	20	0F	4
-	-	D2	19	B5	3	9F	19	76	3	63	19	47	3	2C	19	08	3
-	-	D1	18	B4	2	9E	18	75	2	5C	18	46	2	2B	18	04	2
EF	1	CE	17	B3	1	9D	17	74	1	5A	17	45	1	2A	17	02	1
E8	0	CD	16	B2	0	9B	16	73	0	59	16	43	0	29	16	01	1

Sample configuration definition files

This chapter describes sample configuration definition files for typical CCI configurations.

- [Sample configuration definition files](#)
- [Examples of CCI configurations](#)

Sample configuration definition files

Figure B-1 Configuration Definition of Paired Volumes on page B-2 illustrates the configuration definition of paired volumes. Example B-1 Configuration File Example – UNIX-Based Servers on page B-3 shows a sample configuration file for a UNIX-based operating system. Figure B-2 Configuration File Example – Windows Servers on page B-3 shows a sample configuration file for a Windows operating system.




Figure B-1 Configuration Definition of Paired Volumes

```
HORCM_MON
#ip_address      service      poll(10ms)      timeout(10ms)
HST1             horcm        1000            3000
HORCM_CMD
#unitID 0... (seq#30014)
#dev_name dev_name  dev_name
/dev/rdisk/c0t0d0
#unitID 1... (seq#30015)
#dev_name dev_name  dev_name
/dev/rdisk/clt0d0
HORCM_DEV
#dev_group  dev_name  port#      TargetID  LU#    MU#
oradb       oradb1    CL1-A      3         1      0
oradb       oradb2    CL1-A      3         1      1
oralog      oralog1   CL1-A      5         0
```

```

oralog      oralog2      CL1-A1      5          0
oralog      oralog3      CL1-A1      5          1
oralog      oralog4      CL1-A1      5          1      h1
HORCM_INST
#dev_group  ip_address    service
oradb       HST2         horcm
oradb       HST3         horcm
oralog      HST3         horcm

```

Example B-1 Configuration File Example – UNIX-Based Servers




Figure B-2 Configuration File Example – Windows Servers

The configuration file sets the following parameters:

- [\(1\) HORCM_MON on page B-4](#)
- [\(2\) HORCM_CMD on page B-4](#)
- [\(3\) HORCM_VCMD on page B-7](#)
- [\(4\) HORCM_DEV on page B-8](#)
- [\(5\) HORCM_INST on page B-10](#)
- [\(6\) HORCM_INSTP on page B-14](#)
- [\(7\) HORCM_LDEV on page B-15](#)
- [\(8\) HORCM_LDEVG on page B-15](#)
- [\(9\) HORCM_ALLOW_INST on page B-16](#)

(1) HORCM_MON

The monitor parameter (HORCM_MON) defines the following values:

- **Ip_address:** Specifies the local host name or the IP address of the local host. When you specify the name of a local host that has multiple IP addresses, one of the IP addresses is selected at random and used. If you want to use all IP addresses, specify NONE for IPv4 or NONE6 for IPv6.
- **Service:** Specifies the UDP port name assigned to the HORCM communication path, which is registered in "/etc/services" ("\\WINNT\\system32\\drivers\\etc\\services" in Windows, "SYS\$SYSROOT:[000000.TCPIP\$ETC]SERVICES.DAT" in OpenVMS). If a port number is specified instead of a port name, the port number is used.
- **Poll:** Specifies the interval for monitoring paired volumes in increments of 10 ms. To reduce the HORCM daemon load, make this interval longer. If set to -1, the paired volumes are not monitored. The value of -1 is specified when two or more CCI instances run on a single machine.
- **Timeout:** The time-out period of communication with the remote server. If HORCM_MON is not specified, then the following defaults are set:

HORCM_MON

```
#ip_address service poll(10ms) timeout(10ms)NONE default_port  
1000 3000
```

default_port:

For none specified HORCM instance: "31000 + 0"

For instance HORCM X : "31000 + X + 1"

(2) HORCM_CMD

The command parameter (HORCM_CMD) defines the UNIX device path or Windows physical device number of the command device. The command device must be mapped to the SCSI/fibre using the LUN Manager software. You can define more than one command device to provide failover in case the original command device becomes unavailable (see [About alternate command devices on page 2-15](#)).

To enable dual pathing of the command device under Solaris systems, make sure to include all paths to the command device on a single line in the HORCM_CMD section of the configuration file. Putting the path information on separate lines might cause parsing issues, and failover might not occur unless the HORCM startup script is restarted on the Solaris system.

When a server is connected to two or more storage systems, the HORCM identifies each storage system using the unitID (see [Figure B-3 Configuration and Unit IDs for Multiple Storage Systems on page B-5](#)). The unitID is assigned sequentially in the order described in this section of the configuration definition file. The server must be able to verify that unit ID is the same Serial# (Seq#) with among server when the storage system is shared by two or more servers. This can be verified using the **raidqry** command. The serial number for VSP G1000 is prefixed by a "3" (for example, "312345" = VSP G1000 serial number 12345).




Figure B-3 Configuration and Unit IDs for Multiple Storage Systems

dev_name for Windows

In the Windows SAN environment, "Volume{guid}" is changed on every reboot under MSCS/Windows 2008, if Windows finds the same signature on the command device connected with Multi-Path. Therefore, the user must find NEW "Volume{guid}" and change "Volume{guid}" described in the CCI configuration file. CCI supports the following naming format specifying Serial#/LDEV#/Port# as notation of the command device for only Windows.

\\.\CMD-Ser#-ldev#-Port#

```
HORCM_CMD
#dev_name          dev_name          dev_name
  \\.\CMD-30095-250-CL1-A
```

To allow more flexibility, CCI allows the following format.

- For minimum specification. Specifies to use any command device for Serial#30095

\\.\CMD-30095

If Windows has two different array models that share the same serial number, fully define the serial number, ldev#, port and host group for the CMDDEV.

- For under Multi Path Driver. Specifies to use any port as the command device for Serial#30095, LDEV#250

\\.\CMD-30095-250

- For full specification. Specifies the command device for Serial#30095, LDEV#250 connected to Port CL1-A, Host group#1

\\.\CMD-30095-250-CL1-A-1

- Other examples

\\.\CMD-30095-250-CL1-A \\.\CMD-30095-250-CL1

dev_name for UNIX

In UNIX SAN environment, there are situations when the device file name is changed, a failover operation in UNIX SAN environment or every reboot under Linux when the SAN is reconfigured. The CCI user needs to find NEW "Device Special File" and change HORCM_CMD described in the CCI configuration file. Thus, CCI supports the following naming format specifying Serial#/LDEV#/Port#: **HINT** as notation of the command device **for UNIX**:

\\.\CMD-Ser#-Ldev#-Port#:HINT

HORCM_CMD

#dev_name

dev_name

dev_name

\\.\CMD-30095-250-CL1-A-1:/dev/rdisk/

If these names are specified, HORCM finds "\\.\CMD-Serial#-Ldev#-Port#" from the device files specified by **HINT** at HORCM start-up. HINT must be specified "directory terminated with '/' on the device file name" or "directory including device file name pattern" as below, for example:

/dev/rdisk/ → this finds a specified CMD from /dev/rdisk/*
/dev/rdisk/cl0 → this finds a specified CMD from /dev/rdisk/cl0*
/dev/rhdisk → this finds a specified CMD from /dev/rhdisk*

The device files discovered during HINT are filtered with the following pattern:

- HP-UX: /dev/rdisk/* or /dev/rdisk/disk*
- Solaris: /dev/rdisk/*s2
- AIX: /dev/rhdisk*
- Linux: /dev/sd....
- z/Linux: /dev/sd....
- Tru64: /dev/rrz*c or /dev/rdisk/dsk*c or /dev/cport/scp*
- IRIX64: /dev/rdisk/*vol or /dev/rdisk/node_wwn/*vol/*

If a HINT is already specified, "**:HINT**" can be omitted for next command devices, and then a command device is found from the cached Inquiry information of HORCM for saving unnecessary device scanning.

HORCM_CMD

#dev_name

dev_name

dev_name

\\.\CMD-30095-250-CL1:/dev/rdisk/

\\.\CMD-30095-250-CL2

Example for minimum specification. Specifies to use any command device for Serial#30095:

\\.\CMD-30095:/dev/rdisk/

Example for under Multi Path Driver. Specifies to use any port as the command device for Serial#30095, LDEV#250:

\\.\CMD-30095-250:/dev/rdisk/

Example for full specification. Specifies the command device for Serial#30095, LDEV#250 connected to Port CL1-A, Host group#1:

```
\\.\CMD-30095-250-CL1-A-1:/dev/rdisk/
```

Other examples:

```
\\.\CMD-30095-250-CL1:/dev/rdisk/
```

```
\\.\CMD-30095-250-CL2
```

```
\\.\CMD-30095:/dev/rdisk/c1
```

```
\\.\CMD-30095:/dev/rdisk/c2
```



Note: If the hardware configuration is changed during the time an OS is running in Linux, the name of a special file corresponding to the command device might be changed. At this time, if HORCM was started by specifying the special file name in the configuration definition file, HORCM cannot detect the command device, and the communication with the storage system will fail. To prevent this failure, specify the path name allocated by udev to the configuration definition file as follows before booting HORCM. In this example, the path name for /dev/sdgh can be found.

1. Find the special file name of the command device by using the `inqraid` command.

Command example:

```
[root@myhost ~]# ls /dev/sd* | /HORCM/usr/bin/inqraid -CLI |  
grep CM  
sda CL1-B 30095 0 - - 0000 A:00000 OPEN-V-CM  
sdgh CL1-A 30095 0 - - 0000 A:00000 OPEN-V-CM  
[root@myhost ~]#
```

2. Find the path name from the by-path directory.

Command example:

```
[root@myhost ~]# ls -l /dev/disk/by-path/ | grep sdgh  
lrwxrwxrwx. 1 root root 10 Jun 11 17:04 2015 pci-0000:08:00.0-  
fc-0x50060e8010311940-lun-0 -> ../../sdgh  
[root@myhost ~]#
```

In this example, `pci-0000:08:00.0-fc-0x50060e8010311940-lun-0` is the path name.

3. Enter the path name to HORCM_CMD in the configuration definition file as follows.

```
HORCM_CMD  
/dev/disk/by-path/pci-0000:08:00.0-fc-0x50060e8010311940-lun-0
```

4. Boot the HORCM instance as usual.
-

(3) HORCM_VCMD

This parameter specifies the serial number of the virtual storage machine to be operated by this instance.

You cannot use virtual storage machines whose serial numbers are not specified in HORCM_VCMD. To use more than one virtual storage machine from a CCI instance, specify each serial number on a separate line in HORCM_VCMD. To use the virtual storage machine specified in the second line or higher of HORCM_VCMD, use the command options (for example, `-s <seq#>` or `-u <unit id>`). If you omit these command options, the first virtual storage machine specified is used. If you specify a virtual storage

machine whose serial number is not specified in HORCM_VCMD using the command option (-s <seq#> or -u <Unit ID>), the EX_ENOUNT error occurs.

(4) HORCM_DEV

The device parameter (HORCM_DEV) defines the RAID storage system device addresses for the paired logical volume names. When the server is connected to two or more storage systems, the unit ID is expressed by port number extension. Each group name is a unique name discriminated by a server which uses the volumes, the data attributes of the volumes (such as database data, log file, UNIX file), recovery level, and so on. The group and paired logical volume names described in this item must reside in the remote server. The hardware SCSI/fibre port, target ID, and LUN as hardware components need not be the same.

The following values are defined in the HORCM_DEV parameter:

- dev_group: Names a group of paired logical volumes. A command is executed for all corresponding volumes according to this group name.
- dev_name: Names the paired logical volume within a group (i.e., name of the special file or unique logical volume). The name of paired logical volume must be different than the "dev name" on another group.
- Port#: Defines the RAID storage system port number of the volume that corresponds with the dev_name volume. The following "n" shows unit ID when the server is connected to two or more storage systems (for example, CL1-A1 = CL1-A in unit ID 1). If the "n" option is omitted, the unit ID is 0. The port is not case sensitive (for example, CL1-A= cl1-a= CL1-a= cl1-A).

Port	Basic				Option				Option				Option			
CL1	An	Bn	Cn	Dn	En	Fn	Gn	Hn	Jn	Kn	Ln	Mn	Nn	Pn	Qn	Rn
CL2	An	Bn	Cn	Dn	En	Fn	Gn	Hn	Jn	Kn	Ln	Mn	Nn	Pn	Qn	Rn

The following ports can only be specified for the 9900V:

Port	Basic				Option				Option				Option			
CL3	an	bn	cn	dn	en	fn	gn	hn	jn	kn	ln	mn	nn	pn	qn	rn
CL4	an	bn	cn	dn	en	fn	gn	hn	jn	kn	ln	mn	nn	pn	qn	rn

For 9900V, CCI supports four types of port names for host groups:

- Specifying the port name without a host group:
CL1-A**n** where **n** : unit ID for multiple RAID
- Specifying the port without a host group:
CL1-A-**g** where **g** : host group
CL1-A**n-g** where **n-g** : host group=**g** on CL1-A in unit ID=**n**

The following ports can only be specified for Universal Storage Platform/TagmaStore NSC and USP V/VM:

Port	Basic				Option				Option				Option			
CL5	an	bn	cn	dn	en	fn	gn	hn	jn	kn	ln	mn	nn	pn	qn	rn
CL6	an	bn	cn	dn	en	fn	gn	hn	jn	kn	ln	mn	nn	pn	qn	rn
CL7	an	bn	cn	dn	en	fn	gn	hn	jn	kn	ln	mn	nn	pn	qn	rn
CL8	an	bn	cn	dn	en	fn	gn	hn	jn	kn	ln	mn	nn	pn	qn	rn
CL9	an	bn	cn	dn	en	fn	gn	hn	jn	kn	ln	mn	nn	pn	qn	rn
CLA	an	bn	cn	dn	en	fn	gn	hn	jn	kn	ln	mn	nn	pn	qn	rn
CLB	an	bn	cn	dn	en	fn	gn	hn	jn	kn	ln	mn	nn	pn	qn	rn
CLC	an	bn	cn	dn	en	fn	gn	hn	jn	kn	ln	mn	nn	pn	qn	rn
CLD	an	bn	cn	dn	en	fn	gn	hn	jn	kn	ln	mn	nn	pn	qn	rn
CLE	an	bn	cn	dn	en	fn	gn	hn	jn	kn	ln	mn	nn	pn	qn	rn
CLF	an	bn	cn	dn	en	fn	gn	hn	jn	kn	ln	mn	nn	pn	qn	rn
CLG	an	bn	cn	dn	en	fn	gn	hn	jn	kn	ln	mn	nn	pn	qn	rn

- **Target ID:** Defines the SCSI/fibre target ID number of the physical volume on the specified port. See [Fibre/FCoE-to-SCSI address conversion on page A-2](#) for further information about fibre address conversion.
- **LU#:** Defines the SCSI/fibre logical unit number (LU#) of the physical volume on the specified target ID and port.

For fibre channel, if the TID and LU# displayed on the system are different from the TID on the fibre address conversion table, then use the TID and LU# indicated by the **raidscan** command in the CCI configuration file.

- **MU# for ShadowImage/Copy-on-Write Snapshot:** Defines the mirror unit number (0 - 2) if using redundant mirror for the identical LU on ShadowImage. If this number is omitted it is assumed to be zero (0). The cascaded mirroring of the S-VOL is expressed as virtual volumes using the mirror descriptors (MU#1-2) in the configuration definition file. The MU#0 of a mirror descriptor is used for connection of the S-VOL. The mirror descriptor (MU#0-2) can be used on ShadowImage and Copy-on-Write Snapshot. MU#3-63 can be used only on Copy-on-Write Snapshot.



Note: When you enter the MU number for a ShadowImage/Copy-on-Write Snapshot pair into the configuration definition file, enter only the number, for example, "0" or "1".

Feature	SMPL		P-VOL		S-VOL	
	MU#0-2	MU#3-63	MU#0-2	MU#3-63	MU#0	MU#1-63
ShadowImage	Valid	Not valid	Valid	Not valid	Valid	Not valid
Copy-on-Write Snapshot	Valid	Valid	Valid	Valid	Valid	Valid

- MU# for TrueCopy/Universal Replicator/global-active device: Defines the mirror unit number (0 - 3) if using redundant mirror for the identical LU on TC/UR/GAD. If this number is omitted, it is assumed to be (MU#0). You can specify only MU#0 for TrueCopy, and 4 MU numbers (MU#0 - 3) for Universal Replicator and global-active device.



Note: When you enter the MU number for a TC/UR/GAD pair into the configuration definition file, add an "h" before the number, for example, "h0" or "h1".

State/ Feature	SMPL		P-VOL		S-VOL	
	MU#0	MU#1 - 3	MU#0	MU#1 - 3	MU#0	MU#1 - 3
TrueCopy	Valid	Not valid	Valid	Not valid	Valid	Not valid
Universal Replicator	Valid	Valid	Valid	Valid	Valid	Valid

(5) HORCM_INST

The instance parameter (HORCM_INST) defines the network address (IP address) of the remote server (active or standby). It is used to refer to or change the status of the paired volume in the remote server (active or standby). When the primary volume is shared by two or more servers, there are two or more remote servers using the secondary volume. Thus, it is necessary to describe the addresses of all of these servers.

The following values are defined in the HORCM_INST parameter:

- dev_group: The server name described in dev_group of HORC_DEV.
- ip_address: The network address of the specified remote server.
- service: The port name assigned to the HORCM communication path (registered in the `/etc/services` file). If a port number is specified instead of a port name, the port number is used.

A configuration for multiple networks can be found using `raidqry -r <group>` command option on each host. The current network address of HORCM can be changed using `horcctl -NC <group>` on each host.

When you use all IP addresses of the local host in the configuration for multiple networks, specify NONE (IPv4) or NONE6 (IPv6) as the ip_address of HORCM_MON parameter.




Figure B-4 Configuration for Multiple Networks

For example:

```
# horcctl -ND -g IP46G
```

```
Current network address = 158.214.135.106, services = 50060# horcctl -
NC -g IP46G
```

```
Changed network address(158.214.135.106,50060 ->
fe80::39e7:7667:9897:2142,50060)
```

For IPv6 only, the configuration must be defined as HORCM/IPv6.





Figure B-5 Network Configuration for IPv6

It is possible to communicate between HORCM/IPv4 and HORCM/IPv6 using IPv4 mapped to IPv6.



Host 1 (Left)	Host 2 (Right)
<pre> HORCM_MON #ip_address service poll(10ms) timeout(10ms) NONE horcm4 1000 3000 #158.214.127.64 horcm4 1000 3000 #/****** For HORCM_CMD *****/ HORCM_CMD #dev_name #UnitID 0 (Serial# 63502) /dev/rdsdsk/c1t0d0s2 #/****** For HORCM_LDEV *****/ HORCM_LDEV #dev_group dev_name Serial# LDEV# MU# IPM4G dev1 63502 577 #/****** For HORCM_INST *****/ HORCM_INST #dev_group ip_address service IPM4G 158.214.135.105 horcm 6 </pre>	<pre> HORCM_MON #ip_address service poll(10ms) timeout(10ms) NONE6 horcm6 1000 3000 #::ffff: 158.214.135.105 horcm6 1000 3000 #/****** For HORCM_CMD *****/ HORCM_CMD #dev_name #UnitID 0 (Serial# 63502) /dev/rdsdsk/c1t0d0s2 #/****** For HORCM_LDEV *****/ HORCM_LDEV #dev_group dev_name Serial# LDEV# MU# IPM4G dev1 63502 677 #/****** For HORCM_INST *****/ HORCM_INST #dev_group ip_address service IPM4G ::ffff:158.214. 127.64 horcm 4 IPM4G 158.214.127.64 horcm 4 </pre>

"::
 If IP_address will be specified with IPv4 format, then HORCM
 converts to IPv4 mapped IPv6.

Figure B-6 Network Configuration for IPv4 Mapped IPv6

In the case of mixed IPv4 and IPv6, it is possible to communicate between HORCM/IPv4 and HORCM/IPv6 and HORCM/IPv6 using IPv4 mapped to IPv6 and native IPv6.




Figure B-7 Network Configuration for Mixed IPv4 and IPv6

(6) HORCM_INSTP

This parameter is used to specify "pathID" for TrueCopy, Universal Replicator, and global-active device link as well as "HORCM_INST". PathID must be specified from 1 to 255. If you do not specify the PathID, the behavior is the same as when 'HORCM_INST' is used.

```

HORCM_INSTP
dev_group      ip_address      service      pathID
VG01           HSTA             horcm       1
VG02           HSTA             horcm       2

```

Note: The path ID can be specified at TrueCopy, Universal Replicator, Universal Replicator for Mainframe, and global-active device. However, the path ID cannot be specified at UR/URz when connecting TagmaStore USP/

TagmaStore NSC or USP V/VM. The same path ID must be specified between the site of P-VOL and S-VOL because the path ID is used at the paircreate command.

(7) HORCM_LDEV

The HORCM_LDEV parameter is used for specifying stable LDEV# and Serial# as the physical volumes corresponding to the paired logical volume names. Each group name is unique and typically has a name fitting its use (for example, database data, Redo log file, UNIX file). The group and paired logical volume names described in this item must also be known to the remote server.

- dev_group: This parameter is the same as HORCM_DEV parameter.
- dev_name: This parameter is the same as HORCM_DEV parameter.
- MU#: This parameter is the same as HORCM_DEV parameter.
- Serial#: This parameter is used to describe the Serial number of RAID box.
- CU:LDEV(LDEV#): This parameter is used to describe the LDEV number in the RAID storage system and supports three types of format as LDEV#.

#dev_group	dev_name	Serial#	CU:LDEV (LDEV#)	MU#
oradb	dev1	30095	02:40	0
oradb	dev2	30095	02:41	0

- Specifying "CU:LDEV" in hex used by SVP/GUM or Web console.
Example for LDEV# 260 01: 04
- Specifying "LDEV" in decimal used by the inqraid command of CCI.
Example for LDEV# 260 260
- Specifying "LDEV" in hex used by the inqraid command of CCI.
Example for LDEV# 260 0x104

(8) HORCM_LDEVG

The HORCM_LDEVG parameter defines the device group information that the CCI instance reads. For details about device group, see the *Command Control Interface User and Reference Guide*.

The following values are defined.

- Copy group: specifies a name of copy group. This is equivalent to the dev_group of HORCM_DEV and HORCM_LDEV parameters.
CCI operates by using the information defined here.
- ldev_group: Specifies a name of device group that the CCI instance reads.
- Serial#: Specifies the storage system serial number.

HORCM_LDEVG		
#Copy_Group	ldev_group	Serial#
ora	grp1	64034

(9) HORCM_ALLOW_INST

This parameter is used to restrict the users using the virtual command device. The following IP addresses and port numbers are allowed:

```
For IPv4
HORCM_ALLOW_INST
#ip_address      service
158.214.135.113  34000
158.214.135.114  34000

For IPv6
HORCM_ALLOW_INST
#ip_address      service
fe80::209:6bff:febe:3c17  34000
```

Service in the above example means the initiator port number of HORCM.

If CCI clients not defined HORCM_ALLOW_INST, HORCM instance starting up is rejected by SCSI check condition (SKEY=0x05, ASX=0xfe) and CCI cannot be started up.

Examples of CCI configurations

The following examples show CCI configurations, the configuration definition file(s) for each configuration, and examples of CCI command use for each configuration.

The command device is defined using the system raw device name (character-type device file name). For example, the command devices for the following figure would be:

- **HP-UX:**
HORCM_CMD of HOSTA = /dev/rdisk/c0t0d1 HORCM_CMD of HOSTB = /dev/rdisk/clt0d1
- **Solaris:**
HORCM_CMD of HOSTA = /dev/rdisk/c0t0d1s2 HORCM_CMD of HOSTB = /dev/rdisk/clt0d1s2
For Solaris operations with CCI version 01-09-03/04 and higher, the command device does not need to be labeled during format command.
- **AIX:**
HORCM_CMD of HOSTA = /dev/rhdiskXX HORCM_CMD of HOSTB = /dev/rhdiskXX
where XX = device number assigned by AIX
- **Tru64 UNIX:**
HORCM_CMD of HOSTA = /dev/rrzbXXc HORCM_CMD of HOSTB = /dev/rrzbXXc
where XX = device number assigned by Tru64 UNIX
- **Windows 2008:**
HORCM_CMD of HOSTA = \\.\CMD-Ser#-ldev#-Port# HORCM_CMD of HOSTB = \\.\CMD-Ser#-ldev#-Port#
- **Linux, z/Linux:**

HORCM_CMD of HOSTA = /dev/sdX HORCM_CMD of HOSTB = /dev/sdX
 where X = device number assigned by Linux, z/Linux

- **IRIX:**

HORCM_CMD for HOSTA/dev/rdsd/dks0d011vol or /dev/rdsd/
 node_wwn/lun1vol/c0p0

HORCM_CMD for HOSTB/dev/rdsd/dks1d011vol or /dev/rdsd/
 node_wwn/lun1vol/c1p0




Figure B-8 TrueCopy Remote Configuration Example

Example of CCI commands with HOSTA:

- Designate a group name (Oradb) and a local host P-VOL a case.

```
# paircreate -g Oradb -f never -vl
```

This command creates pairs for all LUs assigned to group Oradb in the configuration definition file (two pairs for the configuration in the above figure).

- Designate a volume name (oradev1) and a local host P-VOL a case.

```
# paircreate -g Oradb -d oradev1 -f never -vl
```

This command creates pairs for all LUs designated as oradev1 in the configuration definition file (CL1-A,T1,L1 and CL1-D,T2,L1 for the configuration in the above figure).

- Designate a group name and display pair status.

```
# pairdisplay -g Oradb
Group PairVol(L/R) P,T#,L#), #, LDEV#..P/S, Status, Fence,
#, P-LDEV# M
oradb oradev1(L) (CL1-A, 1,1) 30053 18...P-VOL COPY
NEVER, 30054 19 -
oradb oradev1(R) (CL1-D, 2,1) 30054 19...S-VOL COPY
NEVER, ----- 18 -
oradb oradev2(L) (CL1-A, 1,2) 30053 20...P-VOL COPY
NEVER, 30054 21 -
oradb oradev2(R) (CL1-D, 2,2) 30054 21...S-VOL COPY
NEVER , ----- 20 -
```

Example of CCI commands with HOSTB:

- Designate a group name and a remote host P-VOL a case.

```
# paircreate -g Oradb -f never -vr
```

This command creates pairs for all LU designated as Oradb in the configuration definition file (two pairs for the configuration in the above figure).

- Designate a volume name (oradev1) and a remote host P-VOL a case.

```
# paircreate -g Oradb -d oradev1 -f never -vr
```

This command creates pairs for all LUs designated as oradev1 in the configuration definition file (CL1-A,T1,L1 and CL1-D,T2,L1 for the configuration in the above figure).

- Designate a group name and display pair status.

```
# pairdisplay -g Oradb
Group PairVol (L/R) (P,T#,L#), Seq#, LDEV#..P/S, Status,
Fence, Seq#, P-LDEV# M
oradb oradev1 (L) (CL1-D, 2,1) 30054 19...S-VOL COPY
NEVER, ----- 18 -
oradb oradev1 (R) (CL1-A, 1,1) 30053 18...P-VOL COPY
NEVER, 30054 19 -
oradb oradev2 (L) (CL1-D, 2,2) 30054 21...S-VOL COPY
NEVER, ----- 20 -
oradb oradev2 (R) (CL1-A, 1,2) 30053 20...P-VOL COPY
NEVER, 30054 21 -
```

The command device is defined using the system raw device name (character-type device file name). For example, the command devices for the following figure would be:

- **HP-UX:**

```
HORCM_CMD of HOSTA = /dev/rdisk/c0t0d1 HORCM_CMD of HOSTB = /dev/
rdisk/clt0d1
```

- **Solaris:**

```
HORCM_CMD of HOSTA = /dev/rdisk/c0t0d1s2 HORCM_CMD of HOSTB
= /dev/rdisk/clt0d1s2
```

For Solaris operations with CCI version 01-09-03/04 and higher, the command device does not need to be labeled during format command.

- **AIX:**

```
HORCM_CMD of HOSTA = /dev/rhdiskXX HORCM_CMD of HOSTB = /dev/
rhdiskXX
```

where XX = device number assigned by AIX

- **Tru64 UNIX:**

```
HORCM_CMD of HOSTA = /dev/rdisk/dskXXc HORCM_CMD of HOSTB = /dev/
rdisk7/dskXXc
```

where XX = device number assigned by Tru64 UNIX

- **Windows 2012/2008:**

```
HORCM_CMD of HOSTA = \\.\CMD-Ser#-ldev#-Port# HORCM_CMD of HOSTB
= \\.\CMD-Ser#-ldev#-Port#
```


- **Linux, z/Linux:**

```
HORCM_CMD of HOSTA = /dev/sdX HORCM_CMD of HOSTB = /dev/sdX
```

where X = disk number assigned by Linux, z/Linux

- **IRIX64:**

HORCM_CMD for HOSTA .../dev/rdsk/dks0d0l1vol or /dev/rdsk/
node_wwn/lun1vol/c0p0
HORCM_CMD for HOSTB .../dev/rdsk/dks1d0l1vol or /dev/rdsk/
node_wwn/lun1vol/c1p0



Configuration file for HOSTA(/etc/horcm.conf)	Configuration file for HOSTB(/etc/horcm.conf)
<pre> HORCM_MON #ip address service poll(10ms) timeout(10ms) HST1 horcm 1000 3000 HORCM_CMD #dev_name /dev/xxx [Note 1] HORCM_DEV #dev_group dev_name port# TargetID LU# oradb oradev1 CL1-A 1 1 oradb oradev2 CL1-A 1 2 HORCM_INST #dev_group ip_address service Oradb HST2 horcm </pre>	<pre> HORCM_MON #ip address service poll(10ms) timeout(10ms) HST2 horcm 1000 3000 HORCM_CMD #dev_name /dev/xxx [Note 1] HORCM_DEV #dev_group dev_name port# TargetID LU# oradb oradev1 CL1-D 2 1 oradb oradev2 CL1-D 2 2 HORCM_INST #dev_group ip_address service Oradb HST1 horcm </pre>

Figure B-9 TrueCopy Local Configuration Example

[Note 1] : Input the raw device (character device) name of UNIX/Windows system for command device.

Example of CCI commands with HOSTA:

- Designate a group name (Oradb) and a local host P- VOL a case.

```
# paircreate -g Oradb -f never -vl
```

This command creates pairs for all LUs assigned to group Oradb in the configuration definition file (two pairs for the configuration in above figure).

- Designate a volume name (oradev1) and a local host P-VOL a case.

```
# paircreate -g Oradb -d oradev1 -f never -vl
```

This command creates pairs for all LUs designated as oradev1 in the configuration definition file (CL1-A,T1,L1 and CL1-D,T2,L1 for the configuration in above figure).

- Designate a group name and display pair status.

```
# pairdisplay -g Oradb
Group PairVol (L/R) (P,T#,L#), Seq#, LDEV#..P/S, Status,
Fence, Seq#, P-LDEV# M
oradb oradev1 (L) (CL1-A, 1,1) 30053 18.. P-VOL COPY
NEVER, 30053 19 -
oradb oradev1 (R) (CL1-D, 2,1) 30053 19.. S-VOL COPY
NEVER, ----- 18 -
oradb oradev2 (L) (CL1-A, 1,2) 30053 20.. P-VOL COPY
NEVER, 30053 21 -
oradb oradev2 (R) (CL1-D, 2,2) 30053 21.. S-VOL COPY
NEVER, ----- 20 -
```

Example of CCI commands with HOSTB:

- Designate a group name and a remote host P-VOL a case.

```
# paircreate -g Oradb -f never -vr
```

This command creates pairs for all LU designated as Oradb in the configuration definition file (two pairs for the configuration in figure above).

- Designate a volume name (oradev1) and a remote host P-VOL a case.

```
# paircreate -g Oradb -d oradev1 -f never -vr
```

This command creates pairs for all LUs designated as oradev1 in the configuration definition file (CL1-A,T1,L1 and CL1-D,T2,L1 for the configuration in above figure).

- Designate a group name and display pair status.

```
# pairdisplay -g Oradb
Group PairVol (L/R) (P,T#,L#), Seq#,LDEV#..P/S, Status,
Fence,Seq#,P-LDEV# M
oradb oradev1 (L) (CL1-D, 2,1) 30053 19.. S-VOL COPY
NEVER ,----- 18 -
oradb oradev1 (R) (CL1-A, 1,1) 30053 18.. P-VOL COPY
NEVER ,30053 19 -
oradb oradev2 (L) (CL1-D, 2,2) 30053 21.. S-VOL COPY
NEVER ,----- 20 -
oradb oradev2 (R) (CL1-A, 1,2) 30053 20.. P-VOL COPY
NEVER ,30053 21 -
```

The command device is defined using the system raw device name (character-type device file name). The command device defined in the

configuration definition file must be established in a way to be following either every instance. If one command device is used between different instances on the same SCSI port, then the number of instances is up to 16 per command device. If this restriction is exceeded, then use a different SCSI path for each instance. For example, the command devices for the following figure would be:

- **HP-UX:**

```
HORCM_CMD of HORCMINST0 = /dev/rdisk/c0t0d1
HORCM_CMD of HORCMINST1 = /dev/rdisk/c1t0d1
```

- **Solaris:**

```
HORCM_CMD of HORCMINST0 = /dev/rdisk/c0t0d1s2
HORCM_CMD of HORCMINST1 = /dev/rdisk/c1t0d1s2
```

For Solaris operations with CCI version 01-09-03/04 and higher, the command device does not need to be labeled during format command.

- **AIX:**

```
HORCM_CMD of HORCMINST0 = /dev/rhdiskXX
HORCM_CMD of HORCMINST1 = /dev/rhdiskXX
```

where XX = device number assigned by AIX

- **Tru64 UNIX:**

```
HORCM_CMD of HORCMINST0 = /dev/rrzbXXc
HORCM_CMD of HORCMINST1 = /dev/rrzbXXc
```

where XX = device number assigned by Tru64 UNIX

- **Windows 2012/2008:**

```
HORCM_CMD of HORCMINST0 = \\.\CMD-Ser#-ldev#-Port#
HORCM_CMD of HORCMINST1 = \\.\CMD-Ser#-ldev#-Port#
```

- **Linux, z/Linux:**

```
HORCM_CMD of HORCMINST0 = /dev/sdX
HORCM_CMD of HORCMINST1 = /dev/sdX
```

where X = device number assigned by Linux, z/Linux

- **IRIX64:**

```
HORCM_CMD for HOSTA (/etc/horcm0.conf)...
/dev/rdisk/dks0d0l1vol or /dev/rdisk/node_wwn/lun1vol/c0p0
HORCM_CMD for HOSTB (/etc/horcm1.conf)...
/dev/rdisk/dks1d0l1vol or /dev/rdisk/node_wwn/lun1vol/c1p0
```




Figure B-10 TrueCopy Configuration Example for Two Instances

[Note 1] : Input the raw device (character device) name of UNIX/Windows system for command device.

Example of CCI commands with Instance-0 on HOSTA:

- When the command execution environment is not set, set an instance number.

For C shell: # setenv HORCMINST 0

For Windows: set HORCMINST=0

- Designate a group name (Oradb) and a local instance P- VOL a case.

```
# paircreate -g Oradb -f never -vl
```

This command creates pairs for all LUs assigned to group Oradb in the configuration definition file (two pairs for the configuration in above figure).

- Designate a volume name (oradev1) and a local instance P-VOL a case.

```
# paircreate -g Oradb -d oradev1 -f never -vl
```

This command creates pairs for all LUs designated as oradev1 in the configuration definition file (CL1-A,T1,L1 and CL1-D,T2,L1 for the configuration in above figure).

- Designate a group name and display pair status.

```
# pairdisplay -g Oradb
Group PairVol(L/R) (P,T#,L#), Seq#, LDEV#.. P/S, Status,
Fence, Seq#, P-LDEV# M
oradb oradev1(L) (CL1-A, 1,1) 30053 18.. P-VOL COPY
NEVER, 30053 19 -
oradb oradev1(R) (CL1-D, 2,1) 30053 19.. S-VOL COPY
NEVER, ----- 18 -
oradb oradev2(L) (CL1-A, 1,2) 30053 20.. P-VOL COPY
NEVER, 30053 21 -
oradb oradev2(R) (CL1-D, 2,2) 30053 21.. S-VOL COPY
NEVER, ----- 20 -
```

Example of CCI commands with Instance-1 on HOSTA:

- When the command execution environment is not set, set an instance number.

For C shell: # setenv HORCMINST 1

For Windows: set HORCMINST=1

- Designate a group name and a remote instance P-VOL a case.

```
# paircreate -g Oradb -f never -vr
```

This command creates pairs for all LU designated as Oradb in the configuration definition file (two pairs for the configuration in above figure).

- Designate a volume name (oradev1) and a remote instance P-VOL a case.

```
# paircreate -g Oradb -d oradev1 -f never -vr
```

This command creates pairs for all LUs designated as oradev1 in the configuration definition file (CL1-A,T1,L1 and CL1-D,T2,L1 for the configuration in above figure).

- Designate a group name and display pair status.

```
# pairdisplay -g Oradb
Group PairVol(L/R) (P,T#,L#), Seq#, LDEV#.. P/S, Status,
Fence, Seq#, P-LDEV# M
oradb oradev1(L) (CL1-D, 2,1) 30053 19.. S-VOL COPY
NEVER , ----- 18 -
oradb oradev1(R) (CL1-A, 1,1) 30053 18.. P-VOL COPY
NEVER , 30053 19 -
```

```

oradb  oradev2 (L)      (CL1-D, 2,2) 30053  21..    S-VOL COPY
NEVER , ----- 20      -
oradb  oradev2 (R)      (CL1-A, 1,2) 30053  20..    P-VOL COPY
NEVER , 30053 21      -

```

The command device is defined using the system raw device name (character-type device file name). For example, the command devices for the following figures would be:

- **HP-UX:**

```

HORCM_CMD of HOSTA = /dev/rdisk/c0t0d1
HORCM_CMD of HOSTB = /dev/rdisk/clt0d1
HORCM_CMD of HOSTC = /dev/rdisk/clt0d1
HORCM_CMD of HOSTD = /dev/rdisk/clt0d1

```

- **Solaris:**

```

HORCM_CMD of HOSTA = /dev/rdisk/c0t0d1s2
HORCM_CMD of HOSTB = /dev/rdisk/clt0d1s2
HORCM_CMD of HOSTC = /dev/rdisk/clt0d1s2
HORCM_CMD of HOSTD = /dev/rdisk/clt0d1s2

```

For Solaris operations with CCI version 01-09-03/04 and higher, the command device does not need to be labeled during format command.

- **AIX:**

```

HORCM_CMD of HOSTA = /dev/rhdiskXX
HORCM_CMD of HOSTB = /dev/rhdiskXX
HORCM_CMD of HOSTC = /dev/rhdiskXX
HORCM_CMD of HOSTD = /dev/rhdiskXX

```

where XX = device number created automatically by AIX

- **Tru64 UNIX:**

```

HORCM_CMD of HOSTA = /dev/rrzbXXc
HORCM_CMD of HOSTB = /dev/rrzbXXc
HORCM_CMD of HOSTC = /dev/rrzbXXc
HORCM_CMD of HOSTD = /dev/rrzbXXc

```

where XX = device number defined by Tru64 UNIX

- **Windows 2012/2008:**

```

HORCM_CMD of HOSTA = \\.\CMD-Ser#-ldev#-Port#
HORCM_CMD of HOSTB = \\.\CMD-Ser#-ldev#-Port#
HORCM_CMD of HOSTC = \\.\CMD-Ser#-ldev#-Port#
HORCM_CMD of HOSTD = \\.\CMD-Ser#-ldev#-Port#

```

- **Linux, z/Linux:**

```

HORCM_CMD of HOSTA = /dev/sdX HORCM_CMD of HOSTB = /dev/sdX
HORCM_CMD of HOSTC = /dev/sdX HORCM_CMD of HOSTD = /dev/sdX

```

where X = disk number defined by Linux, z/Linux

- **IRIX64:**

```

HORCM_CMD for HOSTA ... /dev/rdisk/dks0d011vol or /dev/rdisk/
node_wnn/lun1vol/c0p0
HORCM_CMD for HOSTB ... /dev/rdisk/dks1d011vol or /dev/rdisk/
node_wnn/lun1vol/clp0
HORCM_CMD for HOSTC ... /dev/rdisk/dks1d011vol or /dev/rdisk/
node_wnn/lun1vol/clp0

```

HORCM_CMD for HOSTD ... /dev/rdisk/dks1d011vol or /dev/rdisk/
node_wnn/lun1vol/clp0




Figure B-11 ShadowImage Configuration Example (continues on the next page)




Figure B-12 ShadowImage Configuration Example (continued)

[Note 1] : Input the raw device (character device) name of UNIX/Windows system for command device.

Example of CCI commands with HOSTA (group Oradb):

- When the command execution environment is not set, set HORCC_MRCF to the environment variable.

For C shell: # setenv HORCC_MRCF 1

Windows: set HORCC_MRCF=1

- Designate a group name (Oradb) and a local host P-VOL a case.

```
# paircreate -g Oradb -vl
```

This command creates pairs for all LUs assigned to group Oradb in the configuration definition file (two pairs for the configuration in above figure).

- Designate a volume name (oradev1) and a local host P-VOL a case.

```
# paircreate -g Oradb -d oradev1 -vl
```

This command creates pairs for all LUs designated as oradev1 in the configuration definition file (CL1-A,T1,L1 and CL1-D,T2,L1 for the configuration in the above figure).

- Designate a group name and display pair status.

```
# pairdisplay -g Oradb
Group   PairVol (L/R) (Port#,TID,LU-M), Seq#, LDEV#..P/S,
Status, Seq#, P-LDEV# M
oradb   oradev1 (L) (CL1-A, 1,1 - 0) 30053 18..P-VOL
COPY    30053 20 -
oradb   oradev1 (R) (CL2-B, 2,1 - 0) 30053 20..S-VOL
COPY    ----- 18 -
oradb   oradev2 (L) (CL1-A, 1,2 - 0) 30053 19..P-VOL
COPY    30053 21 -
oradb   oradev2 (R) (CL2-B, 2,2 - 0) 30053 21..S-VOL
COPY    ----- 19 -
```

Example of CCI commands with HOSTB (group Oradb):

- When the command execution environment is not set, set HORCC_MRCF to the environment variable.

For C shell: # setenv HORCC_MRCF 1

Windows: set HORCC_MRCF=1

- Designate a group name and a remote host P-VOL a case.

```
# paircreate -g Oradb -vr
```

This command creates pairs for all LUs assigned to group Oradb in the configuration definition file (two pairs for the configuration in the above figure).

- Designate a volume name (oradev1) and a remote host P-VOL a case.

```
# paircreate -g Oradb -d oradev1 -vr
```

This command creates pairs for all LUs designated as oradev1 in the configuration definition file (CL1-A,T1,L1 and CL1-D,T2,L1 for the configuration in the above figure).

- Designate a group name and display pair status.

```
# pairdisplay -g Oradb
Group   PairVol (L/R) (Port#,TID,LU-M), Seq#, LDEV#..P/S,
Status, Seq#, P-LDEV# M
oradb   oradev1 (L) (CL2-B, 2,1 - 0) 30053 20..S-VOL
COPY    ----- 18 -
oradb   oradev1 (R) (CL1-A, 1,1 - 0) 30053 18..P-VOL
COPY    30053 20 -
```

```

oradb   oradev2 (L)      (CL2-B, 2,2 - 0)  30053  21..S-VOL
COPY    ----- 19      -
oradb   oradev2 (R)      (CL1-A, 1,2 - 0)  30053  19..P-VOL
COPY    30053  21      -

```

Example of CCI commands with HOSTA (group Oradb1):

- When the command execution environment is not set, set HORCC_MRCF to the environment variable.

For C shell: # setenv HORCC_MRCF 1

For Windows: set HORCC_MRCF=1

- Designate a group name (Oradb1) and a local host P-VOL a case.

```
# paircreate -g Oradb1 -vl
```

This command creates pairs for all LUs assigned to group Oradb1 in the configuration definition file (two pairs for the configuration in the above figure).

- Designate a volume name (oradev1-1) and a local host P-VOL a case.

```
# paircreate -g Oradb1 -d oradev1-1 -vl
```

This command creates pairs for all LUs designated as oradev1-1 in the configuration definition file (CL1-A,T1,L1 and CL1-D,T2,L1 for the configuration in the above figure).

- Designate a group name, and display pair status.

```

# pairdisplay -g Oradb1
Group   PairVol (L/R) (Port#,TID,LU-M),      Seq#,LDEV#..P/S,
Status, Seq#,P-LDEV# M
oradb1  oradev1-1 (L) (CL1-A, 1, 1 - 1)  30053  18..P-VOL
COPY    30053      22  -
oradb1  oradev1-1 (R) (CL2-C, 2, 1 - 0)  30053  22..S-VOL
COPY    ----- 18  -
oradb1  oradev1-2 (L) (CL1-A, 1, 2 - 1)  30053  19..P-VOL
COPY    30053      23  -
oradb1  oradev1-2 (R) (CL2-C, 2, 2 - 0)  30053  23..S-VOL
COPY    ----- 19  -

```

Example of CCI commands with HOSTC (group Oradb1):

- When the command execution environment is not set, set HORCC_MRCF to the environment variable.

For C shell: # setenv HORCC_MRCF 1

For Windows: set HORCC_MRCF=1

- Designate a group name and a remote host P-VOL a case.

```
# paircreate -g Oradb1 -vr
```

This command creates pairs for all LUs assigned to group Oradb1 in the configuration definition file (two pairs for the configuration in the above figure).

- Designate a volume name (oradev1-1) and a remote host P-VOL a case.


```
# paircreate -g Oradb1 -d oradev1-1 -vr
```

This command creates pairs for all LUs designated as oradev1-1 in the configuration definition file (CL1-A,T1,L1 and CL1-D,T2,L1 for the configuration in the above figure).

- Designate a group name and display pair status.

```
# pairdisplay -g Oradb1
Group   PairVol(L/R) (Port#,TID,LU-M), Seq#, LDEV#..P/S,
Status, Seq#, P-LDEV# M
oradb1  oradev1-1(L) (CL2-C, 2, 1 - 0) 30053 22..S-VOL
COPY    ----- 18 -
oradb1  oradev1-1(R) (CL1-A, 1, 1 - 1) 30053 18..P-VOL
COPY    30053 22 -
oradb1  oradev1-2(L) (CL2-C, 2, 2 - 0) 30053 23..S-VOL
COPY    ----- 19 -
oradb1  oradev1-2(R) (CL1-A, 1, 2 - 1) 30053 19..P-VOL
COPY    30053 23 -
```

Example of CCI commands with HOSTA (group Oradb2):

- When the command execution environment is not set, set HORCC_MRCF to the environment variable.

For C shell: # setenv HORCC_MRCF 1

For Windows: set HORCC_MRCF=1

- Designate a group name (Oradb2) and a local host P-VOL a case.

```
# paircreate -g Oradb2 -vl
```

This command creates pairs for all LUs assigned to group Oradb2 in the configuration definition file (two pairs for the configuration in above figure).

- Designate a volume name (oradev2-1) and a local host P-VOL a case.

```
# paircreate -g Oradb2 -d oradev2-1 -vl
```

This command creates pairs for all LUs designated as oradev2-1 in the configuration definition file (CL1-A,T1,L1 and CL1-D,T2,L1 for the configuration in the above figure).

- Designate a group name and display pair status.

```
# pairdisplay -g Oradb2
Group   PairVol(L/R) (Port#,TID,LU-M), Seq#, LDEV#..P/S,
Status, Seq#, P-LDEV# M
oradb2  oradev2-1(L) (CL1-A, 1, 1 - 2) 30053 18..P-VOL
COPY    30053 24 -
oradb2  oradev2-1(R) (CL2-D, 2, 1 - 0) 30053 24..S-VOL
COPY    ----- 18 -
oradb2  oradev2-2(L) (CL1-A, 1, 2 - 2) 30053 19..P-VOL
COPY    30053 25 -
oradb2  oradev2-2(R) (CL2-D, 2, 2 - 0) 30053 25..S-VOL
COPY    ----- 19 -
```

Example of CCI commands with HOSTD (group Oradb2):

- When the command execution environment is not set, set HORCC_MRCF to the environment variable.

For C shell: # setenv HORCC_MRCF 1

For Windows: set HORCC_MRCF=1

- Designate a group name and a remote host P-VOL a case.
paircreate -g Oradb2 -vr

This command creates pairs for all LUs assigned to group Oradb2 in the configuration definition file (two pairs for the configuration in the above figure).

- Designate a volume name (oradev2-1) and a remote host P-VOL a case.
paircreate -g Oradb2 -d oradev2-1 -vr

This command creates pairs for all LUs designated as oradev2-1 in the configuration definition file (CL1-A,T1,L1 and CL1-D,T2,L1 for the configuration in the above figure).

- Designate a group name and display pair status.

```
# pairdisplay -g Oradb2
Group   PairVol (L/R) (Port#,TID,LU-M),   Seq#,   LDEV#...P/S,
Status, Seq#,P-LDEV# M
oradb2  oradev2-1 (L) (CL2-D, 2, 1 - 0)   30053   24...S-VOL
COPY    -----    18    -
oradb2  oradev2-1 (R) (CL1-A, 1, 1 - 2)   30053   18...P-VOL
COPY    30053      24    -
oradb2  oradev2-2 (L) (CL2-D, 2, 2 - 0)   30053   25...S-VOL
COPY    -----    19    -
oradb2  oradev2-2 (R) (CL1-A, 1, 2 - 2)   30053   19...P-VOL
COPY    30053      25    -
```

The command device is defined using the system raw device name (character-type device file name). The command device defined in the configuration definition file must be established in a way to be following either every instance. If one command device is used between different instances on the same SCSI port, then the number of instances is up to 16 per command device. If this restriction is exceeded, then use a different SCSI path for each instance. For example, the command devices for the following figure would be:

- **HP-UX:**

HORCM_CMD of HORCMINST0 = /dev/rdisk/c0t0d1 HORCM_CMD of
HORCMINST1 = /dev/rdisk/c1t0d1

- **Solaris:**

HORCM_CMD of HORCMINST0 = /dev/rdisk/c0t0d1s2 HORCM_CMD of
HORCMINST1 = /dev/rdisk/c1t0d1s2

For Solaris operations with CCI version 01-09-03/04 and higher, the command device does not need to be labeled during format command.

- **AIX:**

HORCM_CMD of HORCMINST0 = /dev/rhdiskXX HORCM_CMD of
HORCMINST1 = /dev/rhdiskXX

where XX = device number assigned by AIX

- **Tru64 UNIX:**

HORCM_CMD of HORCMINST0 = /dev/rrzbXXc HORCM_CMD of
HORCMINST1 = /dev/rrzbXXc
where XX = device number assigned by Tru64 UNIX

- **Windows 2012/2008:**

HORCM_CMD of HORCMINST0 = \\.\CMD-Ser#-ldev#-Port# HORCM_CMD
of HORCMINST1 = \\.\CMD-Ser#-ldev#-Port#

- **Linux, z/Linux:**

HORCM_CMD of HORCMINST0 = /dev/sdX HORCM_CMD of HORCMINST1
= /dev/sdX
where X = disk number defined by Linux, z/Linux

- **IRIX64:**

HORCM_CMD for HOSTA (/etc/horcm0.conf)...
/dev/rdisk/dks0d0l1vol or /dev/rdisk/node_wwn/lun1vol/c0p0
HORCM_CMD for HOSTA (/etc/horcm1.conf)...
/dev/rdisk/dks1d0l1vol or /dev/rdisk/node_wwn/lun1vol/c1p0




Figure B-13 ShadowImage Configuration Example with Cascade Pairs

[Note 1] : Input the raw device (character device) name of UNIX/Windows system for command device.

See [Correspondence of the configuration definition file for cascading volume and mirror descriptors on page B-39](#) for more information about ShadowImage cascading configurations.

Example of CCI commands with Instance-0 on HOSTA:

- When the command execution environment is not set, set an instance number.

For C shell: # setenv HORCMINST 0 # setenv HORCC_MRCF 1

For Windows: set HORCMINST=0 set HORCC_MRCF=1

- Designate a group name (Oradb) and a local instance P- VOL a case.

```
# paircreate -g Oradb -vl
# paircreate -g Oradb1 -vr
```

These commands create pairs for all LUs assigned to groups Oradb and Oradb1 in the configuration definition file.

- Designate a group name and display pair status.

```
# pairdisplay -g oradb -m cas
Group   PairVol (L/R) (Port#,TID,LU-M), Seq#, LDEV#. P/S,
Status, Seq#, P-LDEV# M
oradb   oradev1 (L)   (CL1-A , 1, 1-0) 30053 266.. P-VOL
PAIR,   30053 268 -
oradb   oradev1 (R)   (CL1-D , 2, 1-0) 30053 268.. S-VOL
PAIR,   ----- 266 -
oradb1  oradev11 (R)  (CL1-D , 2, 1-1) 30053 268.. P-VOL
PAIR,   30053 270 -
oradb2  oradev21 (R)  (CL1-D , 2, 1-2) 30053 268.. SMPL
----,   ----- ---- -
oradb   oradev2 (L)   (CL1-A , 1, 2-0) 30053 267.. P-VOL
PAIR,   30053 269 -
oradb   oradev2 (R)   (CL1-D , 2, 2-0) 30053 269.. S-VOL
PAIR,   ----- 267 -
oradb1  oradev12 (R)  (CL1-D , 2, 2-1) 30053 269.. P-VOL
PAIR,   30053 271 -
oradb2  oradev22 (R)  (CL1-D , 2, 2-2) 30053 269.. SMPL
----,   ----- ---- -
```

Example of CCI commands with Instance-1 on HOSTA:

- When the command execution environment is not set, set an instance number.

For C shell: # setenv HORCMINST 1 # setenv HORCC_MRCF 1

For Windows: set HORCMINST=1 set HORCC_MRCF=1

- Designate a group name and a remote instance P-VOL a case.

```
# paircreate -g Oradb -vr
# paircreate -g Oradb1 -vl
```

These commands create pairs for all LUs assigned to groups Oradb and Oradb1 in the configuration definition file.

- Designate a group name and display pair status.

```
# pairdisplay -g oradb -m cas
Group   PairVol (L/R) (Port#,TID,LU-M), Seq#, LDEV#. P/S, Status,
Seq#, P-LDEV# M
oradb   oradev1 (L)   (CL1-D , 2, 1-0) 30053 268.. S-VOL
PAIR,   ----- 266 -
oradb1  oradev11 (L)  (CL1-D , 2, 1-1) 30053 268.. P-VOL PAIR,
```

```

30053      270  -
oradb2   oradev21 (L) (CL1-D , 2, 1-2) 30053  268..SMPL
-----,-----
oradb    oradev1 (R) (CL1-A , 1, 1-0) 30053  266..P-VOL PAIR,
30053    268  -
oradb    oradev2 (L) (CL1-D , 2, 2-0) 30053  269..S-VOL
PAIR,----- 267  -
oradb1   oradev12 (L) (CL1-D , 2, 2-1) 30053  269..P-VOL PAIR,
30053    271  -
oradb2   oradev22 (L) (CL1-D , 2, 2-2) 30053  269..SMPL
-----,-----
oradb    oradev2 (R) (CL1-A , 1, 2-0) 30053  267..P-VOL PAIR,
30053    269  -

```

The command device is defined using the system raw device name (character-type device file name). The command device defined in the configuration definition file must be established in a way to be following either every instance. If one command device is used between different instances on the same SCSI port, then the number of instances is up to 16 per command device. If this restriction is exceeded, then use a different SCSI path for each instance. For example, the command devices for the following figures would be:

- **HP-UX:**
HORCM_CMD of HOSTA (/etc/horcm.conf) ... /dev/rdisk/c0t0d1
HORCM_CMD of HOSTB (/etc/horcm.conf) ... /dev/rdisk/c1t0d1
HORCM_CMD of HOSTB (/etc/horcm0.conf) ... /dev/rdisk/c1t0d1
- **Solaris:**
HORCM_CMD of HOSTA (/etc/horcm.conf) ... /dev/rdisk/c0t0d1s2
HORCM_CMD of HOSTB (/etc/horcm.conf) ... /dev/rdisk/c1t0d1s2
HORCM_CMD of HOSTB (/etc/horcm0.conf) ... /dev/rdisk/c1t0d1s2
For Solaris operations with CCI version 01-09-03/04 and higher, the command device does not need to be labeled during format command.
- **AIX:**
HORCM_CMD of HOSTA (/etc/horcm.conf) ... /dev/rhdiskXX HORCM_CMD
of HOSTB (/etc/horcm.conf) ... /dev/rhdiskXX HORCM_CMD of
HOSTB (/etc/horcm0.conf) ... /dev/rhdiskXX
where XX = device number assigned by AIX
- **Tru64 UNIX:**
HORCM_CMD of HOSTA (/etc/horcm.conf) ... /dev/rrzbXXc HORCM_CMD
of HOSTB (/etc/horcm.conf) ... /dev/rrzbXXc HORCM_CMD of HOSTB (/etc/
horcm0.conf) ... /dev/rrzbXXc
where XX = device number assigned by Tru64 UNIX
- **Windows 2012/2008:**
HORCM_CMD of HOSTA (/etc/horcm.conf) ... \\.\CMD-Ser#-ldev#-Port#
HORCM_CMD of HOSTB (/etc/horcm.conf) ... \\.\CMD-Ser#-ldev#-Port#
HORCM_CMD of HOSTB (/etc/horcm0.conf) ... \\.\CMD-Ser#-ldev#-Port#
- **Linux, z/Linux:**

HORCM_CMD of HOSTA(/etc/horcm.conf) ... /dev/sdX HORCM_CMD of
HOSTB(/etc/horcm.conf) ... /dev/sdX HORCM_CMD of HOSTB(/etc/
horcm0.conf) ... /dev/sdX


where X = device number assigned by Linux, z/Linux

- **IRIX64:**

HORCM_CMD for HOSTA (/etc/horcm.conf) ... /dev/rdisk/dks0d0l1vol
or /dev/rdisk/node_wwn/lun1vol/c0p0

HORCM_CMD for HOSTB (/etc/horcm.conf) ... /dev/rdisk/dks1d0l1vol
or /dev/rdisk/node_wwn/lun1vol/c1p0

HORCM_CMD for HOSTB (/etc/horcm0.conf)... /dev/rdisk/dks1d0l1vol
or /dev/rdisk/node_wwn/lun1vol/c1p0



Shaded portions: If HORCMINST0 needs to operate TrueCopy's paired volume, then describe **oradb**.

Figure B-14 TC/SI Configuration Example with Cascade Pairs

[Note 1] : Input the raw device (character device) name of UNIX/Windows system for command device.

Example of CCI commands with HOSTA and HOSTB:

- Designate a group name (Oradb) on TrueCopy environment of HOSTA.
paircreate -g Oradb -v1
- Designate a group name (Oradb1) on ShadowImage environment of HOSTB. When the command execution environment is not set, set HORCC_MRCF.

For C shell: # setenv HORCC_MRCF 1

For Windows: set HORCC_MRCF=1

paircreate -g Oradb1 -vl

These commands create pairs for all LUs assigned to groups Oradb and Oradb1 in the configuration definition file (four pairs for the configuration in the above figures).

- Designate a group name and display pair status on HOSTA.

```
# pairdisplay -g oradb -m cas
Group   PairVol (L/R) (Port#,TID,LU-M),Seq#,LDEV#.P/S,Status,
Seq#,P-LDEV# M
oradb   oradev1 (L)   (CL1-A , 1, 1-0)30052 266..SMPL
-----
oradb   oradev1 (L)   (CL1-A , 1, 1) 30052 266..P-VOL COPY,
30053 268 -
oradb1  oradev11 (R)  (CL1-D , 2, 1-0)30053 268..P-VOL COPY,
30053 270 -
oradb2  oradev21 (R)  (CL1-D , 2, 1-1)30053 268..SMPL
-----
oradb   oradev1 (R)   (CL1-D , 2, 1) 30053 268..S-VOL
COPY,----- 266 -
oradb   oradev2 (L)   (CL1-A , 1, 2-0)30052 267..SMPL
-----
oradb   oradev2 (L)   (CL1-A , 1, 2) 30052 267..P-VOL COPY,
30053 269 -
oradb1  oradev12 (R)  (CL1-D , 2, 2-0)30053 269..P-VOL COPY,
30053 271 -
oradb2  oradev22 (R)  (CL1-D , 2, 2-1)30053 269..SMPL
-----
oradb   oradev2 (R)   (CL1-D , 2, 2) 30053 269..S-VOL
COPY,----- 267 -
```

Example of CCI commands with HOSTB:

- Designate a group name (oradb) on TrueCopy environment of HOSTB.
paircreate -g Oradb -vr
- Designate a group name (Oradb1) on ShadowImage environment of HOSTB. When the command execution environment is not set, set HORCC_MRCF.

For C shell: # setenv HORCC_MRCF 1

For Windows: set HORCC_MRCF=1

paircreate -g Oradb1 -vl

This command creates pairs for all LUs assigned to group Oradb1 in the configuration definition file (four pairs for the configuration in the above figures).

- Designate a group name and display pair status on TrueCopy environment of HOSTB.

```
# pairdisplay -g oradb -m cas
Group   PairVol (L/R) (Port#,TID,LU-M),Seq#,LDEV#.P/S,Status,
Seq#,P-LDEV# M
oradb1  oradev11 (L)   (CL1-D , 2, 1-0)30053 268..P-VOL PAIR,
```

```

30053      270  -
oradb2 oradev21 (L) (CL1-D , 2, 1-1) 30053 268..SMPL
-----,-----
oradb oradev1 (L) (CL1-D , 2, 1) 30053 268..S-VOL
PAIR,----- 266 -
oradb oradev1 (R) (CL1-A , 1, 1-0) 30052 266..SMPL
-----,-----
oradb oradev1 (R) (CL1-A , 1, 1) 30052 266..P-VOL PAIR,
30053 268 -
oradb1 oradev12 (L) (CL1-D , 2, 2-0) 30053 269..P-VOL PAIR,
30053 271 -
oradb2 oradev22 (L) (CL1-D , 2, 2-1) 30053 269..SMPL
-----,-----
oradb oradev2 (L) (CL1-D , 2, 2) 30053 269..S-VOL
PAIR,----- 267 -
oradb oradev2 (R) (CL1-A , 1, 2-0) 30052 267..SMPL
-----,-----
oradb oradev2 (R) (CL1-A , 1, 2) 30052 267..P-VOL PAIR,
30053 269 -

```

- Designate a group name and display pair status on ShadowImage environment of HOSTB.

```

# pairdisplay -g oradb1 -m cas
Group PairVol (L/R) (Port#,TID,LU-M),Seq#,LDEV#.P/S,Status,
Seq#,P-LDEV# M
oradb1 oradev11 (L) (CL1-D , 2, 1-0) 30053 268..P-VOL PAIR,
30053 270 -
oradb2 oradev21 (L) (CL1-D , 2, 1-1) 30053 268..SMPL
-----,-----
oradb oradev1 (L) (CL1-D , 2, 1) 30053 268..S-VOL
PAIR,----- 266 -
oradb1 oradev11 (R) (CL1-D , 3, 1-0) 30053 270..S-VOL
PAIR,----- 268 -
oradb1 oradev12 (L) (CL1-D , 2, 2-0) 30053 269..P-VOL PAIR,
30053 271 -
oradb2 oradev22 (L) (CL1-D , 2, 2-1) 30053 269..SMPL
-----,-----
oradb oradev2 (L) (CL1-D , 2, 2) 30053 269..S-VOL
PAIR,----- 267 -
oradb1 oradev12 (R) (CL1-D , 3, 2-0) 30053 271..S-VOL
PAIR,----- 269 -

```

- Designate a group name and display pair status on ShadowImage environment of HOSTB (HORCMINST0).

```

# pairdisplay -g oradb1 -m cas
Group PairVol (L/R) (Port#,TID,LU-M),Seq#,LDEV#.P/S,Status,
Seq#,P-LDEV# M
oradb1 oradev11 (L) (CL1-D , 3, 1-0) 30053 270..S-VOL
PAIR,----- 268 -
oradb1 oradev11 (R) (CL1-D , 2, 1-0) 30053 268..P-VOL PAIR,
30053 270 -
oradb2 oradev21 (R) (CL1-D , 2, 1-1) 30053 268..SMPL
-----,-----
oradb oradev1 (R) (CL1-D , 2, 1) 30053 268..S-VOL
PAIR,----- 266 -
oradb1 oradev12 (L) (CL1-D , 3, 2-0) 30053 271..S-VOL
PAIR,----- 269 -
oradb1 oradev12 (R) (CL1-D , 2, 2-0) 30053 269..P-VOL PAIR,
30053 271 -

```

```

oradb2  oradev22(R) (CL1-D , 2, 2-1)30053 269..SMPL
-----,-----  -----
oradb   oradev2(R)  (CL1-D , 2, 2) 30053 269..S-VOL
PAIR,----- 267 -

```

Correspondence of the configuration definition file for cascading volume and mirror descriptors

The CCI software (HORCM) is capable of keeping a record of the multiple pair configurations per LDEV. CCI distinguishes the records of the each pair configuration by MU#. You can assign 64 MU#s for local copy products and 4 MU#s for remote copy products as the following figure, you can define up to 68 device groups (records of pair configuration) in the configuration definition file.




Figure B-15 Management of Pair configuration by Mirror Descriptors

The group name and MU# that are noted in the HORCM_DEV section of the configuration definition file are assigned to the corresponding mirror descriptors. This outline is described in the following table. "Omission of MU#" is handled as MU#0, and the specified group is registered to MU#0 on ShadowImage/Copy-on-Write Snapshot and TrueCopy/Hitachi Universal Replicator User Guide/global-active device. Also, when you note the MU# in HORCM_DEV, the sequence of the MU# can be random (for example, 2, 1, 0).

Table B-1 Assignments of Group name and MU# to Mirror Descriptors

HORCM_DEV Parameter in Configuration File	MU#0		ShadowImage (Copy-on-Write Snapshot) Only	UR/GAD
	TC/UR/GAD	SI	MU#1-#2 (MU#3-#63)	MU#1-#3
HORCM_DEV #dev_group dev_name port# TargetID LU# MU# Oradb oradev1 CL1-D 2 1	oradev1	oradev1	-	-

HORCM_DEV Parameter in Configuration File	MU#0		ShadowImage (Copy-on-Write Snapshot) Only	UR/GAD
	TC/UR/GAD	SI	MU#1-#2 (MU#3-#63)	MU#1-#3
HORCM_DEV #dev_group dev_name port# TargetID LU# MU# Oradb oradev1 CL1-D 2 1 Oradb1 oradev11 CL1-D 2 1 1 Oradb2 oradev21 CL1-D 2 1 2	oradev1	oradev1	oradev11 oradev21	-
HORCM_DEV #dev_group dev_name port# TargetID LU# MU# Oradb oradev1 CL1-D 2 1 Oradb1 oradev11 CL1-D 2 1 0 Oradb2 oradev21 CL1-D 2 1 1 Oradb3 oradev31 CL1-D 2 1 2	oradev1	oradev11	oradev21 oradev31	-
HORCM_DEV #dev_group dev_name port# TargetID LU# MU# Oradb oradev1 CL1-D 2 1 0	-	oradev1	-	-
HORCM_DEV #dev_group dev_name port# TargetID LU# MU# Oradb oradev1 CL1-D 2 1 h0	oradev1	-	-	-
HORCM_DEV #dev_group dev_name port# TargetID LU# MU# Oradb oradev1 CL1-D 2 1 0 Oradb1 oradev1 CL1-D 2 1 1 Oradb2 oradev21 CL1-D 2 1 2	-	oradev1	oradev11 oradev21	-
HORCM_DEV #dev_group dev_name port# TargetID LU# MU# Oradb oradev1 CL1-D 2 1 Oradb1 oradev11 CL1-D 2 1 0 Oradb2 oradev21 CL1-D 2 1 h1 Oradb3 oradev31 CL1-D 2 1 h2 Oradb4 oradev41 CL1-D 2 1 h3	oradev1	oradev11	-	oradev21 oradev31 oradev41

Cascade function and configuration files

Each volume in a cascading connection is described by an entry in the configuration definition file on the each HORCM instance, and each connection of the volume is specified by mirror descriptor. In the case of a ShadowImage/TrueCopy cascading connection, too, the volume is described in the configuration definition file on the same instance. The following topics present examples of ShadowImage and ShadowImage/ TrueCopy cascading configurations.

ShadowImage

The following figure shows an example of a ShadowImage cascade configuration and the associated entries in the configuration definition files. ShadowImage is a mirror configuration within one storage system, so the volumes are described in the configuration definition file for each HORCM instance: volumes T3L0, T3L4, and T3L6 in HORCMINST0, and volume T3L2 in HORCMINST1. As shown in this ShadowImage cascading connection example, the specified dev group is assigned to the ShadowImage mirror descriptor: MU#0 in HORCMINST0, and MU#0, MU#1 and MU#2 in HORCMINST1

[Figure B-17 Pairedisplay -g on HORCMINST0 on page B-42](#), [Figure B-18 Pairedisplay -g on HORCMINST1 on page B-42](#), and [Figure B-19 Pairedisplay -d on HORCMINST0 on page B-42](#) show the pairedisplay information for this example of a ShadowImage cascading configuration.






Figure B-16 ShadowImage Cascade Connection and Configuration File




```
# pairedisplay -g oradb -m cas
Group PairVol(L/R) (Port#,TID,LU-M),Seq#,LDEV#.P/S,Status, Seq#,P-LDEV# M
oradb oradev1(L) (CL1-D , 3, 0-0) 30053 266..P-VOL PAIR,30053 268 -
oradb oradev1(R) (CL1-D , 3, 2-0) 30053 268..S-VOL PAIR,----- 266 -
oradb1 oradev11(R) (CL1-D , 3, 2-1) 30053 268..P-VOL PAIR,30053 270 -
oradb2 oradev21(R) (CL1-D , 3, 2-2) 30053 268..P-VOL PAIR,30053 272 -
```

Figure B-17 Pairedisplay -g on HORCMINST0



```
# pairedisplay -g oradb -m cas
Group PairVol(L/R) (Port#,TID,LU-M),Seq#,LDEV#.P/S,Status, Seq#,P-LDEV# M
oradb oradev1(L) (CL1-D , 3, 2-0) 30053 268..S-VOL PAIR,----- 266 -
oradb1 oradev11(L) (CL1-D , 3, 2-1) 30053 268..P-VOL PAIR,30053 270 -
oradb2 oradev21(L) (CL1-D , 3, 2-2) 30053 268..P-VOL PAIR,30053 272 -
oradb oradev1(R) (CL1-D , 3, 0-0) 30053 266..P-VOL PAIR,30053 268 -
```

Figure B-18 Pairedisplay -g on HORCMINST1




```
# pairedisplay -d /dev/rdisk/c0t3d4 -m cas
Group PairVol(L/R) (Port#,TID,LU-M),Seq#,LDEV#.P/S,Status, Seq#,P-LDEV# M
oradb1 oradev11(L) (CL1-D , 3, 4-0) 30053 270..S-VOL PAIR,----- 268 -
oradb1 oradev11(R) (CL1-D , 3, 2-1) 30053 268..P-VOL PAIR,30053 270 -
oradb oradev1(R) (CL1-D , 3, 2-0) 30053 268..S-VOL PAIR,----- 266 -
oradb2 oradev21(R) (CL1-D , 3, 2-2) 30053 268..P-VOL PAIR,30053 272 -
```

Figure B-19 Pairedisplay -d on HORCMINST0

Cascading connections for TrueCopy and ShadowImage

The cascading connections for TrueCopy/ShadowImage can be set up by using three configuration definition files that describe the cascading volume entity in a configuration definition file on the same instance. The mirror descriptor of ShadowImage and TrueCopy definitely describe "0" as MU#, and the mirror descriptor of TrueCopy does not describe "0" as MU#.



Shaded portions: If HORCMINST0 needs to operate TrueCopy's paired volume, then "oradb" must describe that there is a connection to HST1 via HORCMINST0.

Figure B-20 TC/SI Cascading Connection and Configuration File

The following figures cascading configurations and the pairedisplay information for each configuration.




Figure B-21 Pairedisplay for TrueCopy on HOST1






Figure B-22 Pairedisplay for TrueCopy on HOST2 (HORCMINST)



```
# pairdisplay -g oradb -m cas
Group PairVol(L/R) (Port#,TID,LU-M),Seq#,LDEV#.P/S,Status, Seq#,P-LDEV# M
oradb1 oradev11(L) (CL1-D , 3, 2-0) 30053 268..P-VOL PAIR,30053 270 -
oradb2 oradev21(L) (CL1-D , 3, 2-1) 30053 268..P-VOL PSUS,30053 272 W
oradb oradev1(L) (CL1-D , 3, 2) 30053 268..S-VOL PAIR, ---- 266 -
oradb1 oradev1(R) (CL1-D , 3, 4-0) 30053 270. S-VOL PAIR, ---- 268 -
```

Figure B-23 Pairdisplay for ShadowImage on HOST2 (HORCMINST)



```
# pairdisplay -g oradb1 -m cas
Group PairVol(L/R) (Port#,TID,LU-M),Seq#,LDEV#.P/S,Status, Seq#,P-LDEV# M
oradb1 oradev11(L) (CL1-D , 3, 4-0) 30053 270..S-VOL PAIR,---- 268 -
oradb2 oradev11(R) (CL1-D , 3, 2-0) 30053 268..P-VOL PAIR, 30053 270 -
oradb2 oradev21(R) (CL1-D , 3, 2-1) 30053 268..P-VOL PSUS,30053 272 W
oradb oradev1 (R) (CL1-D , 3, 2) 30053 268..S-VOL PAIR, ---- 266 -

# pairdisplay -d /dev/rdisk/c0t3d4 -m cas
Group PairVol(L/R) (Port#,TID,LU-M),Seq#,LDEV#.P/S,Status, Seq#,P-LDEV# M
oradb1 oradev11(L) (CL1-D , 3, 4-0) 30053 270..S-VOL PAIR,---- 268 -
oradb2 oradev11(R) (CL1-D , 3, 2-0) 30053 268..P-VOL PAIR, 30053 270 -
oradb2 oradev21(R) (CL1-D , 3, 2-1) 30053 268..P-VOL PSUS,30053 272 W
oradb oradev1 (R) (CL1-D , 3, 2) 30053 268..S-VOL PAIR, ---- 266 -
```

Figure B-24 Pairdisplay for ShadowImage on HOST2 (HORCMINST0)

Index

A

AIX VIO, restrictions 1-9
alternate command devices 2-15

C

changing the user
 UNIX environment 2-4
 Windows environment 2-6
command devices
 alternate 2-15
 requirements 1-2
 setting 2-12
 virtual 2-14
components, removing 4-3
configuration examples B-16
configuration file
 cascading examples B-40
 creating 2-16
 editing 2-16
 examples B-2
 parameters 2-17
 sample file 2-16
configuration file parameters 2-17, B-3
 HORCM_ALLOW_INST B-7, B-16
 HORCM_CMD B-4
 HORCM_DEV B-8
 HORCM_INST B-10
 HORCM_INSTP B-14
 HORCM_LDEV B-15
 HORCM_LDEVG B-15
 HORCM_MON B-4
conversion tables, fibre-to-SCSI addresses A-5

creating the configuration definition file 2-16

D

definition file, configuration
 cascading examples B-40
 creating 2-16
 editing 2-16
 examples B-2
 parameters 2-17
 sample file 2-16
definition file, configuration parameters 2-17, B-3
 HORCM_ALLOW_INST B-7, B-16
 HORCM_CMD B-4
 HORCM_DEV B-8
 HORCM_INST B-10
 HORCM_INSTP B-14
 HORCM_LDEV B-15
 HORCM_LDEVG B-15
 HORCM_MON B-4

E

editing the configuration definition file 2-16
example configuration files B-2
example configurations B-16

F

FCP, z/Linux restrictions 1-6
fibre-to-SCSI address conversion
 example A-2
 table for HP-UX A-6

table for Solaris and IRIX A-6
table for Windows A-7
FICON, z/Linux restrictions 1-6

H

hardware installation 2-2
HORCM_ALLOW_INST B-7, B-16
HORCM_CMD B-4
HORCM_CONF 2-16
HORCM_DEV B-8
HORCM_INST B-10
HORCM_INSTP B-14
HORCM_LDEV B-15
HORCM_LDEVG B-15
HORCM_MON B-4
HORCMFCTBL A-3

I

In-Band command execution 2-8
installing hardware 2-2
installing software 2-2
 OpenVMS environment 2-7
 UNIX environment 2-3
 Windows environment 2-5
interaction with storage systems 1-29
IP versions, supported platforms 1-4
IPv6, platform support 1-13

L

license key requirements 1-2
LUN configurations A-4

M

mirror descriptors
 configuration file correspondence B-39

O

OpenVMS
 bash start-up 1-27
 DCL command examples 1-24
 DCL detached process start-up 1-21
 installation 2-7

known issues 1-20
requirements and restrictions 1-15
Out-of-Band command execution 2-8

P

parameters, configuration 2-17

R

removing software
 components 4-3
 OpenVMS environment 4-3
 UNIX environment 4-2
 Windows environment 4-3
requirements and restrictions
 AIX VIO 1-9
 OpenVMS 1-15
 system 1-2
 VMWare ESX Server 1-8
 Windows 2008 Hyper-V 1-11
 z/Linux 1-5

S

sample configuration files B-2
sample definition file 2-16
setting the command device 2-12
software installation 2-2
 OpenVMS environment 2-7
 UNIX environment 2-3
 Windows environment 2-5
software removal
 components 4-3
 OpenVMS environment 4-3
 UNIX environment 4-2
 Windows environment 4-3
software upgrade
 OpenVMS environment 3-3
 UNIX environment 3-2
 Windows environment 3-3
SVC, VMWare restrictions 1-9
system requirements 1-2

T

tables, fibre-to-SCSI address conversion A-5

troubleshooting 5-2

U

upgrading software

OpenVMS environment 3-3

UNIX environment 3-2

Windows environment 3-3

user, changing

UNIX environment 2-4

Windows environment 2-6

V

virtual command devices 2-14

VMWare ESX Server, restrictions 1-8

W

Windows 2008 Hyper-V, restrictions 1-11

Z

z/Linux, restrictions 1-5

Hitachi Data Systems

Corporate Headquarters

2845 Lafayette Street
Santa Clara, California 95050-2639
U.S.A.
www.hds.com

Regional Contact Information

Americas

+1 408 970 1000
info@hds.com

Europe, Middle East, and Africa

+44 (0)1753 618000
info.emea@hds.com

Asia Pacific

+852 3189 7900
hds.marketing.apac@hds.com

